

1971

CORVETTE



1971 CORVETTE

Production: 14,680 coupe, 7,121 convertible, 21,801 total.

1971 NUMBERS

Vehicle: 194371S100001 through 194371S121801

• For convertibles, fourth digit is a 6.

Suffix: CGT: 350ci, 270hp, at CPH: 454ci, 365hp, mt
 CGY: 350ci, 330hp(ZR1), mt CPJ: 454ci, 365hp, at
 CGZ: 350ci, 330hp(LT1), mt CPW: 454ci, 425hp, mt, ah
 CJK: 350ci, 270hp, at CPX: 454ci, 425hp, at, ah
 CJL: 350ci, 270hp, mt

Block: 3970010: 350ci, 270hp, 330hp
 3963512: 454ci, 365hp, 425hp

Head: 3946074: 454ci, 425hp 3993820: 454ci, 365hp
 3973487: 350ci, 270hp, 330hp 3994026: 454ci, 425hp (uu)

Carburetor: Rochester Q-jet #7041204: 454ci, 365hp, at
 Rochester Q-jet #7041205: 454ci, 365hp, mt
 Rochester Q-jet #7041212: 350ci, 270hp, at
 Rochester Q-jet #7041213: 350ci, 270hp, mt
 Holley R4801A #3989021: 350ci, 330hp, mt
 Holley R4802A #3986195: 454ci, 425hp, mt
 Holley R4803A #3986196: 454ci, 425hp, at

Distributor: 1112038: 350ci, 330hp, ig 1112053: 454ci, 425hp, at, ig
 1112050: 350ci, 270hp 1112076: 454ci, 425hp, mt, ig
 1112051: 454ci, 365hp

Alternator: 1100543: 454ci, 365hp, 425hp 1100544: All with ac
 1100950: 350ci, 270hp, 330hp

Ending Vehicle: Aug 70: 101212 Jan 71: 108230 May 71: 118223
 Sep 70: 102226 Feb 71: 110886 Jun 71: 120686
 Nov 70: 102675 Mar 71: 113626
 Dec 70: 105269 Apr 71: 115983

Abbreviations: ac=air conditioning, ah=aluminum heads,
 at=automatic transmission, ci=cubic inch, hp=horsepower, ig=transistor
 ignition, mt=manual transmission, uu=uncertain usage.

1971 FACTS

- The 1971 Corvette was one of the least-changed in appearance. A labor dispute in May 1969 caused 1969 production to run long, shortening normal 1970 production by over four months. Chevrolet then treated 1971 Corvette production as an extension of 1970. Plus, GM directed its divisions to reduce octane requirements in 1971 engines, an effort which carried a higher priority than appearance changes.
- With the exception of RPO LS6, 1971 engines were detuned variants of 1970 engines. GM's intention in reducing octane requirements to 91 (research) in 1971 was to give oil companies phase-in time for the unleaded fuels needed for catalytic converters still four years away.
- The 454ci LS6 engine with 425hp was designed to operate on low-lead fuel, but a comparable engine was not available in 1970, so it won the horsepower race for the two years despite its lower octane appetite. It featured aluminum heads and could be combined with an automatic transmission, although not when combined with the ZR2 package.
- One visible clue to a 1971's outward appearance was amber parking light lenses, although very early production had clear lenses.
- The 1971 Corvette was the last model to feature the fiber-optics light monitoring system. It's thought the cost savings permitted inclusion of the optional anti-theft alarm system as standard equipment the following year.

1971 OPTIONS

RPO #	DESCRIPTION	QTY	RETAIL \$
19437	Base Corvette Sport Coupe	14,680	\$5,496.00
19467	Base Corvette Convertible	7,121	5,259.00
—	Custom Interior Trim	2,602	158.00
A31	Power Windows	6,192	79.00
A85	Custom Shoulder Belts (std with coupe)	677	42.00
C07	Auxiliary Hardtop (for convertible)	2,619	274.00
C08	Vinyl Covering (for auxiliary hardtop)	832	63.00
C50	Rear Window Defroster	1,598	42.00
C60	Air Conditioning	11,481	459.00
—	Optional Rear Axle Ratio	2,395	13.00
J50	Power Brakes	13,558	47.00
LS5	454ci, 365hp Engine	5,097	295.00
LS6	454ci, 425hp Engine	188	1,221.00
LT1	350ci, 330hp Engine	1,949	483.00
M21	4-Speed Man Trans, close ratio	2,387	0.00
M22	4-Speed Man Trans, close ratio, heavy duty ...	130	100.00
M40	Turbo Hydra-Matic Automatic Transmission ...	10,060	0.00
N37	Tilt-Telescopic Steering Column	8,130	84.30
N40	Power Steering	17,904	115.90
P02	Deluxe Wheel Covers	3,007	63.00
PT7	White Stripe Tires, F70x15, nylon	6,711	28.00
PU9	White Letter Tires, F70x15, nylon	12,449	42.00
T60	Heavy Duty Battery (std with LS5, LS6)	1,455	15.80
UA6	Alarm System	8,501	31.60
U69	AM-FM Radio	18,078	178.00
U79	AM-FM Radio, stereo	3,431	283.00
ZR1	Special Purpose LT1 Engine Package	8	1,010.00
ZR2	Special Purpose LS6 Engine Package	12	1,747.00

- A 350ci, 270hp engine, 4-speed wide-ratio manual transmission, vinyl interior trim, and soft top (conv) or T-tops were included in the base price.
- The ZR1 included the LT1 engine, M22 transmission, heavy-duty power brakes, transistor ignition, special aluminum radiator, and special springs, shocks, and front and rear stabilizer bars (ZR1s have appeared with and without rear stabilizers). ZR1s also had metal fan shrouds. RPOs A31, C50, C60, N40, P02, UA6, U69 and U79 were not available with ZR1.
- The ZR2 package was similar to ZR1, except ZR2 included RPO LS6, the 454ci, 425hp engine.
- Custom interior included leather seat trim, wood-grain accents and lower carpet trim on interior door panels, wood-grain accents on console, and special cut-pile carpeting.
- M40 was no cost with the base 350ci, 270hp engine, but cost \$100.35 with LS5 or LS6. It was not available with LT1, ZR1 or ZR2.

1971 COLORS

CODE	EXTERIOR	QTY	SOFTTOP	WHEELS	INTERIORS
905	Nevada Silver	1,177	Bk-W	Silver	Bk-Db-Dg-R
912	Sunflower Yellow	1,177	Bk-W	Silver	Bk-Dg-S
972	Classic White	1,875	Bk-W	Silver	Bk-Db-Dg-R-S
973	Mille Miglia Red	2,180	Bk-W	Silver	Bk-R
976	Mulsanne Blue	2,465	Bk-W	Silver	Bk-Db
979	Bridgehampton Blue	1,417	Bk-W	Silver	Bk-Db
983	Brands Hatch Green	3,445	Bk-W	Silver	Bk-Dg
987	Ontario Orange	2,269	Bk-W	Silver	Bk-Dg-S
988	Steel Cities Gray	1,591	Bk-W	Silver	Bk-S
989	War Bonnet Yellow ...	3,706	Bk-W	Silver	Bk-Dg-S

- Suggested interiors shown. Other combinations were possible.
- Exterior color quantity total is 499 short of total production.

Interior Codes: std=Bk/V, 402=Bk/L, 407=R/V, 412=Db/V, 417=S/V, 420=S/L, 423=Dg/V.

Abbreviations: Bk=Black, Db=Dark Blue, Dg=Dark Green, L=Leather, R=Red, S=Saddle, V=Vinyl, W=White.

The Corvette Black Book

1953-1993

October 1992

Published by

Michael Bruce Associates, Inc.
Michael Antonick, President
Post Office Box 396
Powell, Ohio 43065



CONTENTS

Glossary	4	1965 Corvette	44	1981 Corvette	76
Instructions	6	1966 Corvette	46	1982 Corvette	78
Statistics	12	1967 Corvette	48	1983 Corvette	80
Chronology	14	1968 Corvette	50	1985 Corvette	82
1953 Corvette	20	1969 Corvette	52	1986 Corvette	84
1954 Corvette	22	1970 Corvette	54	1987 Corvette	86
1955 Corvette	24	1971 Corvette	56	1988 Corvette	88
1956 Corvette	26	1972 Corvette	58	1989 Corvette	90
1957 Corvette	28	1973 Corvette	60	1990 Corvette	92
1958 Corvette	30	1974 Corvette	62	1991 Corvette	94
1959 Corvette	32	1975 Corvette	64	1992 Corvette	96
1960 Corvette	34	1976 Corvette	66	1993 Corvette	98
1961 Corvette	36	1977 Corvette	68	Notes	100
1962 Corvette	38	1978 Corvette	70	Photos/Specs	104
1963 Corvette	40	1979 Corvette	72	Literature	124
1964 Corvette	42	1980 Corvette	74	Coupons	127

© Michael Bruce Associates, Inc., 1978, 1980, 1983, 1985, 1988, 1991, 1992. All rights reserved under Pan American and Universal Copyright Conventions by Michael Bruce Associates, Inc. Reproduction without permission is prohibited. Because of the possibility of errors, exceptions or other reasons for inaccuracy, the publisher and author disclaim responsibility for the accuracy of any or all information presented in this publication.

Michael Bruce Associates, Inc. acknowledges with appreciation the following enthusiasts who contributed their expertise to this and previous editions of the *Corvette Black Book*: Nolan Adams, Dan Aldridge, John Argyer, Pat Baker, Jane Barthelme, Michele Boring, Kent Brooks, Barry Brown, David Burroughs, Steve Champromond, Dr. M. F. Dobkins, Bob Eckling, the late Sam Feltz, John Hibben, Mike Hunt, Alan Kaplan, Paul Kitchen, Gary Komar, Ralph Kramer and staff, Jim Kruglioff, Gary Lusk, Bill Locke, Bob Lopuski, Bob McDorman, Chip Miller, Bill Mock, Brian Pearce, John Poloney, Bill Rhodes, Jeffrey Smith, Mark & Dixie Smith, Lou Vitale, Jerry Wadsworth, Jerry Weichers and Don Williams. Thanks also to Callaway Engineering, to Mercury Marine, and to the Chevrolet Motor Division of General Motors Corporation.

Notice: The *Corvette Black Book* and its publisher, Michael Bruce Associates, Inc. have no relationship or connection whatever with Hearst Business Media Corporation, its parent or affiliated corporations, or the *Black Book* published by National Auto Research Division of Hearst Business Media Corporation.

Michael Bruce Associates, Inc. and the *Corvette Black Book* are not associated with or sponsored by General Motors or its Chevrolet Motor Division.

Cover: Photo and design by Mike Antonick. 1963 Corvette owned by Bill Munzer; restored by Bill Munzer and Don Williams.

Printed and bound in the United States of America.

ISBN: 0-933534-35-3

BOOK TRADE DISTRIBUTION BY:
Motorbooks International
A Division of Motorbooks, Inc.
1301 North 17th Street
Ishpeming, Michigan 49901, U.S.A.

BLACK BOOK ORDER FORM

Send _____ copies of the

Corvette Black Book 1953-1993

@ \$11.95 each \$ _____

Ohio residents add .72 sales tax _____

Postage/hard shipping container _____ 3.00

Check or money order enclosed \$ _____

Name _____

Street _____

City _____

State _____ Zip _____

Mail Order To: Michael Bruce Associates, Inc.

Post Office Box 396

Powell, Ohio 43065

BLACK BOOK ORDER FORM

Send _____ copies of the

Corvette Black Book 1953-1993

@ \$11.95 each \$ _____

Ohio residents add .72 sales tax _____

Postage/hard shipping container _____ 3.00

Check or money order enclosed \$ _____

Name _____

Street _____

City _____

State _____ Zip _____

Mail Order To: Michael Bruce Associates, Inc.

Post Office Box 396

Powell, Ohio 43065

SECTION 0

GENERAL INFORMATION AND LUBRICATION

CONTENTS OF THIS SECTION

	Page
General Information	0-1
Lubrication	0-10

GENERAL INFORMATION

	Page		Page
Model Identification (Except Corvette)	0-1	Number Locations	0-3
Vehicle Dimensions (Except Corvette)	0-2	Vehicle Serial Number	0-3
Corvette Model Identification	0-3	Keys and Locks	0-4
Corvette Vehicle Dimensions	0-3	Pushing to Start Engine	0-4
Unit and Serial Numbers	0-3	Towing Vehicles	0-4
Engine and Transmission Number (V.I.N.)	0-3	Lifting Vehicles	0-4

MODEL IDENTIFICATION

Series	Model Number		Description
	6-Cyl.	V-8	
Biscayne	15369	15469	4-Door Sedan, 6-Pass.
Brookwood	—	15435	4-Door Station Wagon, 2-Seat
Bel Air	15569	15669	4-Door Sedan, 6-Pass.
Townsmen	—	15835	4-Door Station Wagon, 2-Seat
	—	15845	4-Door Station Wagon, 3-Seat
Impala	16369	16469	4-Door Sedan, 6-Pass.
	—	16439	4-Door Sport Sedan, 6-Pass.
	16357	16457	2-Door Sport Coupe, 5-Pass.
	—	16467	2-Door Convertible, 5-Pass.
Kingswood	—	16435	4-Door Station Wagon, 2-Seat
—	—	16445	4-Door Station Wagon, 3-Seat
Impala Custom	—	16447	2-Door Sport Coupe, 5-Pass.
Caprice	—	16639	4-Door Sport Sedan, 6-Pass.
	—	16647	2-Door Sport Coupe, 5-Pass.
Kingswood Estate	—	16635	4-Door Station Wagon, 2-Seat
	—	16645	4-Door Station Wagon, 3-Seat
Nomad	13136	13236	4-Door Station Wagon, 2-Seat
Camaro	12387	12487	2-Door Sport Coupe 4-Pass.
Greenbrier	13336	13436	4-Door Station Wagon, 2-Seat
	—	13446	4-Door Station Wagon, 3-Seat
Malibu	13569	13669	4-Door Sedan, 6-Pass.
	13539	13639	4-Door Sport Sedan, 6 Pass.
	13537	13637	2-Door Sport Coupe, 5-Pass.*
	13567	13667	2-Door Convertible, 5-Pass.*
Concours	13536	13636	4-Door Station Wagon, 2-Seat
	—	13646	4-Door Station Wagon, 3-Seat
Monte Carlo	—	13857	2-Door Custom Coupe, 5-Pass.*
Concours Estate	—	13836	4-Door Station Wagon, 2-Seat
	—	13846	4-Door Station Wagon, 3-Seat
El Camino	13380	13480	2-Door Sedan Pickup, 3-Pass. Deluxe
	13580	13680	2-Door Sedan Pickup, 3-Pass. Malibu
Nova	—	—	—
	11327	11427	2-Door Sport Coupe, 5-Pass.
—	11369	11469	4-Door Sedan, 6-Pass.

*4-Passenger when optional bucket seats are ordered.

VEHICLE DIMENSIONS

BISCAYNE, BROOKWOOD, BEL AIR, TOWNSMAN, IMPALA,
KINGSWOOD, IMPALA CUSTOM CAPRICE, KINGSWOOD ESTATE

Model	Sedan	2-Door Sport Coupe	Convertible Coupe	Station Wagon
Length Overall	216.4"	216.4"	216.4"	223.2"
Width Overall (Body)	76.5"	79.5"	79.5"	79.5"
Height Overall	54.1"	53.6"	53.5"	57.1"
Wheelbase	21.5"	121.5"	121.5"	125.0"
Tread-Front	63.8"	63.8"	63.8"	64.1"
Tread-Rear	63.7"	63.7"	63.7"	63.0"
Curb Weight: Approximately 3848 lbs. 4-Door Sedan with L-6 Engine; 4006 lbs. with V-8 Engine.				

NOMAD, 300 DELUXE, GREENBRIER, MALIBU, CONCOURS,
CONCOURS ESTATE WAGON, EL CAMINO

Model	Sedan	2-Door Sport Coupe	Convertible Coupe	Station Wagon	Sedan Pickup
Length Overall	201.2"	197.2"	197.2"	207.5"	207.5"
Width Overall (Body)	75.4"	75.4"	75.4"	75.4"	75.4"
Height Overall	53.3"	52.7"	52.9"	54.4"	54.4"
Wheelbase	116.0"	112.0"	112.0"	116.0"	116.0"
Tread-Front	60.0"	60.0"	60.0"	59.3"*	59.3"*
Tread-Rear	59.9"	59.9"	59.9"	59.2"	59.2"
Curb Weight: Approximately 3297 lbs. 4-Door Sedan with L-6 Engine 3430 lbs. with V-8 Engine.					
*60.2" w/Disc Brakes.					

MONTE CARLO

Model	Custom Coupe
Length Overall . . .	205.8"
Width Overall (Body)	75.6"
Height Overall . . .	52.9"
Wheelbase	116.0"
Tread-Front	60.2"
Tread-Rear	59.3"
Weight: Custom Coupe 3564 lbs.	

CAMARO

Model	Custom Coupe
Length Overall . . .	188.0"
Width Overall (Body)	74.4"
Height Overall . . .	50.1"
Wheelbase	108.0"
Tread-Front	60.6"
Tread-Rear	60.0"
Weight: With L6 Eng. 3167 lbs. With V-8 Eng. 3313 lbs.	

NOVA

Model	Sedan	2-Door Sport Coupe
Length Overall . . .	189.4"	189.4"
Width Overall (Body)	72.4"	72.4"
Height Overall . . .	53.9"	52.5"
Wheelbase	111.0"	111.0"
Tread-Front	59.0"	58.9"
Tread-Rear	58.9"	58.9"
Curb Weight: Approximately 3028 lbs. with L-6 Engine; 3169 with V-8 Engine.		

MODEL IDENTIFICATION—CORVETTE

Model Number	Description
19437	2-Door Sport Coupe, 2-Passenger
19467	2-Door Convertible, 2-Passenger

VEHICLE DIMENSIONS—CORVETTE

Model	Convertible	Sport Coupe
Length Overall	182.5"	
Width Overall (Body) . .	69.2"	
Height Overall	47.9"	47.8"
Wheelbase	98.0"	
Tread-Front	58.7"	
Tread-Rear	59.4"	
Curb Weight: 3220 lbs. Convertible 3210 lbs. Sport Coupe with Base V-8		

SERIAL NUMBERS


For the convenience of servicemen when writing up certain business papers, such as Warranty Claims Product Information Reports, or reporting product failures in any way, we are showing on a chart, the location of various unit numbers. These unit numbers and their prefixes and suffixes are necessary on these papers for various reasons--such as accounting, follow-up on production, etc.

The prefixes on certain units identify the plant in which the unit was manufactured, and thereby permits proper follow-up of the plant involved to get corrections made when necessary.

ENGINE AND TRANSMISSION NUMBER

The Vehicle Identification Number is stamped on the engine and transmission of each vehicle (see chart for location).

Example:



At multi-car plants where more than one Chevrolet series is produced, the VIN sequence numbers will be staggered to eliminate duplication of component identification numbers.

Example:

<u>Los Angeles</u>	<u>VIN Sequence</u>
15000-16000 Series (First Vehicle)	000001
13000 Series (First Vehicle)	100001

VEHICLE COMPONENT SERIAL AND UNIT NUMBER LOCATION

Component	Model	Location
Vehicle Serial Number Plate	All	Top of instrument panel left, front
Body Number, Trim and Paint Plate	15-16000 Series 13000 Series 11000 Series 12000 Series 19000 Series	Upper right-hand side of dash panel Upper left-hand side of dash panel Upper left-hand side of dash panel Upper left-hand side of dash panel Upper left-hand door hinge pillar
Engine and Transmission Vehicle Identification Number	6 Cyl. 8 Cylinder 3-Spd. (Muncie) 4-Spd. (Muncie) 3-4 Spd. (Saginaw) Powerglide Turbo Hydra-matic 350 Turbo Hydra-matic 400	On pad at right-hand side of cylinder block at rear of distributor On pad at front, right-hand side of cylinder block On boss above filler plug On right side of case at lower rear of cover flange On lower right side of case adjacent to rear of cover On left upper flange of converter opening of transmission housing
Rear Axle Number	All except Corvette Corvette	On right or left axle tube adjacent to carrier On bottom surface of carrier at cover mounting flange
Delcotron	All	On top drive end frame
Starter	All	Stamped on outer case, toward rear
Battery	All	On cell cover segment, top of battery

Vehicle Serial Number

A typical vehicle serial number plate yields manufacturer's identity, vehicle type, model year, assembly plant and production unit number when broken down as shown in the following chart.

Manufacturer Identity ¹	Body Style ²	Model Year ³	Assembly Plant ⁴	Unit Number ⁵
1	5645	1	F	100025

¹ Manufacturers identity number assigned to all Chevrolet built vehicles.

² See Model Identification in this section.

³ Last number of model year (1971).

⁴ F-Flint

⁵ Unit numbering will start at 000,001 or 100,001 depending on the vehicle.

KEYS AND LOCKS

Four keys (two rectangular head and two oval head) are provided with each vehicle. The rectangular head key operates the ignition switch and front door locks. The oval-head key operates the locks for the glove box and rear compartment lid (spare tire compartment lid lock on Corvette).

PUSHING, TO START ENGINE

NOTE: Towing car to start is not recommended due to the possibility of the disabled car accelerating into tow car.

AUTOMATIC TRANSMISSION

Do not attempt to start the engine by pushing the car. Should the battery become discharged, it will be necessary to use an auxiliary battery with jumper cables to start the engine.

CAUTION: To prevent damage to electrical system, never connect booster batteries in excess of 12 volts and connect positive to positive and negative to negative.

MANUAL TRANSMISSION

When a push start is necessary turn off all electrical loads such as heater, radio, and if possible, lights, turn

on the key, depress the clutch, and place the shift lever in high gear. Release the clutch when your speed reaches 10 to 15 miles per hour.

TOWING VEHICLES

The car may be towed safely on its rear wheels with the (selector lever in "N" (Neutral) position at speeds of 35 mile per hour or less under most conditions.

However, the drive shaft must be disconnected or the car towed on its front wheels if 1) Tow speeds in excess of 35 MPH are necessary, 2) Car must be towed for extended distances (over 50 miles) or, 3) Transmission is not operating properly. If car is towed on its front wheels, the steering wheel should be secured to maintain a straight ahead position.

LIFTING VEHICLES

Many dealer service facilities and service stations are now equipped with a type of automotive hoist which must bear upon some part of the frame in order to lift the vehicle. In Figures 1 through 5 the shaded areas indicate areas recommended for hoist contact.

LIFTING THE CORVETTE

Shaded areas in Figure 5 indicate recommended points for hoist or jack contact. When using a single post hoist place hoist on frame side rail behind pickup at front and forward of #3 body mount at rear. When using a twin-post hoist, two methods are recommended.

- If no rear axle or suspension work is contemplated, use either suspension adapters or drive-on adapters at the front, and drive-in adapters at the rear. If a need for axle work develops, use jack stands beneath the frame side rails on each side and lower rear post.
- If rear axle work is contemplated, use either suspension adapters or drive-on adapters at the front and frame lift adaptors as shown in Figure 9. If frame lift adapters are not available, use jack stands.

NOTE: Wooden blocks, bolted to steel beam shown in Figure 6 are necessary to allow beam to clear exhaust system.




Fig. 5—Vehicle Lifting Points—19000 Series



Fig. 6—Frame Lift Adapters—19000 Series

LUBRICATION INDEX

	Page		Page
Engine	0-10	Distributor Cam Lubricator	0-12
Crankcase Capacities	0-10	Rear Axle	0-12
Lubrication	0-10	Transmission	0-12
SAE Viscosity Oils	0-10	3 and 4-Speed	0-12
Types of Oils	0-11	Control Linkage	0-12
Maintaining Oil Level	0-11	Clutch Cross Shaft	0-12
Engine Oil Change Interval	0-11	Automatic Transmissions	0-12
Crankcase Dilution	0-11	Chassis	0-13
Crankcase Ventilation	0-11	Chassis Lubrication	0-13
Positive Crankcase Ventilation (P.C.V.) Valve	0-11	Front Wheel Bearings	0-13
Air Injection Reactor (A.I.R.)	0-11	Brake Master Cylinder	0-13
Controlled Combustion System (C.C.S.)	0-12	Parking Brake	0-13
GM Evaporation Control System (E.C.S.)	0-12	Steering Gear	0-13
Manifold Heat Control Valve	0-12	Electrical	0-14
Engine Oil Filter	0-12	Battery Care (Energizer)	0-14
Air Cleaner	0-12	Dual Action Safety Hood Latches	0-14
Oil Wetted Paper Element Type	0-12	Air Conditioning	0-14
Fuel Filter	0-12	Body Lubrication	0-14
		Body Lubrication Points (Corvette)	0-14

The time or mileage intervals on the following pages are intended as a general guide for establishing regular maintenance and lubrication periods for your car. Sustained heavy duty or high speed operations or operation under adverse conditions may necessitate more frequent servicing.

ENGINE

CRANKCASE CAPACITY

6 Cylinder	4 qt.
8 Cylinder (307)	4 qt.
8 Cylinder (350)	4 qt.
8 Cylinder (400)	4 qt.
8 Cylinder (402)	4 qt.
8 Cylinder (454)	4 qt.
With filter change; add 1 qt. for 6 and 8 Cyl. engines.	

LUBRICATION

Crankcase oil should be selected to give the best performance under the climatic and driving conditions in the territory in which the vehicle is driven.

During warm or hot weather, an oil which will provide adequate lubrication under high operating temperatures is required.

During the colder months of the year, an oil which will permit easy starting at the lowest atmospheric temperature likely to be encountered, should be used.

When the crankcase is drained and refilled, the crankcase oil should be selected, not on the basis of the existing temperature at the time of the change, but on the lowest temperature anticipated for the period during which the oil is to be used.

Unless the crankcase oil is selected on the basis of viscosity or fluidity of the anticipated temperature, difficulty in starting will be experienced at each sudden drop in temperature.

SAE VISCOSITY OILS


SAE Viscosity Numbers indicate only the viscosity or

body of the oil, that is, whether an oil is a light or a heavy body oil, and do not consider or include other properties or quality factors.

The lower SAE Viscosity Numbers, such as SAE 5W and SAE 10W which represents the light body oils, are recommended for use during cold weather to provide easy starting and instant lubrication. The higher SAE Viscosity Numbers such as SAE 20 and SAE 30, which represents heavier body oils, are recommended for use during warm or hot weather to provide improved oil economy and adequate lubrication under high operating temperatures.

Oils are available which are designed to combine the easy starting characteristics of the lower SAE Viscosity Number with the warm weather operating characteristics of the higher SAE Viscosity Number. These are termed "multi-viscosity oils." SAE 5W-30, SAE 5W-20, SAE 10W-40W, and SAE 10W-30.

The following chart will serve as a guide in selecting the proper oil viscosity. In addition to providing proper lubrication, the correct viscosity helps assure good cold and hot starting by reducing friction and thus increasing cranking speed.



- SAE 5W-20 oil is not recommended for sustained high speed driving.
- SAE 30 oils may be used at temperatures above 40°F.

Types of Oils

In service, crankcase oils may form sludge and varnish and under some conditions, corrosive acids unless protected against oxidation.

To minimize the formation of these harmful products and to assure the use of oil best suited for present day operating conditions, automobile manufacturers have developed a series of sequence tests designed to evaluate the ability of any oil to properly lubricate automobile engines.

It is recommended that only those oils which are certified by their suppliers as meeting or exceeding the maximum severity requirements of these sequence tests (or GM Standard 6041-M) be used in Chevrolet engines. Certified sequence tested oils will be described as such on their containers.

MAINTAINING OIL LEVEL

The oil gauge rod is marked "Full" and "Add Oil." These notations have broad arrows pointing to the level lines. The oil level should be maintained between the two lines, neither going above the "Full" line nor under the "Add Oil" line. **DO NOT OVERFILL.** After operating vehicle allow a few minutes for oil to return to crankcase before checking oil level.

Check the oil level frequently and add oil when necessary.

ENGINE OIL CHANGE INTERVALS

NOTE: Under prolonged dusty driving conditions, it is recommended that these operations be performed more often.

To insure continuation of best performance, low maintenance cost and long engine life, it is necessary to change the crankcase oil whenever it becomes contaminated with harmful foreign materials. Under normal driving conditions draining the crankcase and refilling with fresh oil every 4 months or every 6000 miles whichever occurs first, is recommended. In certain types of service including trailer hauling, extensive idling, short trip operation at freezing temperatures (engine not thoroughly warmed-up), or in commercial use, such as taxicab, limousine or patrol car service, the oil change interval should not exceed 2 months or 3,000 miles, whichever occurs first.

It is always advisable to drain the crankcase only after the engine has become thoroughly warmed up or reached normal operating temperature. The benefit of draining is, to a large extent, lost if the crankcase is drained when the engine is cold, as some of the suspended foreign material will cling to the sides of the oil pan and will not drain out readily with the cold, slower moving oil.

CRANKCASE DILUTION

Probably the most serious phase of engine oil deterioration is that of crankcase dilution which is the thinning of the oil by fuel vapor leaking by pistons and rings and mixing with the oil and by condensation of water on the cylinder walls and crankcase.

Leakage of fuel, or fuel vapors, into the oil pan occurs mostly during the "warming up" period when the fuel is not thoroughly vaporized and burned. Water vapor enters the crankcase through normal engine ventilation and

through exhaust gas blow-by. When the engine is not completely warmed up, these vapors condense, combine with the condensed fuel and exhaust gases and form acid compounds in the crankcase.

As long as the gases and internal walls of the crankcase are hot enough to keep water vapor from condensing, no harm will result. However, when the engine is run in low temperatures moisture will collect and unite with the gases formed by combustion resulting in an acid formation. The acid thus formed is likely to cause serious etching or pitting which will manifest itself in excessively rapid wear on piston pins, camshaft bearings and other moving parts of the engine, oftentimes causing the owner to blame the car manufacturer or the lubricating oil when in reality the trouble may be traced back to the character of the fuel used, or a condition of the engine such as excessive blowby or improper carburetor adjustment.

Automatic Control Devices to Minimize Crankcase Dilution

All engines are equipped with automatic devices which aid greatly in minimizing the danger of crankcase dilution.

The thermostat, mounted in the cylinder head water outlet, restricts the flow of water to the radiator until a predetermined temperature is reached, thus minimizing the length of time required to reach efficient operating temperature, reducing the time that engine temperatures are conducive to vapor condensation.

A water by-pass is included in the cooling system, utilizing a hole in the front of the cylinder block. This allows a limited circulation of coolant, bypassing the thermostat until thermostat opening temperatures are reached. This system provides a uniform coolant temperature throughout the engine, eliminating localized hot-spots, improving exhaust valve life, provides fast warm-up of lubricating oil and fast temperature rise in the coolant which provides fast heater operation in cold weather.

A thermostatic heat control on the exhaust manifold during the warming up period, automatically directs the hot exhaust gases against the center of the intake manifold, greatly aids in proper vaporization of the fuel.

An automatic choke reduces the danger of raw or unvaporized fuel entering the combustion chamber and leaking into the oil reservoir.

An efficient crankcase ventilating system drives off fuel vapors and aids in the evaporation of the raw fuel and water which may find its way into the oil pan.

POSITIVE CRANKCASE VENTILATION VALVE

Every 24,000 miles or 24 months the valve should be replaced. Connecting hoses, fittings and flame arrestor should be cleaned. At every oil change the system should be tested for proper function and serviced, if necessary.

AIR INJECTION REACTOR SYSTEM (A.I.R.) CONTROLLED COMBUSTION SYSTEM (C.C.S.)

The Air Injection Reactor system should have the drive belt inspected for wear and tension every 12 months or 12,000 miles, whichever occurs first. In addition, complete effectiveness of either system, as well as full power and performance, depends upon idle speed, ignition timing, and idle fuel mixture being set

according to specification. A quality tune-up which includes these adjustments should be performed periodically to assure normal engine efficiency, operation and performance.

GM EVAPORATION CONTROL SYSTEM

Every 12 months or 12,000 miles (more often under dusty conditions) the filter in the base of the canister must be replaced and the canister inspected.

MANIFOLD HEAT CONTROL VALVE

Every 6,000 miles or 4 months, check valve for freedom of operation. If valve shaft is sticking, free it up with GM Manifold Heat Control Solvent or its equivalent.

OIL FILTER

Change engine oil filter at first engine oil change and every second oil change thereafter.

NOTE: For Vehicles in heavy duty operation involving continuous start-stop or prolonged idling, engine oil should be changed after 2500-3000 miles of operation. The filter should be changed after 5000-6000 miles of operation.

AIR CLEANER

NOTE: Under prolonged dusty driving conditions, it is recommended that these operations be performed more often.

Oil Wetted Paper Element Type—

First 12,000 miles inspect element for dust leaks, holes or other damage. Replace if necessary. If satisfactory, rotate element 180° from originally installed position. Replace at 24,000 miles. Element must not be washed, oiled, tapped or cleaned with an air hose.

Crankcase Ventilation Filter (Located Within Air Cleaner)

If so equipped, inspect at every oil change and replace if necessary. Replace at least every 24,000 miles; more often under dusty driving conditions.

FUEL FILTER

Replace filter element located in carburetor inlet every 12 months or 12,000 miles whichever occurs first, or, if an in-line filter is also used, every 24,000 miles.

Replace in-line filter every 24,000 miles.

DISTRIBUTOR

6-Cylinder Engine--Remove distributor cap and rotate lubricator 1/2 turn at 12,000 mile intervals. Replace at 24,000 mile intervals.

8-Cylinder Engine--Change cam lubricator end for end at 12,000 mile intervals. Replace at 24,000 mile intervals.

REAR AXLE AND 3-SPEED 4-SPEED TRANSMISSIONS

The passenger car operates under the most severe lubrication conditions at high speed and requires a hypoid lubricant which will meet this condition.

RECOMMENDED LUBRICANTS

Standard Rear Axles--SAE 80 or SAE 90 GL-5 Gear Lubricant.

Positraction Rear Axles--Use special Positraction lubricant.

CAUTION: Straight Mineral Oil gear lubricants must not be used in hypoid rear axles.

Manual transmissions--SAE 80 or SAE 90 GL-5 gear lubricant.

Lubricant Additions—Manual Transmission

The lubricant level in the transmission housing should be checked periodically. (Every 6,000 miles or 4 months)

It is recommended that any additions required to bring up the lubricant level be made using the same type lubricant already in the housing.

When checking lubricant level in transmission or rear axle the unit being checked should be at operating temperature. With unit at operating temperature the lubricant should be level with bottom of the filler plug hole. If the lubricant level is checked with the unit cold the lubricant level should be 1/2 inch below the filler plug hole.

Lubrication Additions—Rear Axle—Standard

Every 4 months or 6,000 miles, whichever occurs first: Check lubricant level, and add lubricant if necessary to fill to level of filler plug hole. Use SAE 80 or SAE 90 GL-5 Gear Lubricant.

Lubricant Changes

The rear axle lubricant does not require changing for the life of the vehicle. If additions are needed, or when refilling the axle after service procedures, use lubricants described above.

Transmission Shift Linkage (Manual and Automatic)

Every 6000 miles or 4 months lubricate shift linkage and on manual transmission floor controls lever contacting faces with water resistant EP chassis lubricant which meets GM Specification 6031M.

Clutch Cross—Shaft

Periodic lubrication of the clutch cross shaft is not required. At 36,000 miles or sooner, if necessary; remove plug, install lube fitting and apply EP CHASSIS LUBRICANT which meets GM Specification GM 6031M.

AUTOMATIC TRANSMISSIONS

NOTE: At first transmission fluid change, it is recommended that the Powerglide and Torque DRIVE low band be adjusted as specified in Section 7 of this manual.

Powerglide, Torque Drive, and Turbo Hydra-Matic 350

Every 6,000 miles or 4 months check fluid level on dipstick with engine idling, selector lever in neutral position, parking brake set and transmission at operating temperature. If fluid level is below full mark on dipstick, add small amount of automatic transmission fluid. Re-check fluid level and again add a small amount of fluid if needed to bring level to full mark. **DO NOT OVERFILL.**

General Motors DEXRON[®] Automatic Transmission Fluid, Part numbers 1050568, 69, 70 has been especially formulated and tested for use in the automatic transmission. Other Automatic Transmission Fluids identified with the mark DEXRON[®] are also recommended.

Every 24,000 miles (every 12,000 if vehicle is driven extensively in heavy city traffic during hot weather; or is in commercial use, such as a taxicab, limousine or patrol car service, where the engine idles for long periods or is used to pull a trailer) remove fluid from the transmission sump and, in Powerglide add 2 quarts* U.S. measure (1-2/3 quarts Imperial measure) of fresh fluid for Chevrolet and Chevelle; add one and a half (1-1/2) U.S. measure and (1-1/4 quarts Imperial measure) for Nova and Camaro (Powerglide and Torque Drive). Operate transmission through all ranges and check fluid level as described above. For Turbo Hydra-Matic 350, add 2.5 quarts U.S. measure (2.0 quarts Imperial measure).

It is not necessary to remove the pan because a drain plug is provided.

*Except if vehicle is equipped with transmission provided in heavy duty service options. If so equipped, drain converter and sump every 24,000 miles and add approximately 9 quarts U.S. Measure (7-1/2 quarts Imperial Measure) of fresh fluid for Chevrolet and Chevelle and 7-1/2 quarts U.S. Measure (6-1/4 quarts Imperial Measure) for Nova and Camaro.

Turbo Hydra-Matic 400

Lubrication for the Turbo Hydra-Matic 400 will, except for fluid capacity and filter change listed below, follow the recommendations above. After checking transmission fluid level it is important that the dipstick be pushed all the way into the fill tube.

Every 24,000 miles after removing fluid from the transmission sump, approximately 7-1/2 pints U.S. measure (3 pints Imperial measure) of fresh fluid will be required to return level to proper mark on the dipstick.

Every 24,000 miles the transmission sump filter should be replaced.

CHASSIS

CHASSIS LUBRICATION

For chassis lubrication, consult the lubrication chart. It shows the points to be lubricated and how often the lubricant should be applied.

The term "chassis lubricant" as used in this manual, describes a water resistant EP chassis lubricant which meets GM Specification GM 6031M designed for application by commercial pressure gun equipment.

FRONT WHEEL BEARINGS

It is necessary to remove the wheel and hub assembly to lubricate the bearings. The bearing assemblies should be cleaned before repacking with lubricant. Do not pack the hub between the inner and outer bearing assemblies or the hub caps, as this excessive lubrication results in the lubricant working out into the brake drums and linings.

Front wheels of all passenger car models are equipped with tapered roller bearings and should be packed every 24,000 miles with a high melting point water resistant front wheel bearing lubricant. On units equipped with disc brakes, use wheel bearing lubricant GM Part No. 1051195 or equivalent. This is a premium high melting point lubricant.

CAUTION: "Long fibre" or "viscous" type lubricant should not be used. Do not mix wheel bearing lubricants. Be sure to thoroughly clean bearings and hubs of all old lubricant before repacking.

The proper adjustment of front wheel bearings is one of the important service operations that has a definite bearing on safety. A car with improperly adjusted front wheel bearings lacks steering stability, has a tendency to wander or shimmy and may have increased tire wear. The adjustment of these bearings is very critical. The procedure is covered in Section 3 of this manual under Front Wheel Bearings--Adjust.

BRAKE MASTER CYLINDER

Check level every 6,000 miles or 4 months and maintain 1/4" below lowest edge of each filler opening with GM Hydraulic Brake Fluid Supreme No. 11 or equivalent.

PARKING BRAKE

Every 6,000 miles or 4 months, apply water resistant lubricant which meets GM Specification GM 6031M to parking brake cable, cable guides and at all operating links and levers.

STEERING GEAR

Manual

The steering gear is factory-filled with steering gear lubricant. Seasonal change of this lubricant should not be performed and the housing should not be drained - no lubrication is required for the life of the steering gear.

Every 36,000 miles, the gear should be inspected for seal leakage (actual solid grease - not just oily film). If a seal is replaced or the gear is overhauled, the gear housing should be refilled with #1051052 (13 oz. container) Steering Gear Lubricant which meets GM Specification GM 4673M, or its equivalent.

NOTE: Do not use EP Chassis Lube to lubricate the gear. **DO NOT OVER-FILL** the gear housing.

Power Steering Pump

On models equipped with power steering gear, check fluid every 6,000 miles or 4 months at operating temperature in pump reservoir. Add GM Power Steering Fluid, or, if this is not available, use DEXRON[®] Automatic Transmission Fluid to bring level to full mark on dip stick.

ELECTRICAL

BATTERY CARE (ENERGIZER)

Energizer--Check fluid level monthly utilizing the level indicator cap marked "Delco Eye". If the transparent eye within the cap glows, fluid level is low. Add only colorless, odorless drinking water or distilled water to bring level to split ring in filler opening.

DUAL ACTION SAFETY HOOD LATCHES

Every 4 months or 6,000 miles, whichever occurs first, lubricate hood latch assembly and hood hinge assembly as follows:

1. Wipe off any accumulation of dirt or contamination on latch parts.
2. Apply Lubriplate or equivalent to latch pilot bolts and latch locking plate.
3. Apply light engine oil to all pivot points in release mechanism, as well as primary and secondary latch mechanisms.
4. Lubricate hood hinges.
5. Make hood hinge and latch mechanism functional check to assure the assembly is working correctly.

AIR CONDITIONING

Every 6,000 miles or 4 months check sight glass under the hood, after the system has been in operation for several minutes. Sight glass should be clear but may, during milder weather, show traces of bubbles. Foam

or dirt indicate a leak which should be repaired immediately.

BODY LUBRICATION

See Body Service Manual for Body Lubrication. (Except Corvette)

BODY LUBRICATION POINTS (CORVETTE)

Lubricate the following items when possible.
Hood Latch Mechanism and Hinges--Apply light engine oil to pivot points. Don't oil lock pins or catch plates.

Rear Compartment Lid Release and Hinges--Apply light engine oil.

Side Door Hinge Pins--Apply light engine oil.

Door Lock Rotor and Strike Plate--Apply light engine oil or stainless stick lubricant.

Lock Cylinders -- Lubricate with powdered graphite.

Window Regulators and Controls and Door Lock Remote Link -- Apply light engine oil.

Gas Tank Filler Cap Hinge -- Apply light engine oil.

Weatherstrips and Rubber Bumpers -- Coat lightly with a rubber lubricant.




Fig. 11—Lubrication Diagram—19000 Series

1. Front Suspension
2. Steering Linkage
3. Steering Gear

4. Air Cleaner
5. Front Wheel Bearings

6. Transmission
7. Rear Axle
8. Oil Filter

9. Battery
10. Parking Brake
11. Brake Master Cylinder

SECTION 1B

CORVETTE BODY

INDEX

	Page		Page
General Description	1B-1	Spare Tire Mount	1B-24
Maintenance and Replacement	1B-1	Rear Plenum Drain	1B-25
Front End	1B-1	Rugs and Interior Trim	1B-26
Adjustments	1B-1	Cleaning Soft Trim	1B-26
Hood	1B-1	Carpets and Covers—All Models	1B-26
Hood Assembly	1B-2	Seats	1B-26
Hood Prop	1B-2	Body Mounting	1B-27
Front Emblem	1B-4	Body Repairs	1B-27
Fender Script	1B-4	General Instructions	1B-27
Fender Louver	1B-4	Repair Panels	1B-27
Cowl Area Trim	1B-5	Precautions	1B-27
Console Assembly	1B-5	Plastic Solder Kit	1B-29
Rear View Mirror	1B-7	Resin Kit	1B-31
Outside	1B-7	Specific Repairs	1B-33
Inside	1B-7	Scratched Panels, Spot Refinishing	1B-33
Sun Visor	1B-8	Dents in Panels—Surface Cracks	1B-33
Windshield	1B-8	Cracked Panels	1B-33
Cowl Ventilator Assembly	1B-10	Fractures	1B-37
Doors	1B-10	Panel Replacement	1B-37
Adjustments	1B-10	Hardtop	1B-37
Door Lock Striker	1B-10	Care and Storage	1B-37
Door Window	1B-11	Rear Window	1B-38
Hinges-Door Assembly	1B-12	Top Attachments	1B-38
Trim Panel and Inside Handles	1B-13	Headlining	1B-38
Door Lock and Remote Controls	1B-13	Weatherstrip and Drip Molding	1B-38
Weatherstrip	1B-13	Vinyl Covering	1B-38
Window Outer Seal Assembly	1B-13	Folding Top	1B-39
Window Anti-Rattle Assembly	1B-13	Care of Folding Top	1B-39
Window Glass	1B-15	Care of Rear Window	1B-39
Glass Run Channels	1B-15	Adjustments	1B-39
Window Regulator—Manual	1B-16	Top Assembly—Removal and	
Window Regulator—Power	1B-17	Installation	1B-41
Outer Handle and Lock Cylinder	1B-17	Top Trim and Rear Window Assembly	1B-41
Rear Quarter	1B-19	Frame and Linkage	1B-44
Door Sill Plate and Molding	1B-19	Weatherstrip	1B-44
Underbody Storage Compartment	1B-19	Sport Coupe Model 19437	1B-45
Rear End	1B-19	Roof Panels	1B-45
Folding Top Compartment Lid	1B-19	Adjustments	1B-45
Adjustments	1B-19	Weatherstrip	1B-45
Hinges	1B-19	Interior Quarter Trim	1B-46
Lock	1B-19	Center Roof Trim	1B-46
Control	1B-23	Storage Tray	1B-46
Gas Tank Door and Rear Trim	1B-23	Rear Window	1B-46
Rear Filler Panel	1B-24	Special Tools	1B-47

GENERAL DESCRIPTION

A structural network of steel makes up the frame of the Corvette body (See Figure 1). Combined with fiber glass reinforced plastic body panels, the steel plastic unit displays properties of increased torsional rigidity and greater beaming strength.

There are two body styles available—the regular convertible with a folding top or removable hardtop, and the new coupe series that features removable roof panels. On convertible model base equipment, either top is standard and both are optional.

MAINTENANCE AND REPLACEMENTS

FRONT END

ADJUSTMENTS

(Refer to Figure 3).

Adjustments should be made in order—hood position first, followed by catch adjustments.

Hood

The position of the hood in relation to the hood body opening and fender surfaces is determined by the position of the hinges and position and adjustment of catch and bumpers.

The fore and aft adjustment of the hood is performed by




Fig. 1—Steel Reinforcing Members

loosening the hinge retaining bolts (lower) and moving the hood to the limit of slotted holes in hinge strap.

The upper surface of hood may be brought flush with adjacent surfaces by shimming under hinges and adjusting bumper screw and catch bolt engagement. Figure 4 indicates specified spacing.

Entrance of catch bolt into the plate may be adjusted by loosening two (2) catch bolt mounting screws to allow movement of bolt assembly.

Synchronization of catch release may be made by adjusting the cable retainer located at left hand catch bolt assembly.

HOOD ASSEMBLY

Removal

1. If hood is to be reinstalled, scribe a line around hood hinge upper strap as shown in Figure 5.
2. With aid of helper to support hood, remove screws that retain hinge straps and support assembly to hood. If hinges are removed from vehicle, note number of shims under each hinge.

Installation

In replacing original hood, align hinge with scribe marks made on removal, and install retaining screws removed from hinges and support.

If adjustment is required, proceed as outlined in this section under Adjustments—Hood—Hood Catch.

HOOD PROP

Retention Feature

When extended under hood service operations are anticipated, the hood, prop track and slide should be secured by placing a 1/4 inch bolt and nut through the existing hole. This will prevent accidental closing of the hood.




Fig. 2—Fender Side Louver




Fig. 3—Hood Hinge and Catch




Fig. 4—Hood Spacing



Fig. 5—Scribing Line Around Hood Hinge

FRONT EMBLEM

Front emblem including flags, numbers, and molding inserts, are retained by special nuts which may be reached by raising hood.

FENDER SCRIPT

Above the front fender louvers the script "Stingray" will be fastened with adhesive.

Front Fender Side Louver— Replacement (Fig. 2)

1. Reach up beneath the front fender lower edge and remove a locknut threaded on a stud fastened to the bottom of the louver.
2. From the outside, remove (2) screws driven through the upper edge of the louver.
3. Gently lift the louver up and off the fender.
4. Reverse Steps 1-3 for installation.




Fig. 6—Cowl Area Trim

1. Instrument Panel Pad L.H.
2. Side Trim Panel L.H.

3. Side Trim Panel R.H.
4. Dash Panel Pad R.H.

5. "J" Nut
6. Screw

7. Special Washer
8. Cover—A/C Convert

COWL AREA TRIM

Figure 6 illustrates the mounting and location of instrument panel pads and side trim panels.

Removal

The right-hand dash pad, instrument panel pad and assemblies are removed by:

1. Remove two mounting screws on the outboard flange.
2. Remove two screws at inner flange of center cluster panel.
3. Pull pad outward to release special plastic retaining clips along top of panel.
4. Pull pad upward to release spring clip at top of trim side panel.

Cowl ventilator and kick panel is removed by:

1. Loosen four (4) screws securing sill plate enough to release force on kick panel.
 2. Remove one (1) screw at center of kick panel.
 3. Lift out panel with a force in the rearward direction.
 4. For installation, follow above steps in reverse order.
- Side trim panels (left and right) can now be lifted out by pulling downward to release spring clip at front console assembly, after removing screw.

Console Assembly

(Refer to Figure 7)

Because of overlap design, it is necessary that the rear




Fig. 7—Front and Rear Console Assemblies

console assembly be first removed or sufficiently loosened before the front console assembly can be removed. Steps for removing the console assemblies are in the following sequence:

1. Disconnect battery ground cable.
2. Open storage compartment, glove box, and battery lids.
 - a. Remove storage compartment interior.
 - b. Remove lid hinge screws (total of nine, three (3) per lid).
 - c. Remove eight (8) screws on periphery of compartment lid trim plate.
 - d. Remove trim plate, lids and glove compartment interior as an assembly.
3. Remove bolt at rear portion of console. Access bolt through opening created in step 2. Remove four (4) screws (two (2) per side) on side of rear portion of console.
4. Lift console. Disconnect electric window switch connectors. Continue raising console while moving it rearward to allow parking brake handle seal to slide out of slot. Remove rear portion of console from vehicle.
5. Service parking brake mechanism as outlined in Section 5 of this Manual or replace concerned power window switch(s).
6. Having first disassembled heater and side vent controls, shift knob assembly, boot assembly, and trim plate, remove front console assembly by carefully pulling rearward and upward (fig. 8).




Fig. 8—Front Console Assembly




Fig. 9—Under Dash Braces - Convertible with A/C




Fig. 10—Under Dash Braces - Convertible w/o A/C

7. Reverse steps 1-6 on installation, making sure seal is properly installed in its slot before finalizing the installation.

Tension of mirror stud is increased by tightening adjusting screw.

Under Dash Brace Rods (Figs. 9, 10)

Convertible style bodies have added reinforcements beneath the dash: one or two on the right and three on the left side. The brace rods are bolted into place from the cowl area towards the center of the vehicle.

If the heater core or radio are to be removed, the right-hand under dash braces may be removed first.

REAR VIEW MIRROR

Outside

Removal

The outside rear view mirror is removed from the door by removing the allen head set screw located on the outboard side of the mirror support. (See Figure 9). Mounting assembly is removed by removing two screws to body (fig. 11).

Installation

Mirror may be installed by following removal procedures in reverse order.

Inside

Installation of inside mirror is illustrated in Figure 12.




Fig. 11—Outside Rearview Mirror




Fig. 12—Sun Visor and Inside Rearview Mirror

SUN VISOR

Attachment of sun visor assembly to windshield header is made as shown in Figure 12. Turning of adjusting screw clockwise increases friction.

WINDSHIELD (Figs. 12 to 16)

The windshield installation incorporates a synthetic self-curing rubber adhesive caulking compound that adheres to both glass and pinchweld frame in place of the rubber channel that was formerly used. Applied to the glass while in a soft state, the material begins to cure soon after exposure to air. It is therefore essential that installation of glass into body opening quickly follow application of material to glass. It is recommended to use the materials provided in a kit from your authorized dealer which consists of:

- a. One tube of Adhesive Caulking Material.
- b. Pressure Sensitive Adhesive Sealing Strip.
- c. Steel Music Wire (.020" diameter).
- d. Adhesive Caulking Primer.

Additional materials required:

- a. Caulking gun
- b. Two pieces of wood for wire handles.
- c. Black weatherstrip adhesive.
- d. Rubber glass spacers.

Removal

1. Set windshield wiper access door in open position.
2. Remove windshield wiper arms.
3. Remove weatherstrips (L and R) from frame by removing mounting screw, prying from channel, and carefully pulling downward.
4. Remove lower corner reveal moldings (L and R) by removing two (2) screws located at end flanges to fender, and carefully prying out from retaining clips.
5. Remove side retainer moldings (L and R) by removing three (3) screws to frame.
6. Remove side reveal molding (L and R) by removing one (1) remaining screw.
7. After indexing molding and header rail with tape to insure proper reinstallation, remove upper reveal molding by carefully prying out at corner with screw driver and then pulling out remainder by hand.
8. Secure one end of steel music wire to piece of wood for handle. Insert other end through caulking material at lower corner of windshield; then secure end of wire to another piece of wood (fig. 12).
9. With the aid of helper, carefully cut through caulking material (using a sawing motion) with the steel wire; up side of windshield, across top, down opposite side, and across bottom.
10. Remove old glass from windshield opening.
11. Using a sharp scraper or wood chisel, remove adhesive caulking material from pinchweld flange.

NOTE: It is not necessary to clean off all the old caulking material completely from windshield frame; however, there should not be any loose pieces of caulking material left in the opening.

12. Check all upper reveal molding retaining clips for damage (4 clip assemblies required). Replace those that are bent or distorted.
13. Using weatherstrip adhesive, cement rubber spacers at bottom, sides, and top of window opening. The step-type spacers are used at bottom, the flat type are used at the top, and at the sides, window opening.
14. Using suction cup holders, position replacement glass in body opening. Carefully check relationship of glass to body pinchweld completely around opening. The overlap of glass to body pinchweld and retaining flanges should be equal with a minimum overlap of 3/16". Where necessary, position shims under the lower spacers to obtain required overlap of glass to body upper and lower flanges.
15. After proper glass to pinchweld relationship has been attained, mark position with grease pencil on glass and windshield pillar.
16. Remove glass from body opening and place on protected surface.
17. Clean inside edge surface of glass so that glass is free of any foreign material (oil, grease, etc.). By first peeling off paper backing, apply pressure sensitive sealing strip approximately 1/4 inch from edge of inside surface of glass completely around glass. Then apply a film of silane primer to inside edge surface completely around glass; also apply silane primer to sealing surface of windshield frame.
18. Cut off painted portion of cartridge nozzle along edge of paint line.
19. Mix adhesive caulking material and accelerator thoroughly according to directions on container.

NOTE: Once caulking material is mixed, there will be approximately 35 minutes of working time with the material. Subsequent steps should be performed immediately after caulking material is mixed.

20. Place caulking material in cartridge.
21. Carefully apply a smooth continuous bead of caulking material on inside surface of glass next to edge completely around glass. Caulking material should be approximately 1/4 inch wide at the base and form a pyramid 3/8 inch high. If during application the pyramid collapses, wait about 2-3 minutes




Fig. 13—Windshield Moldings and Weatherstrips




Fig. 14—Removing Old Glass From Opening

for material to set up. If an air bubble is encountered in material, back up the applicator and apply sufficient material to fill void and to dispense the bubble before continuing.

22. The reveal molding clips are self-sealing and do not require sealing before installing glass.
23. With aid of helper, lift glass and carefully position glass on spacers, matching up marks on glass and frame.
24. Press glass lightly to set caulking material to windshield opening flanges. Paddle material where necessary to insure proper seal.
25. Water test windshield immediately using a cold water spray. If any water leaks are encountered, use flat bladed screw driver or stick, and paddle caulking material into leak point to correct leak. Correction of leak is usually more effectively performed by paddling material from inside the body.

CAUTION: Do not run a heavy stream of water directly on caulking material while the material is still soft.

26. Install previously removed hardware and trim in the following order: upper reveal molding, side reveal molding, side retainer molding, lower corner reveal molding, and windshield pillar weatherstrip.




Fig. 15—Windshield Rubber Spacers




Fig. 16—Applying Caulking Material to Glass

COWL VENTILATOR ASSEMBLY

The following procedure includes either the left or right-hand side. Refer to Figure 17.

Adjustment

Turn plastic adjustment link, located at middle of control cable underneath dash panel, in order to attain




Fig. 17—Cowl Ventilator and Controls




Fig. 18—Non-Adjustable Wedge Pin - Convertible Side Door

desired adjustment. Ventilator valve should be completely closed when knob is at forward position.

Removal

1. Remove cowi kick panel.
2. Disengage control cable fastened to bracket by screw.
3. Remove knob assembly retaining screw.
4. With console trim plate lifted out, remove nut retaining guide.
5. Remove screw retaining cable at inside front of console assembly.
6. Disassemble control mechanism.
7. Remove cable assembly by disconnecting at adjusting link and pulling through.

Installation

Install vent assembly following removal procedure in reverse order. Check operation and adjust accordingly.




Fig. 19—Door Wedge Pin Housing and Bracket Location

DOORS

ADJUSTMENTS

Door Lock Striker (Fig. 20)

The door lock striker consists of a single metal bolt and washer assembly that is threaded into a tapped, floating cage plate located in the body lock pillar. With this design, the door is secured in the closed position when the door lock fork-bolt snaps over and engages the striker bolt.

1. To adjust striker up or down, or in or out, loosen striker bolt and shift striker as required, and then tighten striker.
2. To determine if striker fore or aft adjustment is required, proceed as follows:
 - a. Make certain door is properly aligned.
 - b. Apply modeling clay or body caulking compound to lock bolt opening.
 - c. Close door only as far as necessary for striker bolt to form an impression.

CAUTION: Do not close door completely. Complete door closing will make clay removal very difficult.

- d. Measure striker impression as follows:
Striker head should be centered fore and aft as shown; however, some tolerances are allowed. In this alignment, it is important that minimum dimensions as outlined in Figure 20 be strictly maintained. The following spacers are available as service parts and can be used individually or in combination to achieve the specified alignment:
5/64" Spacer
5/32" Spacer
1/4" Spacer
5/16" Spacer




Fig. 20—Checking Adjustment of Striker

If check indicates need for emergency spacers, proceed as follows:

1. Mark position of striker on body lock pillar using a pencil.
2. Insert J-23457 wrench into head of striker bolt and remove striker.
3. To install, reverse removal procedure. Make certain striker is positioned within pencil mark.

IMPORTANT: Whenever a door has been removed and reinstalled or realigned, the door should not be closed completely until a visual check is made to determine if lock fork-bolt is correctly engaging with striker.

Convertible Side Door Wedge Pin Housing And Bracket Adjustment

The wedge shaped tapered pin located on the side door (fig. 18) is not adjustable nor interchangeable right to left door.

All adjustments for entry of the wedge pin into the housing are made at the housing and housing bracket.

The housing bracket mounted in the quarter panel and lock pillar has six (6) mounting bolts allowing for alignment up and down (fig. 19).

The housing is secured with three (3) bolts to the housing bracket. The housing is adjustable on the horizontal plane in and out, back and forth.

All bracket and housing bolts should be just snug before closing door gently. Tighten all nine (9) bolts before opening door.

Try closing door after housing and housing bracket bolts are tightened to 70 inch pounds torque.

NOTE: No shims are to be used at tapered wedge pin, bracket, or bracket housing.

DOOR WINDOW ADJUSTMENT (Fig. 21)

In order to perform any of the adjustments listed below, the door trim panel must be removed.

Window Tilted

1. Loosen two bolts (A) and adjust by rotating glass until a constant distance is gained between front edge of glass and the windshield pillar. Retighten bolts A.

Window Rolls Up Too Far

2. Loosen front and rear stop screws (B). Roll glass up until it properly seats in roof weather strip. Move front and rear stops until they contact window rollers. Retighten screws (B).

Gap Between Window Forward Edge and Windshield Pillar Too Large or Small

3. Loosen three bolts (C). Move glass towards windshield pillar weather strip until it properly seats in the stripping. Retighten bolts (C).

Glass Too Far Outboard or Inboard

4. Loosen bolts (D & E). Back off adjusting screws (G). Move top edge of glass inboard until it is properly




Fig. 21—Door Glass Adjustments

seated against roof rail weatherstrip. Tighten bolts (D). Move felt weatherstrip against window. Tighten bolts E. Turn adjusting screws so that the inner nylon pads are in light contact with wedges.

Window Rolls Down Too Far

- Loosen screw (H) and roll glass down until top edge is flush with outer panel. Move stop to contact window roller. Retighten screw (H).

If a complete door window adjustment is needed, fully adjust window by following all the steps given above in the order given.

Door Hinges

(Refer to Figure 22)

The position of the door assembly in the body opening is determined by the striker position previously described, and the position of the door on the hinge rear straps. The position of the door is adjusted by sliding the door fore and aft to the limit of the slotted holes in hinge pillar; in and out adjustment is done by installation and removal of shims located between hinge pillar and front straps of hinges; up and down position is determined by adjustment of rear hinge straps in slots of inner door panel. To adjust door, proceed as follows:

- Remove door trim panel as outlined in this section.
- Remove lock striker bolt after first scribing line on lock pillar surface following circular flange. This enables proper installation position.
- For up-and-down adjustment, remove hinge cover (2 screws) for access to upper hinge retaining screws.
- For in-and-out, and fore-and-aft adjustment, it is necessary to first remove instrument panel (left door only), right dash pad (right door), cowl kick panel, air inlet duct, and radio speaker, in order to gain access to hinge retaining screws.
- Adjust door as required. (Do not allow doors to hang on one hinge without support.)
- Install previously removed striker assembly, trim pads and panels and lubricate door hinges with lubricate or equivalent.

NOTE: After performing any door adjustment,

the window and lock pillar should be checked for alignment and adjusted as necessary. Do not slam door after adjustment without first checking the door lock and striker engagement. An adjustment may be necessary.

TRIM PANEL AND INSIDE HANDLES (Figs. 23 to 25)

- Using Tool J-7797, remove clips retaining window crank and lock control.
- Remove four (4) screws securing trim panel located at inside corners of inner door panels.
- Remove trim panel by carefully prying out at plastic fastener clips located around perimeter of panel.
- Remove door lock handle by removing one (1) screw and sliding handle forward.
- Remove formed plastic cover by peeling along edge at adhesive bead.
- For installation follow above steps in reverse order making sure trim panel is properly aligned.

DOOR LOCK AND REMOTE CONTROLS (Fig. 24)

Removal

- Raise window fully up.
- Remove door trim panel as outlined in this section.
- Disengage upper control rod assembly by releasing carburetor type clips at both ends, and removing rod through access hole.
- Disengage lock control rods by releasing clips at both ends and lifting outward.
- Remove remote control assembly by removing four (4) screws to inner door panel.
- Remove "crank link" (intermediate pivot) by removing two (2) screws to inner panel.
- Remove door lock by removing three (3) screws and lifting assembly out through access hole.

Installation

For installation, follow preceding steps in reverse order. After assembly of lock mechanism, adjust linkage for proper operation, by removing clip and turning threaded rods. All components should be lubricated before installation.




Fig. 22—Side Door Hinges




Fig. 23—Door Trim Panel Assembly




Fig. 24—Removing Window Crank with J-7797

WEATHERSTRIP (Fig. 26)

When installing new weatherstrip, all dirt, loose paint and old cement must be removed to ensure a good bond. Use only high quality cement designated by the manufacturer as being suitable for weatherstrip application.

WINDOW OUTER SEAL ASSEMBLY (Fig. 27)

1. Lower window all the way down.
2. Remove trim panel.
3. Remove two (2) screws one located at each end of seal.
4. Carefully pry out of six (6) retaining clips.
5. Lift seal assembly outward and upward.
6. For installation, secure clips and install the two screws, then install trim panel and handles.

WINDOW ANTI-RATTLE (Fig. 27)

1. Lower window
2. Remove trim panel
3. Remove hex head screw
4. Fish anti rattle through access
5. Install anti-rattle through access. Adjust, install trim.

WINDOW GLASS**Removal**

1. Remove door trim panel as outlined in this section.
2. Remove window outer seal assembly as outlined in this section.




Fig. 25—Door Lock and Remote Control




Fig. 26—Door Weatherstrip

- 1. Weatherstrip
- 2. Screw

- 3. Screw
- 4. Spacer

- 5. Striker
- 6. Lock Pillar

3. Position window all the way up to line up two (2) sash screws through access holes.
4. Remove two (2) sash screws on horizontal guide channel while holding nut with other hand (fig. 24).
5. Disengage stop by removing one (1) Phillips head screw at top of channel assembly.
6. Adjust front and rear channel assemblies to extreme outboard position to allow ample clearance for window removal.
7. Carefully pull window upward making certain to clear roller assemblies through opening in inner door panel.

Installation

If replacement glass is necessary, disassemble two (2) pads and fasteners, and frame assembly by removing three (3) mounting bolts through glass (fig. 25). Mount frame assembly and pads onto new glass before installation into door.

The following steps are necessary for installation:

1. Insert glass in door pocket with convex curvature towards outside of vehicle.
2. Install and tighten (2) sash bolt and nut assemblies through horizontal guide channel and glass frame.
3. Adjust front and rear channels to proper in and out position.
4. Install inner window seal, and door trim panel.

GLASS RUN CHANNELS (Fig. 30)

Removal

Removal of either front or rear channel involves the following steps.

1. Remove door trim assembly as outlined in this section.
2. Remove window glass assembly as outlined in this section.
3. Remove retaining screw at lower end of channel and two (2) screws retaining channel to top surface of door inner panel.
4. Remove two (2) screws retaining stationary horizontal guide channel.
5. Remove nut from adjusting stud.
6. Adjust stud to extreme clockwise position to allow proper removal clearance.
7. Carefully lift channel through upper slot as shown in Figure 31 making certain to clear opening.

Installation

1. Position run channel in door and install retaining bolts loosely.
2. Install window glass as outlined in this section.
3. Make necessary adjustments to channel as outlined under Doors - Adjustments - Door Windows. Replace door trim panel.




Fig. 27—Window Glass Seals and Molding

WINDOW REGULATOR—MANUAL (Fig. 32)**Removal**

1. Remove trim panel as outlined in this section.
2. Position window all the way up.
3. Remove two (2) sash bolt and nut assemblies retaining window glass.
4. Remove two (2) screws securing stationary horizontal channel.
5. Remove window crank housing by removing three (3) screws.
6. Remove crank shaft, pin and washer spring.
7. Remove two (2) screws located adjacent to spring opening retaining regulator.
8. Remove lower bolt securing front glass channel.
9. Remove nut securing adjusting stud, and adjust front channel outward to provide adequate clearance for window regulator removal.
10. Collapse regulator linkage to elongated position.
11. While depressing front channel outward, slide regulator assembly forward and rearward to remove through access hole as shown in Figure 33.

Installation

Regulator may be installed by following removal pro-



Fig. 28—Removing Sash Screws




Fig. 29— Glass and Frame Assembly

- | | | | |
|--------------------|------------|--------------------|--------------|
| 1. Glass | 4. Nut | 7. Washer | 10. Washer |
| 2. Channel | 5. Nut | 8. Bolt | 11. Fastener |
| 3. Roller Assembly | 6. Bushing | 9. Roller Assembly | 12. Cap |

cedure in reverse order. Always lubricate all guide rails and rollers when regulator is disassembled. Test regulator thoroughly before installing door trim panel. Adjust window as outlined in this section.

WINDOW REGULATOR—POWER

In the case that window will not operate, check electrical connections first. Figure 34 illustrates location of junctions, switches, and circuit breaker.

Removal

Perform Steps 1 through 12 following Window Regulator—Manual Removal. Note that electrical connectors must be removed from motor before performing any operation on regulator. Figure 34 illustrates location of regulator on door and wiring.

Disassembly

NOTE: Do not attempt to remove motor from regulator until the following operations are performed. Arm is spring-loaded and should be locked in position when motor is removed. Refer to Figure 35.

1. Place regulator assembly in vise.
2. Using jumper leads to 12 volt DC source, operate

- motor until semi-circular hole in sector gear centers over one of two weld nuts on mounting plate.
3. Screw a 1/4" - 20 x 1" bolt into weld nut so that end passes through hole in sector gear. It may be necessary to enlarge hole in gear slightly with file or drill. Install nut on bolt to lock arm position.

Installation

Be sure lock bolt is removed if regulator has been disassembled.

1. Install lubricated regulator assembly and guide rails in reverse order of removal.
2. Install window as outlined in this section.
3. Making sure connectors are securely installed on motor, test operation of window thoroughly.
4. Install door trim panel and control handles as outlined in this section.

OUTER HANDLE AND LOCK CYLINDER (Fig. 36)

Removal

1. Remove trim pad.
2. Remove lock water shield.
3. Remove handle assembly by first removing (3) three screws retaining lock.
4. Remove (2) nuts attached to handle assembly studs and raise handle assembly after prying pivot link clip loose.




Fig. 30—Window Run Adjustment Points

5. Remove lock cylinder by repeating step (2) above then removing 2 clips on rear of cylinder.

Installation

1. If required, install new lock cylinder seal with assembly replacement.
2. Position handle assembly and tighten retaining nuts.
3. Slide lock back into place and secure with (3) three screws.
4. Carefully check operation of door lock, handle and cylinder.
5. Install lock water shield, using foam pressure tape as seal.
6. Install door trim panel as outlined in this section.

HINGES—DOOR ASSEMBLY (Fig. 37)

Removal

1. Remove door trim panel as outlined in this section.
2. Remove hinge access cover from door inner panel.
3. For lower hinge removal, remove door sill plate, cowl kick panel, and radio speaker.
4. For access to upper hinge attaching screws, remove lower mast jacket cover and instrument panel pad (left side), or dash panel pad (right side), and air inlet ducts.
5. If entire door is to be removed and door has electric power window, disconnect and remove wiring between hinge pillar and door.
6. If hinge is to be replaced in same position, scribe around inner strap on door panel and record number of shims found between hinge strap and door panel.
7. Remove bolts retaining hinge to door. DO NOT




Fig. 31—Removing Front Glass Channel

ALLOW DOOR TO HANG UNSUPPORTED ON ONE HINGE.

8. Remove bolts retaining hinge to body.

Installation

1. If door assembly has been removed from car, scribe around lock striker as explained under Adjustments—Door Lock Striker, and remove striker from lock pillar.
2. Install hinges, replacing same number of shims removed, and aligning door hinge straps with marks scribed at disassembly.
3. As necessary, perform door adjustments as outlined in this section.
4. If door is equipped with power window, reinstall wiring.
5. Replace all trim and panels removed during disassembly.

REAR QUARTER

DOOR SILL PLATE AND MOLDING

Figure 38 illustrates assembly details of both the door sill plate and molding. The sill plate, which retains the carpet, the cowl trim kick panel, and lock pillar front edge trim, is mounted to the body by four (4) screws.

The upper molding is replaced by removing seven (7) screws; the lower molding is replaced by first removing the upper molding and then removing five (5) screws and four (4) nuts at face of molding.

UNDERBODY STORAGE COMPARTMENT

Located directly behind the front seats, the underbody storage compartment assembly is divided into three separate storage areas.

Refer to Figure 39.




Fig. 32—Manual Window Regulator

- | | | | |
|---------------------|------------|------------------|--------|
| 1. Regulator | 3. Screw | 5. Washer-Spring | 7. Pin |
| 2. Channel Assembly | 4. Housing | 6. Shaft | |

1. Remove right hand box by opening lid, and lifting box upward.
2. Unfasten storage assembly by removing eight (8) screws along inner flange of frame and lower strap of door hinges.
3. Remove assembly from underbody by lifting upward.
4. Doors are removed from assembly by removing three (3) screws (outer doors) and two (2) screws (center door) at upper hinge strap.
5. Center storage compartment box is removed by removing seven (7) screws located around inside top edge of box.
6. For installation, follow above steps in reverse order.

REAR END

FOLDING TOP COMPARTMENT LID (Fig. 40)

Adjustment

Hinges

The folding top compartment lid should be adjusted so

that, in the closed position, the surface of the lid is flush with surrounding body surfaces, and space between lid edge and body is 1/16" to 3/16" at sides and 3/16" to 1/4" at rear. Whenever lid position is changed on hinges, lock engagement must be inspected and adjusted if necessary. Adjust hinge position as follows:

1. Scribe a line on lid surface following contour of hinge strap. This line will assist in observation of lid movement during adjustment (fig. 41).
2. To raise or lower top surface of lid, add or remove hinge shims as required.

Lock

Lock engagement is adjusted as follows:

1. Lock striker is adjusted in and out to the extent of slotted mounting holes.
2. Release of lock is adjusted by loosening lock assembly retaining bolts and moving lock fore and aft to the limit of slotted holes in lock base.
3. After adjustment, lock release should be tested and readjusted as required.




Fig. 33—Removing Window Regulator

Closing (Fig. 40)

1. Adjust screw and bumper in place to full down position.
2. Close lid assembly allowing pin to engage in bushing and locate housing.
3. Tighten nuts to 70 lbs. inch torque.
4. Adjust screw up until the bumper is firmly seated against the lower surface of the lid assembly.

Hinges**Removal**

1. Scribe around hinge as shown in Figure 41.
2. Hinge is removed as an assembly by opening top compartment lid fully, and removing three (3) retaining screws. Note number of shims found between hinge frame and compartment floor.
3. Remove spring from hinge assembly by closing top compartment lid as far as possible and inserting Tool J-9550 between expanded coils in spring. Opening top compartment lid fully allows removal of spring as shown in Figure 42.
4. Directly after spring is removed, insert long bolt supplied with J-9559 through holes in end of tool through the spring, and install nut on bolt.

Spring may be removed from J-9559 or J-9559 may be installed in a new spring, by the following method:

1. Place a closed 6 or 8 inch "C" clamp in vise or fasten it to a bench top anchored to floor.
2. Hook one end of spring in clamp and the other end in hook of chain hoist, or "cheery picker", as shown in Figure 43.
3. Elongate the spring enough to allow insertion of J-9559. Install through bolt if spring is not to be installed on hinge immediately.

Installation

1. Install same number of shims as removed or, if repairing collision damage, etc., position hinge in

compartment. install upper mounting screws, fill gap between floor and hinge frame with shims and install lower mounting screw.

2. If spring has been removed from hinge, install spring in J-9559 and place spring on hinge with compartment lid raised: closing lid releases J-9559 for removal. Upper end of spring should rest in the one of three notches yielding best lid operation. Approximately three pounds force is necessary to close lid.

Top Lock

1. For locks on either side, remove rod mounting clamps by removing one (1) hex screw.
2. Remove two (2) nut-washer assemblies.
3. After disassembling lock from mounting studs, carefully remove cover and gasket from compartment lid.
4. For installation, follow above steps in reverse order. Test lock and control mechanism for proper operation.

Lock**Removal**

1. Remove rod mounting clamps. Remove retainer from control rod assembly and disengage rod from control.
2. Scribe a mark on lid along outer contour of lock assembly.
3. Remove three (3) lock assembly retaining screws and remove lock from compartment lid.

Installation

1. Place lock assembly on compartment lid aligned with scribed line and install retaining screws.
2. Install end of rod in control assembly and fasten retainer securely.
3. Test operation of lock thoroughly, and adjust if necessary as outlined in this section.

Control**Removal**

1. Remove inner mounting clamps from both cables, and disengage rods from control by removing retainers.
2. Remove four (4) mounting screws and remove control from compartment lid.

Installation

1. Position control on compartment lid and install mounting screws.
2. Install ends of rods in control and fasten securely with retainers.
3. Engage push rod with retainer.
4. Test operation of locks and adjust if necessary.

GAS TANK DOOR AND REAR TRIM

Figure 44 illustrates installation details of gas tank door, letter trim, and tail pipe bezel.

Gas tank door assembly and bezel are replaced by removing sheet metal screws located around inner surface of bezel.

Trim letters are retained by special nuts accessible from underneath vehicle.

REAR FILLER PANEL (Fig. 44)

1. Remove rear license plate and housing.
2. Remove tail pipe extensions from mufflers.
3. Remove eight (8) mounting screws retaining filler panel to body and slide panel down.
4. For installation, follow above steps in reverse order.




Fig. 34—Power Window Regulator Wiring




Fig. 35—Locking Arm in Place

SPARE TIRE MOUNT (Fig. 45)**Removal**

1. Remove spare tire as outlined in Owner's Manual.
2. Loosen pivot bolt lock nuts and turn pivot bolts out of weld nuts in crossmember.
3. Remove two (2) screws retaining swivel bolts assembly to body.
4. Remove four bolts holding cover assembly to body.




Fig. 36—Door handle and Lock Cylinder




Fig. 37—Side Door Hinges

Installation

Installation is made by following removal procedure in reverse order. Before installation swivel bolt assembly, coat nut and bolt threads with chassis grease.

REAR PLENUM DRAIN (Fig. 46)

The coupe rear plenum drain assembly is located in the left rear quarter of the vehicle. The exterior mounted drain shield is located in the left rear wheelhouse.

Replacement of Drain Hose

1. Remove interior quarter trim panel as outlined further in this section.
2. Loosen clamp on drain hose.
3. Remove and replace drain hose.
4. Install clamp on hose at rear plenum.
5. Reinstall quarter trim panel in the reverse order of removal.

RUGS AND INTERIOR TRIM**CLEANING SOFT TRIM****Procedure for Cleaning Folding Top Material**

The top should be washed frequently with neutral soap suds, lukewarm water and a brush with soft bristles. Rinse top with sufficient quantities of clear water to remove all traces of soap.




Fig. 38—Sill Plate and Trim Molding




Fig. 39—Under Body Storage Compartment

- | | | | | | | |
|-------------------------------|-------------|-------------------------------|-------------|-----------|----------|------------------------|
| 1. Cylinder and Case Assembly | 4. Retainer | 8. Cylinder and Case Assembly | 11. Bumper | 15. Hinge | 19. Door | 22. Center Compartment |
| 2. Escutcheon | 5. Screw | 9. Center Door | 12. Striker | 16. Hinge | 20. Seal | 23. Spring Nut |
| 3. Door | 6. Bumper | | 13. Rivet | 17. Screw | 21. Nut | 24. Lens Assembly |
| | 7. Cover | | 14. Striker | 18. Rivet | | 25. Shield |




Fig. 40—Folding Top Lid Assembly

1. Lid Assembly
2. Cable
3. Lock Assembly
4. Grommer
5. Shim
6. Clamp
7. Screw

8. Stop
9. Control Assembly
10. Pin
11. Pin Housing Assembly
12. Clip
13. Rod

14. Rod
15. Weatherstrip
16. Spacer
17. Bumper
18. Hinge Assembly

19. Spacer
20. Body Upper Panel
21. Screw—Lock Washer Assembly
22. Spring
23. Top Lock

If the top requires additional cleaning after using soap and water, a mild foaming cleanser can be used. Rinse the whole top with water; then apply a mild foaming type cleanser on an area of approximately two square feet. Scrub area with a small soft bristle hand brush, adding water as necessary until the cleaner foams to a soapy consistency. Remove the first accumulated soilage with a cloth or sponge before it can be ground into the top material. Apply additional cleanser to the area and scrub until the top is clean. Care must be exercised to keep the cleanser from running on body finish as it may cause streaks if allowed to run down and dry.

Procedure for Cleaning Coated Fabrics

Care of genuine leather and coated fabrics (includes

vinyl coated formed headlining) is a relatively simple but important matter. The surface should be wiped occasionally with a dry cloth, and whenever dirt accumulates, the following cleaning instructions should be used:

1. Lukewarm water and a neutral soap should be used. Apply a thick suds, worked up on a piece of gauze or cheesecloth, to the surface.
2. The operation should be repeated, using only a damp cloth and no soap.
3. The surface should then be wiped dry with a soft cloth.

Polishes and cleaners used for auto body finishes, volatile cleaners, furniture polishes, oils, varnishes or household cleaning and bleaching agents should never be used.



Fig. 41—Marking Hinge Position

Procedure for Cleaning Carpet

Thoroughly brush or vacuum the floor carpet. In many instances the floor carpet may require no further cleaning. If the carpet is extremely soiled remove carpet from car and thoroughly vacuum to remove loose dirt; then with a foaming type upholstery cleaner, clean ap-



Fig. 42—Removing Hinge Spring




Fig. 43—Installing Tool J-9559 in New Spring

proximately one (1) square foot of carpet at a time. After each area is cleaned, remove as much of the cleaner as possible with a vacuum cleaner. After cleaning the carpet use an air hose to "fluff" the carpet pile, then dry the carpet. After the carpet is completely dried, use an air hose to again fluff the carpet pile.

NOTE: If the carpet is not extremely soiled, it may be cleaned in the car by applying a small




Fig. 44—Gas Tank Door and Rear Trim




Fig. 45—Spare Tire Mount

1. Cover
2. Strap Assembly
3. Strap Assembly Pivot Bolt

4. Swivel Bolt Nut
5. Swivel Lock Bolt
6. Swivel Bolt Bracket

7. Swivel Bolt Pin
8. Tray

9. Lock Case
10. Lock Cover

amount of foaming type upholstery cleaner with a brush.

Carpets and Covers—All Models

Removal of front compartment carpeting will require removal of sill plates and loosening of console trim; service of these items is covered in this section under Front End-Cowl Area and Console Trim.

In areas where carpeting is to be cemented, proceed as follows:

1. Remove all old carpeting, jute, etc. which may adhere to floor after original carpet is pulled up.
2. Apply 3M-1711 cement or equivalent, following directions furnished with package. Be sure floor is reasonably clean and dry before applying cement.

SEATS

Removal

1. Remove bolt retaining each forward support to floor.
2. Fold seat back forward.
3. Loosen two bolts retaining each seat hold-down bracket.

4. Move seat forward and out of brackets.




Fig. 46—Rear Plenum Drain




Fig. 47—Front Seat Back Shim Location

FRONT SEAT BACK PANEL

Removal and Installation (Fig. 47)

1. Tilt seat back forward and remove (2) screws securing bottom of seat back panel to seat back frame.
2. Pull bottom of seat back outward and lift panel upward to disengage panel from upper retainers; then remove panel from seat back.
3. To install seat back panel, reverse removal procedure.

SEAT BACK LOCK ASSEMBLY

Removal and Installation (Figs. 47, 48)

1. Remove front seat back panel, as previously described.
2. **IMPORTANT:** If removing and reinstalling same lock assembly, install lock up screw at location shown in Figure 48.
3. Remove lock assembly attaching screws and nuts and remove lock assembly from seat back.
4. Remove lock strap-to-cushion frame attaching screws.
5. To install seat back lock assembly, reverse removal procedure. **IMPORTANT:** After all lock assembly attaching screws, including lock strap-to-cushion frame screws, have been tightened, remove lock up screw at location shown in Figure 48.
6. If requested, shims may be added to raise seat back angle 2°.

A shim must be added to either side of back cushion, under each bumper and a shim placed under the lock strap to cushion attachment in the center of the seat cushion.




Fig. 48—Front Seat Back Lock Attachments

The shims are located in the glove box.

NOTE: Recheck seat back ability to lock after adding the shims.

BODY MOUNTING

The torque of all body mounting bolts should be checked periodically as an aid to preventing annoying squeaks and rattles. All bolts should be torqued 40 to 50 ft. lb.

BODY REPAIRS

GENERAL INSTRUCTIONS

The following gives information necessary for repair of collision damage and performance of general maintenance on Corvette bodies. Included here is information dealing with availability of repair panels, general installation procedures for installing panels and repairing damage to the body.

Repair of fiber glass reinforced plastic bodies can be a relatively easy matter if precautions are observed.

In cases where welding must be done on steel parts which are installed on body, do not allow flame or welding heat to come into direct contact with plastic body panels. The general area around the welding operation should be protected with wet asbestos or any other like method (several thicknesses of aluminum foil makes an excellent heat shield if out of the way of direct flame).

Straightening of steel parts while still in body must be done with care. When applying hydraulic jacks or like equipment which operates by exerting force, bear in




Fig. 49—Front Body Construction

- | | | | |
|----------------------|----------------------------------|-------------------------------|--------------------------------|
| 1. Panel—Hood | 4. Bonding Strip—Front Fender | 6. Reinforcement—Front Fender | 8. Bonding Strip—Front Fender |
| 2. Panel—Access Door | Upper to Lower | 7. Reinforcement—Front Fender | Lower Front to Rear |
| 3. Panel—Grille | 5. Panel—Front Fender Lower Rear | | 9. Panel—Radiator Grille Lower |

mind that the part being used to brace the stationary end of tool must be able to withstand such usage and that fiber glass parts, though tougher than steel, will not yield or "take a set" as with steel parts, so they cannot be "straightened". If poor alignment exists due to collision or other physical damage, check steel reinforcements in

cowl and sill areas with care.

Tracing line of damaging force and checking body carefully for broken bonds and cracks before, during and after repairs will pay off repeatedly.

Small cracks and faults in bonds and panels will usually grow larger if left unattended.




Fig. 50—Center Body Construction

- | | | | |
|---|---------------------------|---------------------------------|----------------|
| 1. Pad—Instrument Panel | 6. Pillar—Body Hinge | 10. Plenum Side Panel Extension | 14. Door Sill |
| 2. Reinforcement—Instrument Panel | 7. Plenum Side Panel | 11. Filler Panel | 15. Molding |
| 3. Door Hinge Assembly | 8. Dash Extension Panel | 12. Panel—Side Door Outer | 16. Sill Plate |
| 4. Panel—Plenum Side Extension | 9. Sill Inboard Extension | 13. Pillar Assembly—Door Lock | |
| 5. Bonding Strip—Lower Outer Windshield | | | |

REPAIR PANELS

Body repair panels are illustrated in Figures 49 through 52. Those shown are typical of panels which are available through Chevrolet parts sources. Procedures which may be used for installing panels are explained in the following paragraphs.

Figure 53 illustrates various bonds which will be encountered during repair procedures.

PRECAUTIONS

Creams are available to protect the skin from a condition known as occupational, or contact dermatitis. This common type of dermatitis is not contagious. Improved resin formulas in the approved kits have almost eliminated skin irritation. Cream is supplied with the kit for persons who may have a tendency toward skin irritation from the resins or dust.

The application of these creams is recommended whenever the Resin materials are used. Generally the cream is not required when the plastic (epoxy) solder kit is being used. Directions for using the cream is as follows:

1. a. Wash hands clean. Dry thoroughly.

- b. Squeeze about 1/2 inch (or 1/2 teaspoonful) of #71 cream into palm of hand.
- c. Spread evenly and lightly until cream disappears. Work cream into cuticle, between fingers and around wrists.
- d. Apply second coat, repeating Steps b and c.
- e. Hold hands briefly under cold running water to set cream.
2. Remove resin mixture from hands as soon as possible and imperatively before mixture starts to gel. This can be observed by the action of the material being used. Resin may be removed with lacquer thinner by washing in soap and water.
3. Respirators are recommended when grinding. Also some minor skin irritation from glass and powdered cured resin may be evident. Washing in cold water will help to minimize.
4. Use a belt sander with a vacuum attachment for dust control whenever possible.
5. Resin mixtures may produce toxic fumes and should be used in well ventilated areas.
6. Be careful not to get any resin material on clothing.
7. Use the right materials for the job. It is important to use the approved kits because other materials




Fig. 51—Under Body Construction

- | | | | |
|---|----------------------------|--|-----------------------------|
| 1. Panel — Underbody | 4. Lid Lock Striker Anchor | 8. Plenum | 10. Reinforcement—Body Bolt |
| 2. Support — Console | 5. Center Panel | 9. Reinforcement—Folding Top Hinge Support (19467) | 11. Shield—Rear Quarter |
| 3. Panel — Wheel Housing Closing — Right Hand | 6. Reinforcement | | |
| | 7. Baffle | | |

available may not meet the required engineering and safety standards.

8. Keep materials, utensils and work area clean and dry. These repairs involve chemical reactions, and dirt or moisture may upset the chemical balances and produce unsatisfactory results.
9. Before starting repair operations, look for hidden damage by applying force around the damaged area, looking for hairline cracks and other breakage. Check for minor damage at other points in the vehicle such as around exhaust pipes, grille, headlamps and points of wear. Early repair of minor damage may prevent major repair later.

PLASTIC SOLDER KIT

The Plastic (Epoxy) Solder Repair Kit is used for minor repairs on the Corvette body. These materials will produce an easy, quick and lasting repair in the case of small cracks, surface imperfections and small holes.

1. Use paint remover or power sander, and remove finish from damaged area. Carefully inspect for other areas requiring repairs.

2. Mix the materials (fig. 54).

3. Apply the epoxy solder using a putty knife or rubber squeegee, Figure 55. Work the material into the repair and build the material up to the desired contour. For deep filling and on vertical surfaces, several layers may be used, each about 1/2" thick.
4. Finish the repair by grinding, sanding and painting in the usual manner, Figure 56.

RESIN REPAIR

The Resin Repair for major repairs, consists of resin, hardener, filler, fiberglass cloth, protecting creams and mixing utensils. Repairs such as torn panels and separated joints require the adhesive qualities of the resin and the reinforcing qualities of the glass fibers. Steel to fiber glass separations are connected together with epoxy solder after first cleaning out old bond.

The following procedure is basic for repairing any plastic (fiberglass component or panel).

1. Look for hidden damage. Apply force by hand around the damaged area.




Fig. 52—Rear Body Construction

- | | | | |
|---|---|---|-----------------------------------|
| 1. Panel—Body Rear Upper | 6. Extension—Body Rear Upper Panel | 11. Panel—Body Rear Upper | 15. Bonding Strip—Body Rear Upper |
| 2. Bezel—Fuel Tank Filler Door | 7. Support—Body Rear Upper Panel | 12. Bonding Strip—Body Rear Upper Panel | 16. Body Rear Lower Panel |
| 3. Reinforcement Roof—Right Hand | 8. Lid—Folding Top Compartment | 13. Panel—Rear Quarter—Left Hand | 17. Shield—Rear Quarter Splash |
| 4. Panel—Rear Roof Inner Center—Left Hand | 9. Panel—Rear Quarter—Right Hand | 14. Bonding Strip—Body Lower Panel to Quarter Panel—Left Hand | 18. Panel—Rear Filler |
| 5. Panel—Rear Roof Inner Rear—Left Hand | 10. Bonding Strip—Body Rear Upper Panel to Quarter Panel—Right Hand | | |
2. Use paint remover and remove finish from around damage area. Inspect area again for signs of other damage.
3. Grind or file the damaged area to form a "V" at the broken or cracked portion. Side of "V" should have a shallow pitch for maximum bonding surface. A belt sander with a vacuum attachment will minimize the dust problem, Figure 57.




Fig. 53—Typical Body Bonds

4. If rear of damage is accessible, use a button-type repair. Clean back of area to permit the use of laminate (resin-saturated glass-cloth) on both sides of damaged area.
5. Cut fiberglass cloth to size. Make certain a minimum of five layers is cut for the average repair.
6. Mix resin and hardener, 1 part hardener to 4 parts resin. Add filler to the mix to give the mix body and reduce the "runniness" of the material.



Fig. 54—Mixing Plastic (Epoxy) Solder Material




Fig. 55—Applying Plastic Solder



Fig. 56—Finishing Plastic Solder Repair



Fig. 57—Grind "V" at Damaged Area



Fig. 58—Applying Resin Mixture to Fiberglass

CAUTION: Cleanliness is most important. Be certain all containers are dry and clean and the resin and hardener cans are kept closed when not in use. Do not use waxed cups for mixing and do not allow resin to enter hardener can or vice versa.

7. Saturate layers of fiberglass (Fig. 58). Place laminate over damage area. Smooth out wrinkles, and make sure general contour of area is maintained. Figure 59.
8. Apply heat to repair area. Heat lamps are recommended, used at least 12" away from repair. Allow 15 to 20 minutes curing time. Trim repair to shape at gel stage.
9. After the repair is cured, grind, file or sand to contour. Files other than body files may be more suitable. A belt sander with a vacuum cleaner attachment will minimize the dust problem. Feather edge and finish sand.

NOTE: After Resin Repair, small pits or irregularities may appear in finished surface. Imperfections should be repaired using the Plastic (Epoxy) Solder Repair Kit.

SPECIFIC REPAIRS

Scratched Panels, Spot Refinishing

In many instances, a scratched panel will involve only



Fig. 59—Applying Laminate to Body




Fig. 60—Typical Scratched Panel

a paint refinishing job. Figure 60 shows the top of a fender panel which has been scratched through to the plastic.

1. Remove all paint down to the plastic from the area surrounding the scratch with Lacquer Removing Solvent.
2. Featheredge the repair area with No. 220 wet or dry sandpaper and finish block sand with No. 320 wet or dry paper. Figure 61.

CAUTION: Do not sand too deeply into fiberglass mat. Should it be necessary to cut fairly deep into the glass mat use the repair procedure suggested for dents and pits in plastic panels.

3. Clean up repair area using Prep-Sol or equivalent, then finish the clean-up with a tack rag.
4. Protect surrounding panels by masking before performing paint refinishing operations. Use only non-staining type masking tapes on Corvette plastic body.
5. Refinish panel as described in paint refinishing portion of this manual.



Fig. 61—Repair Area Finish Sanded




Fig. 62—Typical Pitted Panel

Dents or Pits in Panels, Cracks in Glaze Coat

Figure 62 shows a panel which has received a heavy glancing blow, resulting in an indentation or large pit in the panel. The following procedure is advised for a repair of this type of damage. Cracks in the glaze or finish coat of plastic and paint may also use this procedure.

NOTE: This repair may be used wherever the damage is not extensive and the plastic is not pierced, but the damage area does require a plastic build-up.

1. Remove paint down to the plastic from area surrounding the damage with Lacquer Removing Solvent, or its equivalent.
2. Scuff area surrounding damaged area to provide a good bonding surface.
3. Clean up work area with Prep-Sol then use tack rag for finish clean-up.




Fig. 63—Typical Cracked Panel

4. Use the Plastic Solder Repair (previously described) to fill the imperfections.
5. Feather-sand damaged area with No. 220 sandpaper and finish sand with No. 320.
6. Prepare repair area for paint refinishing operation.

Cracked Panels

NOTE: For best results, temperature should be at least 70°-75°F.

1. In the case of a cracked panel, such as shown in Figure 63, cut along the break line with a hacksaw blade and remove broken portion of the panel.
2. Remove the paint down to the plastic from both portions of the panel with a Lacquer Remover or equivalent.
3. Remove dirt and deadener thoroughly, back approximately 2 to 3 inches from the fracture, on the under side of both portions of the panel. Also, remove paint and scuff area clean to provide a good bonding surface.
4. Remove all cracked and fractured material along the break. Bevel the attaching edges of the panels at approximately a 30° angle with a file or grinder and scuff plastic surfaces along edges of break.

NOTE: Mask surrounding panels using a non-staining masking tape.

5. Use "C" clamps to align panel portions allowing approximately 1/8" between the panels or as necessary to provide proper alignment of panels, Figure 64.
6. Cut two pieces of woven glass fiber cloth for backup of sufficient size to overlap the fracture by approximately two inches.
7. Clean up repair area with Prep-Sol, then use tack rag for finish cleanup.
8. Use the Resin Repair Procedure previously described.

NOTE: In some cases it may be advantageous to provide additional reinforcements along a fracture. This may be accomplished by placing glass cloth strips in the panel break before applying the plastic mixture.




Fig. 64—Cracked Panel Preparation




Fig. 65—Molding and Weatherstrip (Convertible Hardtop)




Fig. 66—Top Attachments and Headlining (Convertible Hardtop)

Fractured Panels

Sometimes damage will occur to panels where the underside is inaccessible or for reasons of panel contour it is impractical to use back plies of fiberglass cloth. The following repair operations are typical of this type of damage.

1. Prepare the damaged area by grinding or filing all cracked and splintered material away from the fracture.
2. Bevel the edge of the fracture at approximately a 20° angle.
3. Remove paint from area surrounding fracture with Lacquer Solvent, or its equivalent.
4. Scuff surface to provide a good bonding surface. Then, clean up area with Prep-Sol and wipe dry.
5. Protect adjacent panels by masking, use non-staining masking tape.
6. Cut a strip of fiberglass cloth of sufficient size, so the fracture will be lapped from 1 to 2 inches on all sides.
7. Prepare plastic mixture in an unwaxed paper cup. (See Resin Repair procedure.)
8. Impregnate glass fiber cloth by brushing or dipping in plastic mixture. Squeeze excess mixture from cloth.

NOTE: Avoid over-rich plastic areas in the glass cloth, as the strength of the patch is directly proportional to the glass content of the patch.

9. Position plastic impregnated fiberglass over the fracture on the exterior of the panel, lap the break by 1 to 2 inches, and depress into fracture.
10. Carefully work excess plastic out of woven glass by sponging from the center of the break outward.

NOTE: Hold woven glass in place until plastic resin "gels" with Saranwrap or some similar material.

11. Trim excess or loose strands of fiberglass from patch.
12. If low spots exist, prepare another plastic mixture of resin and hardener and mix thoroughly. To this mixture add short fibers cut from glass cloth to give the mixture a putty-like consistency.
13. Liberally apply the plastic mixture with a spatula to fracture and surrounding area. Deposit enough material build-up to allow for filing and sanding operations.
14. Allow the patch to harden.
15. File or grind patch to match the general contour of the panel. Exercise care when performing these operations to avoid gouging the patch or surrounding panel.
16. Use epoxy plastic solder as necessary to fill any imperfections.
17. Allow fill to harden, then sand finish preparatory to paint operation.

Panel Replacement

To install a replacement panel, the following method may be used. Various repair panels are available for service. See Repair Panels in general instructions at

beginning of this section. These complete panels may be used or sections may be cut to accommodate the type of repair necessary. The panels should be fitted in and all attaching parts installed to insure proper alignment.

To replace panel, proceed as follows:

1. Cut out damaged panel with a hacksaw blade and thoroughly remove all dirt and paint from the underside of the old panel or panels for a distance of approximately 2 to 3 inches back from the attaching line.
2. Remove the paint from the finish side, for a distance of 2 to 3 inches on the panel adjacent to the replacement panel location with lacquer solvent or equivalent.
3. Scuff the surface on both the replacement panel and adjacent panel for a distance of 2 to 3 inches back from the attaching line and wipe clean.
4. Bevel all attaching edges at approximately 30° across the entire thickness of the plastic so a single "V" butt joint will be formed on the finish surface when the pieces are joined. If the replacement panel does not fit closely to the break, reshape to suit.
5. Cut two backup pieces of woven glass fiber cloth to run the entire length of the joint or shorter lengths of fiber cloth may be lapped over entire length of joint, also cut wide enough to lap the junction line on either side by two or three inches.
6. Prepare a sufficient amount of liquid plastic in an un-waxed paper cup by mixing resin with hardener (See Resin Repair procedure).
7. Align replacement panel, then clamp panel in place to form a closed "V" butt joint at the panel junction. When panel cannot be clamped, use 3/16" bolts with large washer on inner and outer of panel to hold panels in alignment or use straps and sheet metal screws.
8. Impregnate backup plies of woven glass cloth with prepared plastic mixture by dipping or brushing. Remove excess plastic from cloth by squeezing.
9. Place impregnated backup plies on underside of panels. If necessary, hold backup plies in place with paper until plastic "gels."
10. Prepare another plastic mixture of resin and hardener and mix thoroughly. To this mixture add cut glass fiber (1/2" lengths) until mixture has a putty-like consistency, or utilize glass cloth.
11. Fill "V" groove with reinforced plastic material or saturated glass cloth. Build up surrounding area with sufficient material to allow for finish operations.
12. Allow patch to harden.
13. File or sand (#80-D sandpaper) to general panel contour.
14. Allow plastic fill to harden, then sand, preparatory to paint operations.

HARD TOP

CARE AND STORAGE

The outside painted finish of the hard top should be cleaned in the same manner as the rest of the body. The inside headlining should be cleaned as outlined under Cleaning Soft Trim.

When hard top is not in use, it should be stored indoors where it can be kept clean and dry. If stored for a long period of time, keep covered to prevent dirt from settling on headlining and outside surface.

REAR WINDOW

Refer to Figures 65 and 66 for parts identification.

Removal

1. Remove hard top from vehicle and place protective covering over headlining.
2. Mark position of right-hand upper reveal molding end (fig. 67) and pry out from retaining clips. Repeat for left-hand and lower molding assemblies.
3. Remove lower (inside) garnish molding by removing four (4) nuts from fixed studs and carefully pulling molding outward.
4. Follow Steps 8 through 13 as outlined in the section entitled FRONT END--WINDSHIELD for removal of glass.

Installation

1. Position replacement glass in opening and carefully check relationship of glass to flange completely around opening. Overlap of glass should be equal with a minimum overlap of 3/16 inches.
2. Where necessary, place shims under lower spaces to obtain required overlap of glass to upper and lower flanges.
3. After proper alignment is attained, mark position on glass and top surface with grease pencil.
4. Follow Steps 16-22 in the section entitled FRONT END--WINDSHIELD for installation of glass.
5. Press glass lightly to set caulking to window opening flanges. Paddle material where necessary to ensure proper seal.
6. Water test immediately using a cold water spray. If water leaks are encountered, use flat bladed screw driver or splint, and from the inside, paddle caulking material into point of leakage.




Fig. 67—Marking Molding Position

CAUTION: Do not run a heavy stream of water directly on caulking material while the material is still soft.

7. Install previously removed moldings in reverse order of removal.

TOP ATTACHMENTS

Figure 66 illustrates location and installation of guides and lock mechanisms. With headlining removed as outlined in this section, to adjust left and right hand locks fore and aft, mark original position, loosen two (2) mounting bolts, and move in desired direction. Make certain that lock is engaged in serrations before tightening mounting screws.

Up-and-down adjustment is performed by turning hexagonal latch bolts clockwise and counter-clockwise respectively. Header guide pins and rear pin housings are retained by mounting screws located at flanges. Center trim plate is removed by first removing center lock, and then four (4) retaining screws.

HEADLININGS

The headlining assembly is secured to the top by plastic fasteners located around the periphery of the hard top inner panel. The headlining is removed by carefully disengaging fasteners by prying outward with fingers on flat-bladed instrument. After removal from plastic top, the headlining can be disassembled into three parts by removing retaining nuts at inside surface of headlining. For installation, make certain to align headlining to top before engaging plastic fasteners.

WEATHERSTRIP AND DRIP MOLDING

As shown in Figure 65, door window weatherstrip and drip molding are retained by screws to top assembly. Side outer and rear outer weatherstrip are mounted to body at ends by screw and around periphery by special plastic retaining clips. Weatherstrip is replaced by removing two (2) screws and carefully pulling outward at clip location.

Inner forward weatherstrip is replaced by removing mounting screws and disengaging special clips along length of weatherstrip. All drip molding must have pumpable sealer on underside and adhesive applied to weatherstrips.

VINYL COVERING

Removal

1. Remove weatherstrip assemblies.
2. Remove reveal moldings.
3. Prior to removing fabric cover, application of heat to cemented areas will permit easier loosening of cemented edges.

CAUTION: Apply heat by lamps held 18" (minimum) from fabric only until fabric is warm. If lamps are held too close, or fabric cover is heated over 200°F, the fabric may lose its grain, blister, or become very shiny.

4. Loosen cemented edges of fabric roof cover.

Installation

1. Wipe roof panel with a Xylol solvent such as 3M

- Adhesive cleaner or equivalent. Remove or smooth out excess old cement. Apply solvent and allow to soak before rubbing.
2. Where possible, install new cover at room temperature (approximately 72°) to permit easier fitting and removing of wrinkles from the cover assembly.
 3. Determine center line of roof panel by marking center points on front of hard top and back window opening. Fold cover lengthwise. Lay cover on roof panel. Determine overhang (approximately 1").
 4. Apply nitrile non-staining vinyl trim adhesive (such as 3M Vinyl Trim Adhesive) to the roof panel adjacent to center line of fabric roof cover.
 5. Application of nitrile vinyl trim cement should be as thin as possible. An excessive amount of cement may result in trapped solvents (blisters) between fabric cover and roof panel. A monair roller should be used for thin adhesive application.

NOTE: If nitrile non-staining cement is not available, neoprene type non-staining weatherstrip cement (3M weatherstrip cement or equivalent) may be used.

6. Apply cement to entire fabric roof cover.
- NOTE:** Allow approximately 15 minutes for cement to dry.
7. Fold vinyl cover back to contact adhesive on roof panel. Vinyl cover seam must be parallel to centerline of vehicle.
 8. Repeat above steps for opposite side of roof.
 9. Use suitable spatula or roller to remove wrinkles and/or bubbles from vinyl cover.
 10. Trim excess vinyl around entire top to provide a minimum of 1/2" flange which will be cemented to substructure of removable hardtop with adhesive.
 11. Reinstall reveal moldings and weatherstrips.

Vinyl Roof Cover Repairs

Certain types of fabric roof cover discrepancies can successfully be repaired without replacing or removing the cover.

Scuffs or Small Cuts Near Exterior Moldings

If a small cut is present, an attempt should be made to cement the loose ends prior to performing the following:

1. Obtain a scrap piece of fabric roof cover material, or material from a hidden area directly on complaint car (such as under reveal moldings).
2. Using an electric wood burning needle or low heat soldering gun, scrape off an appropriate amount of vinyl from scrap piece of material or from hidden area and immediately apply to scuffed or cut area on car.

CAUTION: Be certain low heat is maintained to prevent discoloration of cover.

3. Carefully blend applied vinyl to fabric roof cover, utilizing electric needle or soldering gun.

Wrinkles, Blisters and Bubbles

1. Pierce each wrinkle, blister and bubble on fabric

roof cover with a small needle.

2. Completely saturate a clean shop towel with water and wring out.
 3. Apply cloth to wrinkle or blistered area.
 4. Apply a home type laundry iron over shop towel using back and forth strokes until towel is dry. (If iron has heat control settings, control should be set to "wool".)
- CAUTION:** Do not continue to use iron after towel has become dry as excess heat may cause permanent damage to vinyl roof cover.
5. Remove towel and inspect area. If slight wrinkles or blisters are still present, perform the following steps:
 6. Using a syringe and hypodermic needle filled with clear water, inject sufficient water into wrinkle or bubble to dampen fabric backing.
 7. Repeat Steps 2 through 4.

FOLDING TOP

CARE OF THE FOLDING TOP

To avoid water stains, mildew, or possible shrinkage of the top material, do not keep the top folded for extended periods of time if it is damp or water soaked. Permit top to dry out in a raised position before stowing. Also avoid pasting advertising stickers, gummed labels or masking tape on the plastic back window. In addition to being difficult to remove, the adhesive on these stickers may also be injurious to the plastic composition of the window.

Care of Rear Window

The large plastic rear window in the folding top will remain in good condition for the life of the top if given proper care. Due to the texture of the plastic window, it is susceptible to scratches and abrasions; therefore, when cleaning the window, follow the steps outlined below.

1. To remove superficial dust, do not use a dry cloth. Use a soft cotton cloth moistened with water and wipe cross-wise of the window.
2. To wash the rear window, use cold or tepid (not hot) water and a mild neutral soap suds. After washing, rinse with clear water and wipe with a slightly moistened clean soft cloth. A high quality plastic window cleaner is available from Chevrolet parts sources.

CAUTION: Never use solvents such as alcohol or volatile cleaning agents on the plastic window. These liquids may have a deteriorating effect on the plastic and if spilled, may spot the painted finish on the rear body panels directly below the rear window.

3. When removing frost, snow or ice from the plastic window, DO NOT USE A SCRAPER. In an emergency, warm water may be used. Use care that the warm water does not contact the glass windows or windshield.

ADJUSTMENTS

To correct variations in the top fit, adjustments are




Fig. 68—Folding Top Adjustments




Fig. 69—Folding Top Trim Installation

made at three locations shown in Figure 68. A combination of adjustments may be necessary to correct any given problem, including door and window adjustments which are covered elsewhere in this section.

The folding top adjustments are:

Header

After removing header trim panel, header assembly may be moved fore and aft when the two clamping screws are loosened. This will correct such conditions as header latch guide pin alignment with the holes in the windshield upper frame. Indications of misalignment are loose top trim when top is up and locked, and excessive effort required to engage header locks. Note that it will be necessary to remove side roof rail weatherstrip to gain access to header outer clamping screw. Refer to Weatherstrip portion of this section.

Hinge

The hinges may be moved up and down and fore and aft to the limit of the slotted holes in hinge plate and body. To gain access to hinge, remove rigid plastic trim as explained in Interior Trim portion of this section. Repositioning hinge will correct conditions such as poor top fit at upper and rear edge of windows; faulty fore and aft engagements of rear bow hold-down pins in lock assemblies and loose or over-tight top rear panel when top is raised and properly locked in position.

Rear Bow Hold-Down Locks

Fore and aft adjustment is provided by slotted holes in lock housing. Turning of locating pins adjusts force that holds seal to folding top lid. The hold-down pins may be moved to left or right to center top on body in raised position; thus correcting poor alignment at windows and difficult entry of pins in locks.

TOP ASSEMBLY REMOVAL AND INSTALLATION

The entire top assembly (frame with trim attached) may be removed from vehicle as follows:

1. Raise top, but do not engage header or rear bow locks.
2. Remove rigid plastic trim as outlined in Interior Trim portion of this section.
3. Mark installed position of hinge by scribing outline of hinge plate on lock pillar surface.
4. Remove two screws retaining each hinge to lock pillar and remove top assembly from vehicle.
5. When installing top assembly, carefully match hinge plate with scribed marks on body lock pillar and install screws. If necessary, proceed as outlined under Top Adjustments.

TOP TRIM AND REAR WINDOW ASSEMBLY

The following information deals with removal and installation of the folding top trim and window assembly complete. Figure 69 may be referred to for parts identifications. Lettered sections (i.e. Section A-A) referred to in the instructions may also be found in Figure 77. Note that the sections are illustrated as they would appear if the parts were cut through on the lettered lines

on the top assembly and the cut surface exposed. Arrows indicate direction in which you would have to look in order to see the view shown.

Before old trim assembly is removed, top should be thoroughly adjusted as outlined in this section. As loose parts are removed such as stay straps and pads, their installed positions should be marked as an aid to installation of replacements.

Removal

1. Remove rear side rail window sealing weatherstrip, as explained further on in this section; also remove screws from ends of header inner weatherstrip. Note, however, that it is not necessary to remove header weatherstrip entirely and that header strip must be in place during final installation procedures of top trim so that correct tension of installed trim is achieved.
2. Remove tacks securing top and header outer weatherstrip to header (fig. 70).
3. Remove screw securing trim hold cable and spring assembly to header.
4. Pull cemented trim from rear side rail (Section C-C).
5. Remove end caps from wire-on binding; remove tacks securing binding to #3 bow (View F.). See frame and linkage portion for bow identification.
6. Remove staples securing trim to #3 bow.
7. Remove tacks securing upper ends of stay straps to #3 bow. Pads may be removed at this time, if desired. Mark position of pads and straps on head and #3 bow before removal.
8. Disconnect rear bow from top frame assembly. Two screws remain at each side Figure 71.
9. Remove trim-rear bow assembly from vehicle to clean work bench or table.
10. Remove plastic filler from rear bow weatherstrip and pull weatherstrip and trim from rear bow. Section A-A shows installed position of these components. Refer also to Figure 72.

Installation

1. Find and mark center of header, #3 bow, rear bow and leading and trailing edges of top trim. Align these marks during installation and recheck their alignment from time to time while installation is in progress, especially during tacking or stapling.
2. Assemble top trim and weatherstrip to rear bow, referring to Section A-A and Figure 72. Note that filler strip locks this assembly together and goes in last. Align center marks.
3. If new pads are required, install at this time, aligning with marks made when old pads were removed. Figure 73 shows pad construction; Figure 74 shows pad installed.
4. Install top trim-rear bow assembly on top frame with four screws removed at disassembly.
5. Lock down rear bow in desired "top up" position. Pull up stay straps and staple or tack to #3 bow (fig. 75).
6. Using a piece of mechanics wire, fish trim hold down cable assembly through top pocket and secure spring cable assembly to header with a screw.
7. Pull leading edge of trim up to header and align




Fig. 70—Trim at Header

- center marks. Smooth out fabric and clamp, tack or staple temporarily to header.
8. Draw window extension up to #3 bow, aligning centering marks. Turn an ample amount of fabric under and tack to #3 bow. Apply neoprene trim cement, GM Part #3695016 or equivalent, to area shown in View D of Figure 69. Follow directions on package.
 9. Draw roof portion of trim over #3 bow, align marks and tack on staple.
 10. Trim off excess material and install wire-on binding as shown in Figure 76 and View D of Figure 69. Install binding caps.
 11. Remove temporary clamps or fastenings holding trim to header.

12. With header locked down, pull trim assembly up tight and mark for final installation.
13. Apply trim cement to header and rear side rail.
14. Release header from windshield. Tack or staple trim to header (fig. 70).
15. Apply trim to rear side frame, previously cemented.




Fig. 71—Rear Bow Retaining Screws




Fig. 72—Installing Trim and Weatherstrip to Rear Bow




Fig. 73—Pad Construction



Fig. 74—Pad Installed

16. Install weatherstrips which were removed at disassembly and install retaining screws in header weatherstrip.
17. Install header trim panel.
18. Make any adjustments necessary, following instructions listed under Folding Top—Adjustments.




Fig. 75—Installing Stay Strap




Fig. 76—Installing Binding




Fig. 77—Top Frame and Linkage

FRAME AND LINKAGE

Figure 77 illustrates construction features of the folding top frame and linkage. Various cross sections in Figure 77 show the pivoting joints and their assembly.

If an operation is being performed which requires removal of folding top trim, follow directions in this section. The entire frame assembly may be removed and replaced as a unit. Follow instructions for Folding Top Trim and Rear Window Assembly and Top Assembly—Removal and Installation.

The pivoting joints should be lubricated with light machine oil once a year. Apply oil sparingly so as not to stain top trim.

WEATHERSTRIP

Side Rail Weatherstrip

Figure 78 illustrates installation of side rail weatherstrip which acts to seal window opening. The weatherstrip is held in place by loose screws which are part of the weatherstrip assembly, and by neoprene base cement which is applied between weatherstrip and side rail surface.

When replacing weatherstrip remove all rust, old cement and foreign material from the surfaces to be cemented, to assure successful bonding. Use only good




Fig. 78—Side Rail Weatherstrip




Fig. 79—Header Weatherstrip

quality neoprene cement suitable for weatherstrip application.

Header Weatherstrip

Weatherstrip assembly is retained to the header panel by a combination of studs, and special fasteners as shown in Figure 79 along with neoprene base weatherstrip cement.

SPORT COUPE MODEL 19437

ROOF PANEL ADJUSTMENT (Fig. 80)

Each roof panel is adjusted in relationship to the other




Fig. 80—Roof Panel Alignments

and to the header and roof crossover.

Roof panel inner edges are spaced parallel 1/16" to 3/16". The rear edges of the roof panel are spaced 1/8" to 1/4" side to side. The outboard edge of the roof panel to header spacing is determined by the triangular headed pin fastened to the roof crossover. The back edge of the triangular headed pin should measure 1/4" from the plate it screws into.

All latches and adjustments must be loose before starting the roof panel alignments. The only shimming possible is at the center guides.

Adjustment Procedure

1. Remove roof panel and place upside down on a clean soft surface.
2. Remove screw from each side of headlining panel and gently pry headlining loose from plastic retainers.
3. Loosen screws on underside of roof panel at forward (b) and center guides (c).
4. Repeat steps 1-3 for opposite roof panel.
5. Check dimension of triangular pin (a) on header panel at outer edges of the roof panel attachment locations. Refer to View A.
6. Reinstall roof panels and observe spacing. The roof halves should meet within 1/16"-3/16" in the center (dimension A) and within 1/8"-1/4" to the header (dimension B).

NOTE: Contour of roof is controlled by shims (d) (no more than 4). It should be noted that the fewer shims used at this location, the more compression on the seating gasket.

7. Once dimensions A and B have been obtained by manipulating each roof panel with respect to one another and the header, tighten the screws securing the center and forward guides in the roof panels.

NOTE: If compression at the lock locations is needed, adjust bolts (e) accordingly. If point of contact of latch bolt needs adjustment loosen bolts (f) and move latch assemblies fore or aft as necessary.

8. Align headlining with a 3/16" gap all around and push headlining panels upward with firm palm pressure at nylon retainers.
9. Remove panels, make sure all nylon fasteners are engaged and reinstall headlining screws.
10. Reinstall roof panels on vehicle.

Weatherstrip Replacement (Fig. 81)

1. Remove roof panel and place upside down on soft clean surface.
2. Remove screw on each side of headliner panel.
3. Pry headliner loose from nylon retainers at eight (8) locations. Remove headliner.
4. Pry out plastic buttons retaining weatherstrip to roof panel.
5. Clean old sealer off roof.
6. Apply sealer to roof panel along the entire outline of the roof panel where the weatherstrip is to lie.
7. Install new weatherstrip at screw attachment end engaging all plastic retainers. Push down along strip to uniformly spread the sealer.
8. Secure weatherstrip to roof panel with four (4) screws.

9. Reinstall headliner panel.
10. Reinstall roof panel.

INTERIOR QUARTER PANEL TRIM REMOVAL (Fig. 82)

1. Remove rear window.
2. Gently pry off back window lower garnish molding (f) by pulling lower edge forward, then after unhooking nylon fasteners, lift up.
3. Remove (right or left) rear roof trim panel latch cover (a) secured by screws.
4. Remove (right or left) rear roof trim panel (b).
5. Remove (right or left) quarter trim panel secured by screws.

NOTE: Four (4) screws retaining forward lip of interior quarter trim panel are removed and installed from inside door jamb.

6. Install interior trim and rear window in the reverse order of removal.

CENTER ROOF REINFORCEMENT TRIM REMOVAL (Fig. 77)

1. Remove both rear roof trim panel latch covers (a)—2 screws each.
2. Remove rear window.
3. Remove both rear roof panels (b) secured by screws.
4. Remove left and right sun visor assemblies. Remove windshield upper garnish molding (c) secured by screws.
5. Remove center roof trim screws. Pull assembly (d) downward to release the attachment stud (e).
6. Install interior trim in the reverse order of removal, then install rear window.

STORAGE TRAY

The storage tray which provides a means of storing rear window assembly when removed from vehicle, is replaced by removing hinge screws at rear body panel. The latch is adjusted by bending for proper engagement.




Fig. 81—Roof Panel Weatherstrips

REAR WINDOW

Glass Replacement

To replace rear window glass, the following procedure is recommended.

1. Remove rear window assembly from vehicle and place on bench.
2. Remove lower frame member from old glass and frame assembly.
3. Remove glass from upper frame member and clean out sealer by carefully scraping from groove around entire perimeter of frame.
4. Apply bead of caulking material (polysulfide or equivalent) around slot of both frame components.
5. Insert replacement glass into curved frame member.
6. Assemble frame by aligning lower member with glass.
7. Clean excess caulking material from surface of glass.

Adjustment

The locks and lower receiving plates which determine the holding force are adjusted to the extent of slotted mounting holes to attain an even, adequate seal.

Weatherstrip

The weatherstrip between the rear window assembly and rear body opening is replaced by cementing to rear inner body surface around opening. The weatherstrip is then screwed in place.




Fig. 82—Interior Quarter Trim

SPECIAL TOOLS





Fig. 83—Special Tools

1. J-9559 Deck Lid Spring Tool
2. J-7797 Door Handle Clip Remover
3. J-23457 Door Lock Striker Bolt Remover



Model	List Price	Factory D&H	Mfr's Suggested Retail	Dealer's Charge	Total
-------	------------	-------------	------------------------	-----------------	-------

Camaro					
1967 Coupe	\$5248.00	\$285.00	\$5533.00		
1967 Convertible	\$5022.00	274.00	5296.00		

*Does not include state and local taxes, license fees, options or accessories.

STANDARD EQUIPMENT

Air Cleaner: Oil-wetted paper	Engine: V8: 270-hp, 350 cu in
Air, Front: Independent suspension; coil springs; stabilizer bar	Emission Control Equipment:
Air, Rear: Independent suspension; leaf springs; ratio, 3.36	Frame: Welded; full length ladder type
Battery: 12 volt, 62-amp-hr	Fuel Tank: Capacity approx 18 gallons
Belts, Seat: Driver and passenger	Generator: 42-amp Delcotron
Belts, Shoulder: Driver and passenger	Head Restraints: Driver and passenger
Brakes, Service: Hydraulic, self-adjusting; dual system; disc-type	Heater and Defroster
Size: 11.75" rotor (front and rear)	Oil Filter: Full-flow; 1 pt. throwaway type
Total effective lining area: 78.1 sq in	Shock Absorbers: Front and rear
Brakes, Parking: Rear wheels	Tires: Five F70 x 15B nylon blackwall
Clutch: Dia. 11", 123.7 sq in	Transmission: Fully synchronized 4-speed; floor-mounted shift lever
Cooling: 2.88" core, cross-flow type, effective area 315 sq in	Wheels: 15" x 8"
	Windshield Washer and Wipers: Electric; 2-speed

POPULAR OPTIONAL EQUIPMENT*

Description	Opt No.	List Price	Factory D&H	Mfr's Suggested Retail
-------------	---------	------------	-------------	------------------------

POWER TEAMS

Engines:

370-hp Turbo-Fire 350 V8. Available only when standard 4-speed or 4-speed close-ratio transmission is ordered. Includes full transmitter ignition system	L71	\$459.00	\$24.45	\$483.45
365-hp Turbo-Fire 454 V8. Available only when standard 4-speed, 4-speed close-ratio or Turbo Hydra-matic transmission is ordered. Includes HD Battery	L55	280.00	14.90	294.90
425-hp Turbo-Fire 454 V8. Available only when optional 4-speed or Turbo Hydra-matic transmission is ordered. Includes HD Battery	L56	1159.00	61.70	1220.70

Transmissions:

Replacing standard 4-speed with 4-speed transmission				
Turbo Hydra-matic	M40	N.C.	N.C.	N.C.
With standard 270-hp engine	M40	95.00	5.35	100.35
With 365- or 425-hp engine	M21	N.C.	N.C.	N.C.

4-Speed Close-Ratio	M22	95.00	5.35	100.35
Special 4-Speed Close Ratio				
With 425-hp engine only				

Air, Radio, Seat: Replacing standard postraction rear axle ratio	ZQ8	12.00	.65	12.65
Economy ratio	ZQ9	12.00	.65	12.65
Performance ratio	YE1	12.00	.65	12.65
3.70 ratio	YE2	12.00	.65	12.65
4.11 ratio	YE3	12.00	.65	12.65
4.56 ratio				

*Popular Chevrolet installed options. See latest Chevrolet Price Schedule or Truck Data Book for complete list of optional equipment.

POPULAR OPTIONAL EQUIPMENT*

Description	Opt No.	List Price	Factory D&H	Mfr's Suggested Retail
-------------	---------	------------	-------------	------------------------

POWER ASSISTS

Brakes, Power:	ISO	\$ 45.00	\$ 2.40	\$ 47.40
Steering, Power:	N40	110.00	5.90	115.90
Windows, Power/Electric:	A31	81.00	4.35	85.35

OTHER OPTIONS

Air Conditioning, Four-Season: Available only when 4-speed wide-range or Turbo Hydra-matic transmission with standard or 365-hp engine is ordered.	C60	\$441.00	\$23.50	\$464.50
Alarm System, Audio	UA6	30.00	1.60	31.60
Battery, Heavy-Duty: Included with 365- or 425-hp engine.	T60	15.00	.80	15.80
Belts, Custom Deluxe Shoulder: Convertible only—2 front.	A85	40.00	2.15	42.15
Defroster, Rear Window:	C50	40.00	2.15	42.15
Paint, Exterior: Solid colors.		N.C.	N.C.	N.C.
Radio, Pushbutton: Includes antenna: AM/FM	U69	169.00	9.00	178.00
AM/FM/Stereo Radio.	U69/U79	269.00	14.35	283.35
Roof Cover, Vinyl: Black. Available when removable auxiliary hardtop is ordered on Convertible.	C08	60.00	3.20	63.20
Steering Wheel, Tilt-Telescopic:	N37	80.00	4.30	84.30
Top, Auxiliary: Removable hardtop; Convertible model only	C07	260.00	13.85	273.85
In addition to folding top				
Top, Folding: Manually operated. Convertible only—White	AA	N.C.	N.C.	N.C.
Black	BB	N.C.	N.C.	N.C.
Tires, Custom: Genuine Leather seats, special carpeting, door trim panels and console with wood-grained accents.				
Wheel Covers, Custom	T02	60.00	3.20	63.20

OPTIONAL TUBELESS TIRES—Factory Installed

Replacing (5) F70 x 15/B Special Nylon Blackwall.	P77	29.00	1.35	30.35
(5) F70 x 15/B Special White stripe nylon.				
(5) F70 x 15/B Special Nylon White Lettered Blackwall	P09	42.00	1.65	43.65

*Popular Chevrolet installed options. See latest Chevrolet Price Schedule or Truck Data Book for complete list of optional equipment.

COLOR AND TRIM SELECTIONS

	INTERIOR TRIM & COLOR CODE									
	Type of Seat	Black		Blue (Dark)	Green (Dark)	Red	Saddle			
		Vinyl	Custom Interior Leather	Vinyl	Vinyl	Vinyl	Vinyl	Custom Interior Leather		
Coupe and Convertible	Bucket	400	403	412	423	407	417	420		

EXTERIOR COLOR	CODE									
	Lower	Upper								
Solid	26	26	X	X						
Blue, Mulsanne (Bright)	27	27	X	X						
Blue, Bridgethampton (Dark)	48	48	X		X			X		
Green, Brands Hatch	98	98	X							
Gray, Steel Cities	97	97	X		X			X		
Orange, Ontario	76	76	X							
Red, Millie Miglia	13	13	X	X	X	X	X			
Silver, Nevada	10	10	X	X	X	X	X			
White, Classic	52	52	X	X	X	X	X			
Yellow, Sunflower	91	91	X		X			X		
Yellow, War Bonnet										

POWER TEAMS

Transmission	Opt. No.	Engine Usage
4-Speed Wide-Range	Std	270-hp V8 330-hp V8 365-hp V8
4-Speed Close-Ratio	M21	330-hp V8 365-hp V8 425-hp V8
Special 4-Speed Close-Ratio	M20	425-hp V8
Turbo Hydraulic	M40	270-hp V8 365-hp V8 425-hp V8

SPECIFICATIONS

Wheelbase.....	98.0
Length (overall).....	182.5
Width (overall).....	69.0
Height (loaded): Coupe.....	47.8
Convertible.....	47.9
Tread: Front.....	56.7
Rear.....	59.4
Interior Room:	
Head Room.....	Coupe 37.2 Convertible 38.3
Leg Room.....	43.0
Hip Room.....	48.8
Shoulder Room.....	46.9
Entrance Height.....	29.0
Luggage Area (cu ft): Total.....	NA
Usable.....	5.0
Tire Size: Sport Coupe and Convertible.....	F70 x 15/H
Turning Diameter (ft): Curb-to-curb.....	37.0
Wall-to-wall.....	39.0
Steering Ratio (overall): Standard.....	20.2:1
Power.....	17.6:1
Curb Weight (lbs): Coupe.....	3292
Convertible.....	3306

1971 Corvette		Index
Coupe	V8	Corvette Features..... 2
Convertible	19437	Corvette Coupe.....3-4
	19467	Corvette Convertible..... 5
		Corvette Interiors.....6-7
		Color and Trim.....8-9
		Power Teams.....10-11
		Exterior Features.....12-13
		Interior Features.....14-15
		Specifications.....16

New Corvette Features

for 1971 . . .

- 10 Magic-Mirror colors—7 new for '71—include 3 special fire-mist choices
- New Interior trim colors
- Fuel Evaporation Control System standard
- All engines operate on low lead fuel
- New Combination Emission Control (CEC) valve
- New low profile body resin process contributes to a smoother surface and improved exterior finish

Safety and security features . . .

Occupant Protection Features

- Seat belts and shoulder belts (except Convertible) with pushbutton buckles and retractors—driver and passenger
- Built-in head restraints
- Energy-absorbing steering column
- Passenger-guard door locks
- Safety door latches
- Energy-absorbing padded instrument panel
- Thick-laminate windshield
- Padded sun visors
- Safety armrests
- Safety steering wheel

Accident Prevention Features

- Side marker lights and reflectors (front side marker lights flash with directional signal)
- Parking lights that illuminate with headlights
- Four-way hazard warning flasher
- Back-up lights
- Lane-change feature in direction signal control
- Windshield defroster, washers and dual-speed wipers
- Wide-view inside day-night mirror (vinyl-edged, shatter-resistant glass and deflecting support)

- Outside rearview mirror
- Dual master cylinder brake system with warning light

Anti-Theft Features

- Anti-theft ignition key warning buzzer
- Anti-theft steering column lock

Traditional quality features . . .

- Custom Interior option (includes leather seat trim, plush cut-pile carpeting, special door trim with carpeted lower panel, plus wood-grain accents on doors and console)
- High-rise slim-tapered bucket seats with integral head restraints
- Instrument panel and console with aircraft-type instrumentation
- Astro Ventilation system with adjustable vent-ports in instrument panel
- Seat belt retractors
- Console-mounted parking brake control
- Deep-twist floor carpeting standard
- All-vinyl Interior trim standard
- Color-matched seat belts
- Utilized seat and shoulder belt buckle design
- Special sport-styled steering wheel
- Tachometer
- Separate trip odometer
- Rally-type electric clock
- Ammeter, oil pressure, fuel and temperature gauges
- Vinyl-covered molded headlining on Coupe
- Courtesy light with automatic door switches
- Light monitoring system standard with indicators built into console
- Suspended accelerator pedal
- Rear compartment stowage wells
- Warning lights for seat belt and door ajar
- Tinted glass in all windows
- Efficient valve-in-head design
- Full dual exhaust system
- Positraction rear axle standard
- Special high-domed hood included with 330-, 365-, and 425-hp engines
- High-output Delco-tron generator with micro-circuit integral regulator
- Sealed side-terminal energizer-type battery
- Positive-shift starter
- Automatic choke
- Controlled pressure lubrication system with full-flow oil filter
- Magic-Mirror acrylic lacquer finish
- Hide-A-Way windshield wipers with built-in washer nozzles concealed beneath power-operated cowl panel
- Concealed outside door handles
- Dual-speed electric windshield wipers
- Built-in blended-air heater and defroster system
- Padded instrument panel and sun visors
- Power-operated retractable dual headlights
- Carpeted luggage compartment behind front seats
- Rear compartment stowage wells
- Keyless door locking
- Concealed Convertible top stowage
- Separate spare tire stowage with key lock
- Full door-glass styling without ventpanes
- Front lower air spoiler
- Rear deck air spoiler
- Removable hardtop (available for Convertible) with glass rear window
- Full Independent suspension system
- Self-adjusting disc brakes at all four wheels
- Rugged all-welded ladder-type frame
- Wide 15" x 8" wheels
- F70 x 15 wide-oval tires
- Precise Ball-Race steering
- Rubber-mounted front stabilizer bar


2 / Corvette features

Corvette Coupe / 3






4 / Corvette Coupe with roof panels removed




Corvette Convertible



Corvette Convertible with removable hardtop / 5



6 / Corvette all-vinyl standard interior



Corvette Custom Interior

Interior Trim

models	seat style	Black vinyl	leather	Dark Blue vinyl	Dark Green vinyl	Red vinyl	Saddle vinyl	leather
Coupe & Convertible	bucket	400	403	412	423	407	417	420

Exterior Colors

code	code
Mulsanne Blue	26
Bridgehampton Blue	27
Brands Hatch Green	48
Steel Cities Gray	98
Ontario Orange	97
Mille Miglia Red	78
Nevada Silver	13
Classic White	10
Sunflower Yellow	52
War Bonnet Yellow	91

Vinyl Roof Cover Color Choice (RPO C08)

Available for removable hardtop (RPO C07) in black only with all exterior colors.

Convertible Top Colors

Choice of black or white convertible top available with all exterior colors.

Seat and Shoulder Belt Colors

interior trim color	belt colors
Black	Black
Dark Blue	Dark Blue
Dark Green	Dark Green
Red	Red
Saddle	Saddle

Engines, Transmissions and Axle Ratios

transmissions and postraction rear axle ratios

engines	4-speed (2.52:1 low)		4-speed (2.20:1 low)		Special 4-speed (2.20:1 low)		Turbo Hydra-matic	
	std.	econ.* perf.* spec.*	std.	econ.* perf.* spec.*	std.	econ.* perf.* spec.*	std.	econ.* perf.* spec.*
Standard V8 270-hp (210▲) Turbo-Fire 350 V8	3.36	3.08					3.08	3.36
(RPO LT1) 330-hp (275▲) Turbo-Fire 350 V8	3.55	3.36	3.70	3.55 4.11	3.36	3.08 3.55 4.11 4.56		
(RPO L55) 365-hp (285▲) Turbo-Jet 454 V8	3.08	3.36	3.36	3.08 3.55			3.08	2.73 3.36
(RPO L56) 425-hp (325▲) Turbo-Jet 454 V8			3.36	3.08 3.55	3.36	3.08 3.55 4.11	3.08	2.73 3.36

▲ SAE net (as installed) horsepower *Optional at extra cost.

Equipment Included With Optional* V8 Engines

	330-hp (275▲) Turbo-Fire 350	365-hp (285▲) Turbo-Jet 454	425-hp (325▲) Turbo-Jet 454
Special high-demand hood	•	•	•
Heavier duty front springs			
Heavier duty front stabilizer bar			
Heavier duty rear wheel spindle support arms	•	•	•
Rear suspension stabilizer bar			
Heavy-duty front and rear shock absorbers	•		
Heavier duty clutch			
Larger capacity radiator	•	•	•
Dual water pump and fan pulleys	•	•	•
Finned aluminum valve rocker covers	•		
Aluminum cylinder heads			
Heavier duty battery		•	•
Full transistor ignition system			

▲ SAE net (as installed) horsepower *Optional at extra cost.

10 / Corvette power teams

Transmissions

transmission gear ratios (:1)

shift selector
location

	engine	1	2	3	4	R	console
4-Speed Fully Synchronized (Standard)	270-hp (210▲) V8 330-hp (275▲) V8 365-hp (285▲) V8	2.52	1.88	1.46	1.00	2.59	•
4-Speed Fully Synchronized (RPO M21)	330-hp (275▲) V8 365-hp (285▲) V8 425-hp (325▲) V8	2.20	1.64	1.27	1.00	2.26	•
Special 4-Speed Fully Synchronized (RPO M22)	425-hp (325▲) V8	2.20	1.64	1.27	1.00	2.26	•
Turbo Hydraulic (RPO M40)	270-hp (210▲) V8 330-hp (275▲) V8 425-hp (325▲) V8	Drive (maximum)—5.21:1 to 1:1 Low 2—5.21:1 to 1.48:1 Low 1—5.21:1 to 2.48:1 Reverse—4.37:1 to 2.08:1					•


▲SAE net (as installed) horsepower

Clutches for Corvette 4-Speed Transmission Power Teams

type	270-hp (210Δ)	330- (275Δ)	365-hp (285Δ)	425-hp (325Δ)
Disc Facing Material	Semi-centrifugal bent-finger-design diaphragm spring with single dry disc—pearlitic or nodular iron pressure plate			
Disc Facing Outside Diameter	11.00	10.40	11.00	10.40
Disc Facing Total Area (sq. in.)	123.70	103.53	123.70	103.53
Spring Effective Plate Load (lbs.)	2450-2750	2900-3100	2450-2750	2900-3100

▲SAE net (as installed) horsepower


Stingray



Corvette Coupe

Corvette Convertible

Corvette Convertible with
optional removable hardtop
(RPO C07)




Corvette standard wheel trim
ring with center cap

Custom Wheel Cover
(RPO P02)

12 / Corvette exterior features

Corvette Exterior Features		Coupe	Convertible
Precision-cast bright grille		•	•
Concealed headlights		•	•
Front bumper guards		•	•
White lenses over amber parking/direction signal lights		•	•
Bright license plate frames		•	•
Functional front fender louvers with bright trim		•	•
Windshield molding		•	•
Hide-A-Way windshield wipers with built-in washers		•	•
Full door-glass styling		•	•
Rectangular outside rearview mirror		•	•
Wide-oval F70 x 15 tires and 15 x 8 wheels		•	•
Body sill moldings		•	•
Bright wheel trim (rings and center caps)		•	•
Side marker lights—front and rear		•	•
Bright roof drip and rear window molding		•	•
Flush-mounted door handles		•	•
Removable roof panels and rear window		•	•
Astro Ventilation outlet grilles on rear deck		•	•
Twin-unit taillights/back-up lights with bright bezels		•	•
Bright exhaust outlet extensions and frames		•	•
Wraparound rear bumper with built-in guards		•	•

Corvette Interior Features		
	Coupe	Convertible
Sports-styled steering wheel with black rim	•	•
Bright-accented Corvette horn button emblem	•	•
Adjustable Astro Ventilation vent-ports	•	•
Convenient aircraft-type center console	•	•
7000-rpm tachometer	•	•
Anti-theft steering column lock	•	•
Illuminated heater control panel	•	•
Separate trip odometer	•	•
Ammeter, temperature, fuel and oil pressure gauges	•	•
Light monitoring system alert panels	•	•
Seat belt, door ajar and headlight position indicators	•	•
Electric clock with sweep second hand	•	•
Cigarette lighter in console ashtray	•	•
Console-mounted parking brake control	•	•
Headlight high-beam indicator	•	•



Corvette Interior Features		Coupe		Convertible	
Luxurious all-vinyl interior styling		•		•	
High-backed slim-tapered bucket seats		•		•	
Unitized seat and shoulder belt buckle design		•		•	
Tinted glass in all windows		•		•	
Molded door panels with built-in armrests		•		•	
Full door-glass styling and Astro Ventilation		•		•	
Folding seat back latches		•		•	
Custom Deluxe color-matched seat belts		•		•	
Handy map and storage pockets		•		•	
Glare-resistant padded instrument panel and sun visors		•		•	
Parking brake and brake system warning light		•		•	
Seat belt retractors		•		•	
Deep-twist color-keyed floor carpeting		•		•	
Vinyl-covered molded headlining		•		•	
Dual Courtesy lights with automatic door switches		•		•	
Suspended accelerator pedal		•		•	
Carpeted rear compartment storage wells		•		•	
Day-night inside rearview mirror		•		•	
Door pull handles		•		•	
Black-accented hood release handle		•		•	
Special bright pedal trim		•		•	
Removable roof panels and rear window		•		•	
Bright seat adjustment handle		•		•	
Vinyl plastic rear window		•		•	

Exterior Dimensions	Sport Coupe	Convertible
Wheelbase	98.0	98.0
Length (overall)	182.5	182.5
Width (overall)	69.0	69.0
Height (loaded)	47.8	47.9
Front Tread	58.7	58.7
Rear Tread	59.4	59.4
Interior Roominess		
Head room	37.2*	38.3
Leg room	43.0	43.0
Hip room	48.8	48.8
Shoulder room	46.9	46.9
Entrance height	29.0	29.0
Luggage Compartment		
Usable luggage space (cu. ft.)	6.1	5.0

*With removable hardtop—37.1

Glass Area	Sport Coupe	Convertible
Windshield glass area (sq. in.)	977.4	977.4
Rear window glass area (sq. in.)	392.5	418.0
Total glass area (sq. in.)	2170.7	2196.2
Tire Size & Steering Specifications		
Standard tire size	F70 x 15	F70 x 15
Turning circle—curb-to-curb (ft.)	37.0	37.0
Turning circle—wall-to-wall (ft.)	39.0	39.0
Steering ratio—std. (overall)	20.2:1	20.2:1
Steering ratio—power (overall)	17.6:1	17.6:1
Fuel Capacity & Weight		
Rated fuel tank capacity (approximate gallons)	18	18
Curb weight—standard V8 (lbs.)	3292	3306
Shipping weight—standard V8 (lbs.)	3202	3216

1971



PASSENGER CAR SPECIFICATIONS

CHEVROLET

CORVETTE



ENGINEERING PRODUCT INFORMATION DEPARTMENT



WARREN

MICHIGAN

ORIGINAL COPY

GENERAL

MODEL IDENTIFICATION	2
SERIAL NUMBERS AND IDENTIFICATION	3
EXTERIOR EQUIPMENT	4
INTERIOR EQUIPMENT	5-6
EXTRA COST EQUIPMENT	7
AIR CONDITIONING EQUIPMENT	8

MODEL IDENTIFICATION

CORVETTE 19437 SPORT COUPE
MODEL 19437 2-DOOR SPORT COUPE, 2-PASSENGER

CORVETTE 19467 CONVERTIBLE
MODEL 19467 2-DOOR CONVERTIBLE, 2-PASSENGER

SERIAL NUMBERS AND IDENTIFICATION

ONLY BASIC DESIGNATIONS SHOWN

VEHICLE SERIAL NUMBER

8-Cylinder Example:

Model	Model Year	Assembly Plant (St. Louis)	Unit Number (1st Unit)
19437	1	S	100001

Thus: The 1st model built at St. Louis would be serial number 194371S100001

ASSEMBLY PLANTS

S - St. Louis

Starting unit number 100001 and up at
each assembly plant regardless of series
Location Stamped on plate attached
to left hand windshield pillar

TRANSMISSION IDENTIFICATION

● Example: P1E01

Type Designation	Source Designation	Model Year 1971	Production ^o Month & Date
WT	P (Muncie)	1	E10D*
WT	4-Speed	V-8 engine	P - Muncie
CY	Turbo Hydra-Matic	V-8 engine	- - Ypsilanti

Location:

- 4-Speed Stamped on
the right side of the case at adapter.
Turbo Hydra-Matic Nameplate
tag on right hand side of the case.

^oMonth: E denotes May; 01 denotes 1st day.

-Alpha Characters used in identifying the Calendar Month

A - January D - April K - July R - October
B - February E - May M - August S - November
C - March H - June P - September T - December

- *The letter "D" or "N" following the date numerals
indicates day or night shift, on automatic only.

ENGINE IDENTIFICATION

Example: F1210CJL

Source Designation	Production* MOnth & Date	Type Designation
F (Flint)	1210	CJL

350 Cubic Inch 8-Cylinder

CJL - Regular engine, 4-speed, 4-bbl. carb.
CJK - Regular engine, Turbo Hydra-Matic

350 Cubic Inch 8-Cylinder (RPO LT1)

CGY - Optional engine, 4-speed, 4-bbl. carb.

454 Cubic Inch 8-Cylinder (RPO LS5)

CPH - Optional engine, 4-speed, 4-bbl. carb.
CPJ - Optional engine, Turbo Hydra-Matic

454 Cubic Inch 8-Cylinder (RPO LS6)

CPW - Optional engine, 4-speed, 4-bbl. carb.
CPX - Optional engine, Turbo Hydra-Matic

Location:

8-Cylinder engine Stamped on
top front of RH bank of cylinder and case.

*Month: December, 12; 10th day of December, 10.

REAR AXLE IDENTIFICATION

Location, Identification Number

Bottom left or right of axle tube
adjacent to carrier housing.

See Power Train Section for
additional information.

EXTERIOR EQUIPMENT

STANDARD EXTERIOR EQUIPMENT

FRONT	AERO COUPE 19437	CONVERTIBLE 19467
Radiator Grille - Die Cast Chrome Plated Aluminum	X	X
Parking Lamps - Clear Lens	X	X
License Plate Frame, Bright	X	X
Retractable Headlamps, Painted Bezels	X	X
Hood Emblem, Cross-Flags	X	X
Windshield Reveal Moldings, Bright and Painted	X	X
Concealed Windshield Wipers with Integral Washers in Wiper Arms	X	X
Front Bumper and Grille Guards, Bright	X	X
SIDE		
Front Fender and Rear Quarter Marker Lamps	X	X
Front Fender Louver - Body Color Die Cast Aluminum-Chrome Accented	X	X
Front Fender Nameplate, "Stingray" Script	X	X
Outside Rear View Mirror	X	X
Rocker Panel Molding, Bright	X	X
Wheel Trim Ring and Hub Cap	X	X
Roof Drip Molding - Bright	X	-
Removable Roof Panels	X	-
Press-Flap Door Opening Handles - Bright	X	X
Key Locks - Bright	X	X
Door Belt Bead Molding - Bright	X	X
REAR		
Rear End Panel Block Letters "Corvette"	X	X
Single Outboard Tail Lamps	X	X
Single Inboard Back-Up Lamps	X	X
Gas Tank Filler Door Emblem, Cross Flags	X	X
License Plate Frame and Compartment Bezel, Bright	X	X
Exhaust Pipe Extensions and Bezels, Bright	X	X
Air Outlet Grilles, Painted	X	X
Rear Bumper and Integral Guards	X	X

STANDARD INTERIOR EQUIPMENT

ROOF AND PILLARS	AERO COUPE 19437	CONVERTIBLE 19467
Molded Headlining, Padded with Sun Visor Pockets	X	-
Windshield Pillars, Padded	X	X
Sunshades, Padded with Brushed Hardware	X	X
Rear View Mirror, Padded with Brushed Finish Support	X	X
Roof Center Strut, Padded with Bright Hardware	X	-
Top Header Release Latches, Bright	X	-
Removable Rear Window, Bright Frame	X	-
Door Jamb Light Switch	X	X

SEATS AND FLOOR COVERING		
Bucket Seats - All Vinyl with Integral Head Restraints	X	X
Passenger and Stowage Compartment Floor Carpet with Sound Blanket	X	X
Seat Back Latch, Bright	X	X
Seat Adjuster Handle, Bright	X	X
Seat Belts (2), Bright Buckles (Mini-Buckles)	X	X
Shoulder Harness and Retractors (Positive Control)	X	-
Floor Stowage Compartment - 3-Doors, Carpeted	X	X
Floor Stowage Compartment Door Trim Rings and Push Buttons - Painted - Bright	X	X
Body Sill Plates - Bright and Painted	X	X
Stowage Compartment Rear Wall Courtesy Lamp	X	X
Roof Panel Stowage Vinyl Bag and Tie-Down Straps, Color-Keyed	X	-

DOOR AND QUARTER PANEL		
Molded Door Trim Panel with Stitching and Built-In Armrest	X	X
Door Assist Handle - Vinyl	X	X
Door Remote Control Handle - Chrome and Painted	X	X
Door Locking Knobs and Escutcheons - Chrome and Painted	X	X
Door Trim Panel Applique	X	X
Door Locks - Free Wheeling	X	X
Window Control Handle - Bright, Plastic Knob	X	X

INTERIOR EQUIPMENT

STANDARD INTERIOR EQUIPMENT

INSTRUMENT PANEL, CONSOLE AND STEERING WHEEL	AERO COUPE 19437	CONVERTIBLE 19467
Instrument Panel Pad - Trim Color - With Stitching	X	X
160 MPH Speedometer with Trip-O-Dometer	X	X
7000 RPM Tachometer	X	X
Headlamp Rotation and Main Light Switch	X	X
Windshield Washer and Wiper Control - Black-Painted	X	X
"Astro-Ventilation" Air Outlets and Control Knobs - Bright	X	X
Instrument Panel Map Pocket - R.H.	X	X
Electric Clock	X	X
Ammeter, Temperature, Fuel and Oil Pressure Gauges	X	X
Headlamp Hi-Beam Indicator	X	X
Seat Belt, Door Ajar and Headlamp Indicators	X	X
Hood Release Lever - Black-Painted	X	X
Lamp Monitoring Indicators	X	X
Rear Compartment Glove Box with Lamp - Carpeted Door	X	X
Ash Tray and Lighter	X	X
Parking Brake Warning Light	X	X
Heater Controls - Thumb Wheel	X	X
Air Vent Control Knobs - Black Plastic White Letters "Close"	X	X
Shift Quadrant - Black With Bright Lettering	X	X
Floor Center Console and Trim Plate - Padded, Morocco Finish	X	X
Floor Center Console Trim Plate "Crossed Flags" Emblem and Engine I.D.	X	X
Parking Brake Lever - Black - Bright	X	X
15" Black Vinyl Steering Wheel, Bright Trim	X	X
Horn Button Cap - Painted, Grained	X	X
Horn Button Cap Emblem - Bright, Painted	X	X
Hazard Warning Switch - Bright	X	X
Turn Signal Indicators and Control Lever - Bright, Painted	X	X
Steering Column Ignition Switch and Lock - 5-Position Painted	X	X
Center Cluster, Morocco Finish	X	X
Center Cluster "Corvette" Nameplate	X	X
Floor Console - Vinyl Grain Covered	X	X

GLASS (TINTED)

Windshield, Laminated Safety Plate	X	X
Door Windows with "Astro-Ventilation" Monogram, Safety Solid Plate	X	X
Removable Rear Window, Safety Solid Plate	X	-
Rear Window, Vinyl Plastic*	-	X

* Safety solid plate in optional auxiliary top.

EXTRA COST EQUIPMENT

EQUIPMENT	RPO	ACC
POWER TEAMS		
330-hp Turbo-Fire 350 V-8	LT1	
365-hp Turbo-Jet 454 V-8	LS5	
425-hp Turbo-Jet 454 V-8	LS6	
4-Speed manual transmission - close ratio	M21	
4-Speed manual transmission - H.D. close ratio	M22	
Turbo Hydra-Matic automatic transmission	M40	
Rear Axle:		
Economy ratios	ZQ8	
Performance ratios	ZQ9	
Special 3.70 ratio	YE1	
Special 4.11 ratio	YE2	
Special 4.56 ratio	YE3	
POWER ASSISTS		
Brakes, Power	J50	
Steering, power	N40	
Windows, power	A31	
OTHER OPTIONS		
Air conditioning, four season	C60	
Alarm system, horn	AU6	
Battery, heavy duty	T60	
Belts, shoulder - Convertible only	A85	
Cap, locking gas filler		ACC
Carrier, rear deck		ACC
Compass		ACC
Defroster, rear window (forced air)	C50	
Fire extinguisher		ACC
Floor mats, clear vinyl twins		ACC
Highway emergency kit - fire extinguisher, tire inflator, fuses		ACC
Litter container		ACC
Radio equipment: Radios, Pushbutton - Includes rear deck antenna		
AM/FM Radio	U69	ACC
AM/FM/Stereo Radio	U79	ACC
Roof cover, vinyl - Auxiliary top required	C08	
Safety seat - child		ACC
Safety seat - infant		ACC
Spotlight, hand portable		ACC
Steering wheel, tilt and telescope	N37	
Suspension, special front and rear	F41	
Top, auxiliary - Convertible only	C07	
Top, Convertible (colors)	C05	
Wheel covers, special	P02	
FACTORY INSTALLED REGULAR PRODUCTION TIRES		
F70 x 15 B special nylon white stripe	PT7	
F70 x 15 B special nylon white letters	PU9	

AIR CONDITIONING

FOUR-SEASON (RPO C60)

Heater integrated; manually controlled by two thumb wheel controls on instrument control panel, plus a 4-speed fan switch. Left thumb wheel uses vacuum supply and electrical switches to operate mode doors and compressor. Right thumb wheel uses bowden cable to temperature door in selector duct assembly.

BASIC COMPONENTS

Evaporator, blower, condenser, receiver - dehydrator, refrigerant (freon) tank, air intake assembly and duct assembly for both systems.

EQUIPMENT (Used in addition to or in place of base equipment)

CHASSIS

Front and Rear Springs Heavy duty
Rear Axle Ratio - Refer to Power Trains Section

POWER TRAINS

Fan Blade 7 blade
Crankshaft Pulley Dual
Water Pump & Fan Pulley Dual
Compressor & Crankshaft Belt One
Generator 61 Ampere

DIMENSIONS AND WEIGHTS

INTERIOR DIMENSIONS	2
EXTERIOR DIMENSIONS	3
VEHICLE WEIGHTS	4

INTERIOR DIMENSIONS

LENGTHS

CODE	DESCRIPTION	19437	19467	
		COUPE	SOFT TOP	HARDTOP
H30	H point to heel point		6.8	
H37	Headlining to roof height	0.7	0.9	
H54	D point to tunnel		4.0	
H58	H point rise		0.4	
H61	Effective headroom	37.2	38.3	37.1
H67	Depressed floor covering thickness		0.2	
H70	Body zero line to H point (vert.)		7.0	
L17	H point travel		4.5	
L31	Body zero line to H point (horiz.)		44.7	
L34	Maximum effective leg room - accelerator		43.0	
L40	Back angle (degrees)		33.0	
L42	Hip angle (degrees)		107.0	
L44	Knee angle (degrees)		138.0	
L46	Foot angle (degrees)		88.0	
L53	H point to accelerator floor point		36.1	

SEAT AND ENTRANCE

H3	Seat chair height	18.6
H11	Entrance height	29.0
H26	Interior body height, M/M @ car centerline	33.4
H27	Interior body, M/M @ C/LO	40.0
H32	Seat cushion deflection	2.2
H50	Upper body opening to ground	43.6
W3	Shoulder room	46.9
W5	Hip room	48.8
W16	Seat width (each seat)	18.5
L14	Seat back thickness	3.7
L18	Entrance foot clearance	14.5

VISION AND CONTROL

H6	H point to W/S bottom DLO	19.8
H13	Steering wheel thigh clearance	4.2
H18	Steering column angle (degrees) horizontal	14.1
H25	Belt height	17.5
H49	H point to top of steering wheel	1.0
W7	Steering wheel center to car centerline	12.7
W9	Steering wheel maximum O.D.	15.0
W122	Tumble-home (degrees)	26.5
L7	Steering wheel torso clearance	12.4
L13	Brake pedal knee clearance	24.5
L52	Brake pedal to accelerator	3.9

LUGGAGE COMPARTMENT

V1	Luggage Capacity - Usable (Cu.Ft.)	6.1	5.0
----	------------------------------------	-----	-----

EXTERIOR DIMENSIONS

LENGTHS

CODE	DESCRIPTION	19437 COUPE	19467	
			SOFT TOP	HARDTOP
L101	Wheelbase		98.0	
L102	Tire size (standard)		F70-15	
L103	Overall length		182.5	
L104	Overhang - front		40.6	
L105	Overhang - rear		43.9	
L123	Body upper structure length at car C/L		55.6	
L127	Body O line to C/L of rear wheels		72.0	
L128	Hood length at centerline		77.5	
L129	Deck length @ car C/L		46.7	
L130	Body zero line to W/S cowl point		13.1	
L30	Vertical O line to actual front of dash		-1.7	

WIDTHS

W101	Tread - front	58.7
W102	Tread - rear	59.4
W103	Maximum overall width of car (W106)	69.0
W106	Front fender overall width	69.0
W107	Rear fender overall width	68.8
W120	Overall car width, front doors open	107.4

HEIGHTS

H101	Overall height (design)	47.8	47.9
H102	Front bumper to ground		19.2
H104	Rear bumper to ground	13.2	13.0
H111	Rocker panel to ground - rear		6.7
H112	Rocker panel to ground - front		6.7
H114	Hood at rear to ground		26.6
H115	Step height - front (design)		13.1
H122	W/S slope angle (degrees)		57.0
H125	Headlamp to ground		25.4
H126	Tail lamp to ground	27.1	26.9
H130	Step height - front (curb)	13.7	13.6
H136	Body O line to ground - front		7.6
H137	Body O line to ground - rear		7.6
H158	Roof thickness		3.9
H159	DLO height		11.9
H160	Body thickness		24.4

CLEARANCES

H106	Angle of approach (degrees)	22.0	
H107	Angle of departure (degrees)	21.0	
H147	Ramp breakover angle (degrees)	22.0	
H148	Front suspension to ground	5.7	
H149	Oil pan to ground	4.8	
H150	Flywheel housing to ground	5.2	
H151	Frame to ground	5.4	
H152	Exhaust system to ground	4.8	4.5
H153	Rear axle to ground	6.0	
H155	Tire well to ground	5.1	
H156	Minimum ground clearance	4.8*	4.5*

*-Position on car - exhaust system to ground.

VEHICLE WEIGHTS

CORVETTE

Model Symbol	VEHICLE TYPE	SHIPPING WEIGHT			CURB WEIGHT		
	Description	Front	Rear	Total	Front	Rear	Total
19437	2-Door Sport Coupe	1634	1568	3202	1616	1676	3292
19467	2-Door Convertible	1608	1608	3216	1590	1716	3306

SHIPPING WEIGHT: Weight of basic vehicle with regular equipment, including grease, oil, engine coolant to capacity and (3) gallons of gasoline.

CURB WEIGHT: Shipping weight plus gasoline to capacity.

For total shipping, and curb weights of vehicles equipped with the following options, add to, or deduct from, the base vehicle weight (lbs.)

RPO	OPTION		WEIGHT
C60	Air Conditioning	With 270 HP Engine & 4-Speed Transmission	+ 90
		With 270 HP Engine & Automatic Transmission	+ 84
		With 365 HP Engine & 4-Speed Transmission	+ 98
		With 365 HP engine & Automatic Transmission	+ 89
C07	Auxiliary Top	With Folding Top Only	+ 55
A31	Power Windows		+ 10
J50	Power Brakes		+ 10
---	350 Cu.In. V8 Engine (270 HP)	With Turbo Hydra-Matic Transmission	+ 88
LT1	350 Cu.In. V8 Engine (370 HP)	With 4-Speed Transmission	+ 62
LS5	454 Cu.In. V8 Engine (365 HP)	With 4-Speed Transmission	+220
		With Turbo Hydra-Matic Transmission	+268
LS6	454 Cu.In. V8 Engine (425 HP)	With H.D. 4-Speed Transmission	+ 82
		With Turbo Hydra-Matic Transmission	+132
		With 270 HP Engine	+ 24
N40	Power Steering	With 330 HP Engine	+ 26
		With 365 & 425 HP Engine	+ 28
P02	Deluxe Wheel Covers		+ 18
U69	Radio, AM/FM Push Button	With 350 Cu.In. Engine	+ 14
		With 454 Cu.In. Engine	+ 11

BODY

EXTERIOR PAINT PROCESS	2
EXTERIOR-INTERIOR COLORS	3
BODY CONSTRUCTION AND GLASS AREA	4

EXTERIOR PAINT PROCESS

1. **PRIMARY SANDING.** All body panels and bonded joints that receive acrylic lacquer are dry sanded to prepare surfaces for painting. A filler material, called putty rub, is applied to the entire body to fill minor imperfections.
2. **PRIMER.** Two coats of primer are applied – the first red and the second gray – and are oven baked for 60 minutes at 280 degrees F.
3. **WET SANDING.** The body is wet sanded to provide a smooth surface for the sealers. Most of the gray primer coat is removed with the red primer acting as a depth signal for the sanding operation. The body is dried to remove all moisture.
4. **SEALER.** One coat of sealer and one coat of color acrylic lacquer are applied and baked.
5. **DRY SANDING.** The body is dry sanded to prepare surfaces for the final acrylic lacquer.
6. **LACQUERING.** Three coats of acrylic lacquer are sprayed on the body to build up the required paint thickness. The paint is “rested” for eight minutes to permit it to partially set up and to remove excess volatile paint vehicle.
7. **INITIAL BAKING.** The body is oven baked for 30 minutes at 140 degrees F to harden the paint which permits the subsequent operation. Small interior and exterior parts are painted to complete the body paint schedule.
8. **FINAL BAKING.** To assure a durable, hard, high luster finish the lacquer is oven baked for 45 minutes at 250 degrees F. Reheating the lacquer permits the paint film to soften and allows surface blemishes and sanding scratches to disappear during the thermo-reflow process.
9. **FINAL SANDING AND POLISHING.** The body is lightly oil sanded and polished to bring painted surfaces to a high luster finish.

EXTERIOR-INTERIOR COLORS

		INTERIOR TRIM COLORS & RPO NO'S.				
	Interior Trim	Black	Dark Saddle	Red	Dk. Brt. Blue	Dark Green
Standard	Vinyl	400	417	407	412	423
Custom*	Leather	403	420	—	—	—

CODE	EXTERIOR COLOR					
10	Classic White	X	X	X	X	X
13	Nevada Silver	X		X	X	X
26	Mulsanne Blue	X			X	
27	Bridgehampton Blue	X			X	
48	Brands Hatch Green	X	X			X
52	Sunflower Yellow	X	X			X
76	Mille Miglia Red	X		X		
91*	War Bonnet Yellow	X	X			X
97*	Ontario Orange	X	X			X
98*	Steel Cities Gray	X				

*Special "Firemist" colors.

Convertible Top: Black or White with any exterior color.

Vinyl Top: Used with auxiliary top only, Black with any exterior color.

*—Includes leather seat trim, special cut pile carpeting on floor and lower door side walls. Wood grain insert on floor console. Wood grain insert with bright die cast molding on door side wall.

BODY CONSTRUCTION AND GLASS AREA

GENERAL

Construction Uniconstruction: fiber glass reinforced plastic body backboned by a steel cage outlining the passenger compartment. Principal members – underbody, front and rear end assemblies, dash panel and hinge pillars are bonded, riveted, or bolted together and to each other. Hood is plastic with bonded plastic reinforcement. Coupe: two removable roof panels and removable rear window.

DOORS AND LOCKS

Construction Plastic, double paneled, reinforced with steel at hinge and lock locations. Front hinged.

Door handles Press-flap handles with fork-type latches. Inside door locking knob on each door, free-wheeling 2-position inside door handles.

HOOD

Operation Internal release lever. Front hinged with telescoping link on right side. Ratchet-type lock for hold open.

VENTILATION

Type Astro Ventilation cowl top air inlets channel air to cowl side kick panel outlets controlled by bowden cable and slide type levers mounted in instrument panel center console. Water drainage at base of "saddlebag" plenum chambers.

GRILLE Die cast aluminum chrome plated.

SEATS

Type and construction Bucket with integral head restraints; leather grained vinyl covering over polyurethane padding. Leather optional.

WINDSHIELD WIPERS

Type Concealed, dual, two-speed, electric vacuum operated cowl panel; integral washers provided in wiper arms.

HEADLIGHTS

Type Dual retractable. Headlamp door retraction system vacuum operated.

SPARE TIRE

Location In well under fuel tank; accessible from underside of car. Cover with key lock provided.

TOOLS

Type Scissors jack, and combination jack handle and lug wrench. Stowage In well in luggage area directly behind passenger seat; carpeted door over well.

BODY GLASS VISIBILITY AREA

LOCATION	MODELS	
	37	67
Windshield	977.4	
Door window	800.8	
Back window	392.5	418.0*
Total area (sq.in.)	2170.7	2196.2*

Windshield – Laminated safety plate (tinted)

Doors and Removable Rear Window on hardtop – solid safety plate (tinted).

Rear window on convertible – vinyl plastic.

(*) Removable auxiliary top – 620.1; total – 2398.3.

CHASSIS

FRAME AND FRONT SUSPENSION	2
STEERING, DRIVELINE, WHEELS AND TIRES	3
REAR AXLE AND SUSPENSION	4
BRAKES	5
BULBS AND LAMPS	6
FUSES AND CIRCUIT BREAKERS	7

FRAME AND FRONT SUSPENSION

FRAME

Description All welded, full length, ladder constructed frame with 5 cross-members. Side rails and intermediate cross-members box section; front crossmember box girder section. Eight body mounting points.

FRONT SUSPENSION

Description Independent, SLA type, coil springs with center mounted shock absorbers, spherical joint steering knuckle pivots.

Wheel travel (design)

Total 7.84
Jounce Coupe 3.82 Convertible 3.97
Rebound Coupe 4.02 Convertible 3.87
Wheel to spring, travel ratio 1.63

CONTROL ARMS

Description Reinforced steel stamping with pre-loaded steel encased rubber bushings at pivot.

STEERING KNUCKLES

Description Forged steel, with integral brake caliper mounting pads and detachable steering knuckle arm

Spindle diameters

Inner bearing 1.3743-1.3748
Outer bearing 0.8428-0.8433

Spindle thread size 27/32-20NEF-3 (modified)

Wheel bearings

Type Taper roller

SPHERICAL JOINTS

Type Ball stud
Upper Compression
Lower Compression
Bearing surfaces
Upper Teflon-coated phenolic
Lower Teflon-coated phenolic

SHOCK ABSORBERS

Type Direct, double-acting, hydraulic
Piston diameter 1.00

STABILIZER BAR

Type Link
Material HR steel
Diameter 350 V-8, .750; 454 V-8, .9375
Bushing material Rubber

FRONT WHEEL ALIGNMENT (CURB)

Camber (degrees) 0 to P1-1/2
Caster (degrees) 0 to P2
Toe-in (total) 3/16 to 5/16
Steering Axis Inclination (degrees) 6-1/2 to 7-1/2

GENERAL SUSPENSION PROVISIONS

Car leveling Front stabilizer bar
Anti-drive control Angle of front upper control arm

FRONT SPRINGS

Part Number	Ref.	Type	Material	Cut-off Length	Wire Dia.	Inside Dia.	Heights Working (In. @ lbs)	Deflection Rate (lbs per inch)	
								@ Spring	@ Wheel
3931823	A	Coil, R.H. helix	Steel alloy	138.25	.600	3.80	9.99 @ 1395	250	61.8
3931825	B			138.75	.618	3.80	9.99 @ 1540	284	71.8

Engine	350 Cu.In. V-8	454 Cu.In. V-8
Model	19400	19400
Reference	A	B

STEERING, DRIVELINE, WHEELS AND TIRES

MANUAL STEERING, regular production

Description Semi-reversible gear with ball-nut driven by recirculating anti-friction bearings, energy absorbing steering column, steering damper attached to relay rod; two-position steering knuckle arm attachment for street and fast ratio steering. Adjustable steering column available optionally.

System ratios

Steering gear 16:1

Overall ratio

Street 20.2:1

Fast 17.6:1

Turning diameters (ft)

Outside front, wall to wall 39

Outside front, curb to curb 37

Number of wheel turns, lock to lock

Street 3.4

Fast 2.92

Outside wheel angle with inside wheel

@ 15 degrees 14.25

@ 20 degrees 18.47

@ 34 degrees (limit of turn) 27.34

Linkage Parallelogram type, rear of front wheels

Steering wheel

Standard and optional telescoping wheel Deep dished, 15.0 diameter

POWER STEERING, RPO N40

(Same as standard manual steering except as shown)

Description Hydraulic; pump powered cylinder assisting linkage

Ratios Gear, 16:1; overall, 17.6:1

Number of wheel turns, lock to lock 2.92

DRIVELINE

Type Tubular propeller shaft

Number used One

Diameter (OD)

Manual 2.0

Turbo Hydra-Matic 2.0

Length (/L of U-joints)

Manual 29.90

Turbo Hydra-Matic 29.50

Wall thickness

Manual120

Turbo Hydra-Matic095

Universal joints

Type Cross

Number used Two

Bearings Prepack, anti-friction

Drive and torque forces Through rear suspension control arms

WHEELS (Regular Production)

Type Short spoke spider

Attachment to hub 5 hex nuts, 7/16-20 UNF 2-B, arranged on a 4.75 diameter bolt circle

Offset N.28

Rim size 15 x 8.00

TIRES

Construction Nylon - 2-ply

Size and ply rating F70-15B-4PR

Specifications

Static Loaded Radius 12.6

Loaded rev/mi @ 45 MPH 772

Capacity (lb @ psi) 1280 @ 24

Recommended inflation, all tires, psi

Cold 24

Hot 30

REAR AXLE AND SUSPENSION

REAR AXLE

Description Fixed differential housing hypoid ring and pinion gear set, tubular articulating inner axle shafts and short solid outer shafts with integral drive flange, independently sprung rear wheels

Pinion offset 1.5
Pinion bearing adjustment Shim
Hypoid gear PD all 8.375
Type Military Spec, MIL-L-2105-B
Viscosity SAE80
Filler plug 1-3/8 hex, 1-20 AN thread
Capacity (pts) 4.0

RING AND PINION GEARS

Axle Ratio	Tooth Combination
2.73	41,15
3.08	37,12
3.36	37,11
3.55	32,9
3.70	37,10
4.11	37,9
4.56	41,9

AXLE SHAFTS

Inner Welded steel tubing with universal joint attachments to short shafts at each end.

Outer Short, splined high-alloy steel with integral wheel mounting flange

Axle bearings

Type Inner and outer tapered roller, steel encased rubber bearing seals

REAR SUSPENSION

Description Full independent with frame-anchored differential. Position of each wheel established by 3 links: tubular axle drive shafts, transverse strut rods, torque control arms. Vertical suspension loads taken by transverse leaf spring. Built-in camber adjustment at strut rod inner ends.

Wheel travel (design height)

	Coupe	Conv.
Total	6.86	6.86
Jounce	2.87	2.76
Rebound	3.99	4.10

SHOCK ABSORBERS

Type Direct, double-acting, hydraulic
Piston diameter 1.00

STRUT

Material Forged steel
Diameter75

STABILIZER BAR (454 V8)

Diameter562

REAR WHEEL ALIGNMENT

Curb
Camber (degrees) N1-3/8 to N 3/8
Toe-in (total) 1/32 to 3/32

TORQUE CONTROL ARMS

Description Welded steel box construction

REAR SPRING

Type Variable rate, 9-leaf
Material Chrome carbon steel, heat treated
Length (developed) between eye centers 46.36
Width 2.25
Design load, lb @ camber 1360 @ .352
Deflection rate, lb per inch, @ design load
 @ Spring 140
 @ Wheel (wheel rate) 123
Spring liners
Number 7
Location Between all leaves except numbers 6 and 7
Material Polyethylene with graphite

FUSES AND CIRCUIT BREAKERS

CIRCUIT	TYPE OF PROTECTION	LOCATION AND CIRCUIT*
Air conditioning	AGC 30 fuse	In line
Air conditioning lamp	AGC 25 fuse	Fuse panel (f)
Back-up lamps	AGC 5 fuse	Fuse panel (d)
Cigarette lighter	AGC 20 fuse	Fuse panel (b)
Cigarette lighter lamp	AGC 25 fuse	Fuse panel (c)
Clock	AGC 5 fuse	Fuse panel (d)
Clock lamps	AGC 25 fuse	Fuse panel (c)
Courtesy lamps	AGC 5 fuse	Fuse panel (d)
Defogger, rear window	AGC 25 fuse	Fuse panel (c)
Direction signal indicator lamp	AGC 10 fuse	Fuse panel (d)
Fuel gage	AGC 20 fuse	Fuse panel (b)
Glove compartment lamp	AGC 10 fuse	Fuse panel (b)
Headlamp hi-beam indicator lamp	AGC 25 fuse	Fuse panel (c)
Headlamp warning indicator lamp	15 amp CB	Light switch (g)
Headlamps	40 amp CB	Hinge pillar (h)
Heater	CB	Light switch (g)
Heater lamp	AGC 25 fuse	Fuse panel (f)
Ignition switch lamp	AGC 5 fuse	Fuse panel (d)
Instrument cluster lamps	AGC 5 fuse	Fuse panel (d)
License plate, rear	AGC 5 fuse	Fuse panel (d)
Brake warning lamp	AGC 20 fuse	Fuse panel (a)
Parking lamps	AGC 10 fuse	Fuse panel (b)
Power windows	20 amp fuse	Fuse panel
Radio	30 amp CB	Firewall
Radio lamp	AGC 10 fuse	Fuse panel (e)
Side Marker lamp - Front	AGC 4 fuse	Fuse panel (d)
Side Marker lamp - Rear	AGC 20 fuse	Fuse panel
Spot lamp, portable	AGC 20 fuse	Fuse panel
Tail lamps	AGC 15 fuse	In line
Temperature gage	AGC 20 fuse	Fuse panel (a)
Traffic hazard indicator	AGC 20 fuse	Fuse panel (b)
Windshield wiper	AGC 10 fuse	Fuse panel (c)
	25 amp fuse	Fuse panel

* Letter suffix indicates same circuit

SERVICE BRAKES (Regular Production)

Type	4-wheel hydraulic caliper disc brakes; dual-circuit brake system, pressure differential and parking brake warning light
Line pressure; psi, @ 100 lb pedal load	576
Braking ratios	
Pedal	5.23
Hydraulic	43.3
Overall	196.0
Distribution of braking effort	Front 65.0
Brake disc	
Construction	Double faced disc spaced by integrally cast radial cooling passages
Material	Cast iron
Diameter, front & rear	11.75
Swept drum area (sq.in.)	461.2
Brake lining	
Material	Woven asbestos
Size, all segments (L x W x T)	5.96 x 2.21 x .41
Method of attachment	Riveted
Total effective area (sq.in.)	78.1
Gross lining area (sq.in.)	86.3
Master cylinder	
Piston diameter	1.00
Piston travel (with available pedal travel)	1.10
Wheel cylinders	
Number	4 per wheel
Piston diameter	
Front	1.875
Rear	1.375
Foot pedal travel	5.75

PARKING BRAKE

Type	Drum; cast integral with each rear rotor. Internal expanding shoes, mechanically actuated
Control	Lever; floor mounted in center console
Drum diameter	6.5
Brake lining	
Number	2 shoes per each rear wheel
Size (L x W x T)	6.78 x 1.25 x .175
Gross lining area (sq.in.)	33.9

BULBS AND LAMPS

BULBS AND LAMPS	NUMBER REQUIRED AND TRADE NUMBER	CANDLE POWER PER LAMP
Back-up	2-1156	32
Cigarette lighter	1-1445	1
Clock	1-1895	2
Courtesy		
Instrument panel	2-631	6
Rear compartment	1-90	6
Direction signal indicator	2-1895	2
Headlamp Outer	2-4002	High beam 37.5W Low beam 55.0W
Inner	2-4001	High beam 37.5W
Headlamp hi-beam indicator	1-1895	2
Headlamp warning indicator	1-1895	2
Heater or air conditioning control	1-1816	2.5
Instrument cluster	12-1895	2
License plate rear	1-97	4
Parking		
Park	2-1157	3
Turn		32
Parking brake alarm & warning light	1-1895	2
Radio	1-1893	2
Compartment Storage Box	1-1895	2
Side Marker - Front	2-168	3
Side Marker - Rear	2-168	3
Spot lamp, portable	1-4416	30W
Tail		
Stop and turn	2-1157	32
Tail		3
Stereo indicator	1-2182	0.3
Door ajar indicator	1-1895	2
Seat belt warning indicator	1-194	2
Transmission indicator	1-1895	2
Washer fluid level indicator	1-168	3

POWER TRAINS

POWER TEAM COMBINATIONS	2
POWER TEAM MULTIPLICATION FACTORS	2
ENGINE DATA AND RATINGS	3
ENGINE SPEED AND PISTON TRAVEL	3
VEHICLE PERFORMANCE FACTORS	4
PRINCIPAL COMPONENTS	5
FUEL SYSTEM	10
EXHAUST AND VENTILATION SYSTEM	10
LUBRICATION SYSTEM	11
COOLING SYSTEM	12
ELECTRICAL SYSTEM	13
CLUTCHES	14
THREE AND FOUR SPEED TRANSMISSIONS	14
TURBO HYDRA-MATIC TRANSMISSION	15

POWER TEAM COMBINATIONS

ENGINE	TRANSMISSION	MODEL APPLICATION	AXLE RATIOS (A)						
			2.73:1	3.08:1	3.36:1	3.55:1	3.70:1	4.11:1	4.56:1
Turbo-Fire 350 350 Cu.In. V-8 270 HP Standard	4-Spd (2.52:1 low)	All Models		(Econ.)	(Std.)				
	Turbo Hydra-Matic			(Std.)	(Perf.)				
Turbo-Fire 350 350 Cu.In. V-8 330 HP RPO LT1	4-Spd (2.52:1 low)	All Models			Econ.	Std.	Perf.		
	4-Spd (2.20:1 low)					Econ.	Std.	Perf.	
	H.D. 4-Spd (2.20:1 low)			Econ.	Std.	Perf.	Spcl.	Spcl.	Spcl.
Turbo-Jet 454 454 Cu.In. V-8 365 HP RPO LS5	4-Spd (2.52:1 low)	All Models		(Std.)	Perf.				
	4-Spd (2.20:1 low)			Econ.	Std.	Perf.	Spcl.		
	Turbo Hydra-Matic		Econ.	(Std.)	Perf.				
Turbo-Jet 454 454 Cu.In. V-8 425 HP RPO LS6	4-Spd (2.20:1 low)	All Models	Econ.	Std.	Perf.				
	H.D. 4-Spd (2.20:1 low)			Econ.	Std.	Perf.	Spcl.	Spcl.	
	Turbo Hydra-Matic		Econ.	Std.	Perf.				

(A) Air conditioning available only with combination, as indicated by parenthesis ().

Std.—Standard

Econ.—Economy (optional)

Perf.—Performance (optional)

Spcl.—Special (optional)

MULTIPLICATION FACTORS

WITH MANUAL TRANSMISSION

ENGINE	CARBURETION	TRANSMISSION	TOTAL GEAR REDUCTION					AXLE RATIO
			1st	2nd	3rd	4th	Rev	
350 Cu.In. V-8 270 HP Standard	4-Barrel	4-Speed (2.52:1)	8.47	6.32	4.91	3.36	8.70	3.36
		4-Speed (2.52:1)	8.95	6.67	5.18	3.55	9.19	3.55
350 Cu.In. V-8 330 HP RPO LT1	4-Barrel	4-Speed (2.20:1)	8.14	6.07	4.70	3.70	8.36	3.70
		H.D. 4-Spd (2.20:1)	7.39	5.51	4.27	3.36	7.59	3.36
		4-Speed (2.52:1)	7.76	5.79	4.50	3.08	7.98	3.08
454 Cu.In. V-8 365 HP RPO LS5	4-Barrel	4-Speed (2.20:1)	7.39	5.51	4.27	3.36	7.59	3.36
		4-Speed (2.20:1)	7.39	5.51	4.27	3.36	7.59	3.36
425 HP RPO LS6	4-Barrel	4-Speed (2.20:1)	7.39	5.51	4.27	3.36	7.59	3.36

WITH AUTOMATIC TRANSMISSIONS

ENGINE	TRANSMISSION	SELECTOR POSITION	TOTAL TORQUE* MULTIPLICATION	AXLE RATIO
350 Cu.In. V-8 Standard and 454 Cu.In. V-8	Turbo Hydra-Matic	Drive	16.05:1 - 3.08:1	3.08:1
		Low	16.05:1 - 7.64:1	
		Second	16.05:1 - 4.56:1	
		Reverse	13.46:1 - 6.41:1	

*—Axle ratio x transmission ratio

ENGINE DATA AND RATINGS

GENERAL DATA

Engine Type		V-8 OHV			
Piston Displacement (Cu.In.)		350		454	
Availability		Standard	RPO LT1	RPO LS5	RPO LS6
Number of cylinders		Eight			
Bore and Stroke (nominal)		4.00 x 3.48		4.251 x 4.00	
Compression Ratio		8.5:1	9.00:1	8.5:1	9.00:1
Taxable (SAE) Horsepower		51.2		57.8	
Firing Order		1-8-4-3-6-5-7-2			
Idling	Manual Trans. (In Neutral)	600	700	600	700
Speed	Automatic Trans. (In Drive)	550		600	700
Compression Press. (PSI) @ Cranking Speed, Engine Hot		150		160	
Power Plant Mounting		Two front and one rear, compression type			
Measurements	Fan to rear of engine block	30.16		33.96	
	Top air cleaner to bottom oil pan	26.79		27.62	
	Exhaust manifold to generator (width)	27.97		30.00	

ADVERTISED ENGINE RATING

Engine	350 Cu.In.		454 Cu.In.	
	270 HP	330 HP	365 HP	460 HP
Availability	Standard	RPO LT1	RPO LS5	RPO LS6
Gross Brake HP @ RPM	270 @ 4800	330 @ 5600	365 @ 4800	425 @ 5600
Gross Torque @ RPM (lb-ft)	360 @ 3200	360 @ 4000	465 @ 3200	475 @ 4000
Net Brake HP @ RPM	210 @ 4400	275 @ 5600	285 @ 4000	325 @ 5600
Net Torque @ RPM (lb-ft)	300 @ 2800	300 @ 4000	390 @ 3200	390 @ 3600

ENGINE SPEED AND PISTON TRAVEL

Engine		350 Cu.In. Std.		350 Cu.In. LT1		454 Cu.In.		
Transmission		4-Speed	Trb/Hyd.	4-Speed		4-Speed		Trb/Hyd
Rear Axle Ratio		3.36:1	3.08:1	3.55:1	3.70:1 (a)	3.36:1 (a)	3.08:1 (a)	3.08:1
Tire Size		F70 x 15B						
Crankshaft Revolutions per Mile		2580.5	2365.4	2726.4	2841.6	2580.5	2365.4	
Crankshaft RPM @ MPH	Low	108.4	97.8	114.5	104.2	94.8	99.4	97.7
	Second	80.9	58.4	85.4	77.7	70.6	74.1	58.4
	Third	62.8	39.4	66.3	60.2	54.7	57.6	39.4
	Fourth	43.0		45.4	47.4	43.0	39.4	
	Reverse	111.4	82.0	117.8	107.0	97.4	102.1	82.0
Piston Travel (Ft/Mile)		1496.7	1371.9	1581.3	1648.1	1720.3	1576.9	

(a) Available with close ratio (2.20:1) transmission

VEHICLE PERFORMANCE FACTORS

ENGINE	BASE 350 CU.IN. 270 HP	RPO LT1 350 CU.IN. 330 HP	RPO LS5 454 CU.IN. 365 HP	RPO LS6 454 CU.IN. 425 HP
--------	------------------------------	---------------------------------	---------------------------------	---------------------------------

4-SPEED TRANSMISSION

Performance Weight (pounds)	3592	3654	3812	
Pounds per Gross Horsepower	13.30	11.07	10.44	
Pounds per Cu.In. Displacement	10.26	10.44	8.40	
Gross HP per Cu.In. Displacement	.771	.943	.804	
Power Displacement (cu.ft./mile)	261.33	276.11	310.73	
Displacement Factor (cu.ft./ton mile)	145.18	150.88	162.68	

4-SPEED TRANSMISSION - CLOSE RATIO

Performance weight (pounds)		3654	3812	3674
Pounds per Gross Horsepower		11.07	10.44	8.64
Pounds per Cu.In. Displacement		10.44	8.40	8.09
Gross HP per Cu.In. Displacement		.943	.804	.956
Power Displacement (cu.ft./mile)		287.78	338.99	338.99
Displacement Factor (cu.ft./ton mile)		157.26	177.48	167.06

TURBO HYDRA-MATIC

Performance Weight (pounds)	3680		3860	3724
Pounds per Gross Horsepower	13.63		10.57	8.76
Pounds per Cu.In. Displacement	10.51		8.50	8.20
Gross HP per Cu.In. Displacement	.771		.804	.956
Power Displacement (cu.ft./mile)	239.55		310.73	310.73
Displacement Factor (cu.ft./ton mile)	130.19		161.00	184.23

GLOSSARY

Performance Weight	Curb Weight plus 300 Lb (weight of two 150 lb passengers)
Power Displacement	$\frac{\text{Crankshaft Revs/Mi} \times \text{Piston Displacement}}{2 \times 1728}$
Displacement Factor	$\frac{\text{Power Displacement}}{\text{Performance Wt (tons)}}$

PRINCIPAL COMPONENTS

CYLINDER BLOCK

Material	Cast alloy iron
Bore Diameter	
V8-350 Cu.In.	3.9995-4.0025
V8-454 Cu.In.	4.2496-4.2524
Bore Spacing (Centerline to Centerline)	
V8-350 Cu.In.	4.4
V8-454 Cu.In.	4.84
Bearing Caps (Number, material & attachment)	
V8-350 Cu.In.	5, cast iron; 2-bolt
V8-350 (LT1)	No. 1 & 5, cast iron; 2-bolt
	No. 2, 3 & 4, nodular iron; 4-bolt
V8-454 (LS5)	5, cast iron; 2-bolt
V8-454 (LS6)	5, cast iron; 4-bolt
Water Jackets	Full length around each cylinder

CYLINDER HEAD

Material	High chrome cast alloy iron
	Cast aluminum with (LS6)
Bolt Number	34 (350 Cu.In.); 32 (454 Cu.In.)
Bolt Size	.4375 dia.; 14 threads/inch

COMBUSTION CHAMBER VOLUME

(Total chamber volume of assembled engine with piston at top center)	
V8-350 Cu.In. (Base)	6.08 Cu.In.
V8-350 Cu.In. (LT1)	5.54 Cu.In.
V8-454 Cu.In. (LS5)	7.79 Cu.In.
V8-454 Cu.In. (LS6)	7.28 Cu.In.

INLET MANIFOLD

Material	Cast alloy iron
	Cast aluminum with RPO LS6 & LT1
Type	8 port, double deck


EXHAUST MANIFOLD

Material	Cast alloy iron
Type	
V8-350 Cu.In.	Dual, 4 port, exhaust emission to a single runner with center takedown collector
V8-454 Cu.In.	Dual, 4 port, extended runners from each port converging to a rear takedown collector
Outlet Diameter (Nominal)	
V8-350 Cu.In.	2.00
V8-454 Cu.In.	2.50

CRANKSHAFT

Material	
V8-350 Cu.In.	Nodular iron
V8-350 (LT1)	Forged steel
V8-454 Cu.In.	Forged steel
End Play	
V8-350 Cu.In.	.002-.006
V8-454 Cu.In.	.006-.010
Counter Weights	6
Crank Arm Length	
V8-350 Cu.In.	1.74
V8-454 Cu.In.	2.00
Torsional Damper	Rubber mounted inertia
Timing Gear	Steel; sprocket & chain
Pulley Pitch Diameter	6.64

350 CUBIC INCH V-8 ENGINES



PRINCIPAL COMPONENTS

MAIN BEARINGS

Material Premium aluminum
 Type Precision removable
 Thrust Against Bearing No. 5
 Clearance
 V8-350 Cu.In. (No. 1) .0008-.0020;
 (No. 2, 3 & 4) .0011-.0023; (No. 5) .0017-.0033
 V8-454 Cu.In. (No. 1) .0007-.0019
 (No. 2-3-4) .0013-.0025 (No. 5) .0019-.0035

Dimensions	Theoretical Inner Dia.	Effective Length	Projected Area
V8-350 Cu.In.			
Bearing No. 1	2.4502	.752	1.8425
Bearing No. 2-4	2.4502	.752	1.8425
Bearing No. 5	2.4508	1.177	2.8846
V8-454 Cu.In.			
Bearing No. 1	2.7509	.992	2.7289
Bearing No. 2-4	2.7505	.992	2.7285
Bearing No. 5	2.7505	1.2525	3.4450

CAMSHAFT

Material Cast alloy iron
 Drive Sprocket & chain; steel
 Lobe Lift
 V8-350 Cu.In. (Base) . . .2600 Inlet; .2733 Exhaust
 V8-350 (LT1) Cu.In. . . .3057 Inlet; .3234 Exhaust
 V8-454 (LS5) Cu.In. . . .2714 Inlet; .2824 Exhaust
 V8-454 (LS6) Cu.In.3057 Inlet & Exhaust
 Bearings 5; steel backed babbitt

VALVE LIFT

V8-350 Cu.In. (Base)3900 Inlet; .4100 Exhaust
 V8-350 (LT1) Cu.In.4586 Inlet; .4850 Exhaust
 V8-454 (LS5) Cu.In.4614 Inlet; .4800 Exhaust
 V8-454 (LS6) Cu.In.5197 Inlet & Exhaust

VALVE TRAIN

Type Individually mounted
 overhead rocker arms, push rod actuated
 Lifters Hydraulic
 V8-350 (LT1) Cu.In. Mechanical
 V8-454 (LS6) Cu.In. Mechanical
 Push Rods
 Type Hollow steel
 Ends
 V8-350 (Base) Hardened
 V8-350 (LT1) Cu.In. Hardened
 steel insert on rocker arm ends
 V8-454 Cu.In. Hardened steel inserts
 Rocker Arms
 Material Stamped steel
 Ratio
 V8-350 Cu.In. 1.50:1
 V8-454 Cu.In. 1.70:1


VALVE SPRINGS

Diameter (I.D.)
 V8-350 Cu.In.868-.884
 V8-454 (LS5) Cu.In. 1.080-1.094
 V8-454 (LS6) Cu.In. 1.080-1.094
 Installed Length (lb. @ in.)
 Valves Closed
 V8-350 Cu.In. 76-84 @ 1.70
 V8-454 Cu.In.
 Outer spring 69-81 @ 1.88
 Inner spring 26-34 @ 1.78
 Valves Opened
 V8-350 Cu.In. 194-206 @ 1.25
 V8-454 Cu.In.
 Outer spring 228-252 @ 1.38
 Inner spring 81-99 @ 1.28
 Free Length
 V8-350 Cu.In. 2.03
 V8-454 Cu.In.
 Outer spring 2.12
 Inner spring 2.06
 Valve Spring Damper
 V8-350 Cu.In. Flat steel, 4 coils

PRINCIPAL COMPONENTS

VALVES - INLET


Material	Alloy steel
Coating	
V8-350 Cu.In.	None
V8-454 Cu.In.	Face and head aluminized
Valve Guide Inserts (V8-454)	Cast alloy iron



A - Stem Diameter	
V8-350 Cu.In.	3.410-3.417
V8-454 Cu.In.	.3715-.3722
B - Overall Length	
V8-350 Cu.In.	4.870-4.889
V8-454 (LS5) Cu.In.	5.215-5.235
V8-454 (LS6) Cu.In.	5.204-5.224
C - Gage Length	
V8-350 Cu.In.	4.785-4.795
V8-454 Cu.In.	5.115-5.125
D - Overall Head Diameter	
V8-350 Cu.In. (Base)	1.935-1.945
V8-350 (LT1) Cu.In.	2.017-2.023
V8-454 (LS5) Cu.In.	2.060-2.070
V8-454 (LS6) Cu.In.	2.185-2.195
E - Angle of Face	45°
F - Guide Diameter	
V8-350 Cu.In.	.3427-.3437
V8-454 Cu.In.	.3732-.3742
G - Angle of Seat	46°
H - Valve Angle	
V8-350 Cu.In.	23°
V8-454 Cu.In.	4°
I - Valve Seat (Cutter) Diameter	
V8-350 Cu.In. (Base)	1.990-2.010
V8-350 (LT1) Cu.In.	2.080
V8-454 (LS5) Cu.In.	2.150
V8-454 (LS6) Cu.In.	2.228

VALVE - EXHAUST

Material	High alloy steel
Coating	
V8-350 Cu.In.	Aluminum face
V8-454 Cu.In.	Face and head aluminized
Valve Guide Inserts (V8-454)	Cast alloy iron



A - Stem Diameter	
V8-350 Cu.In.	.3410-.3417
V8-454 Cu.In.	.3713-.3720
B - Overall Length	
V8-350 Cu.In. (Base)	4.913-4.933
V8-350 (LT1) Cu.In.	4.891-4.910
V8-454 Cu.In.	5.345-5.365
C - Gage Length	
V8-350 Cu.In.	4.781-4.791
V8-454 Cu.In.	5.235-5.245
D - Overall Head Diameter	
V8-350 Cu.In. (base)	1.495-1.505
V8-350 (LT1) Cu.In.	1.595-1.605
V8-454 (LS5) Cu.In.	1.715-1.725
V8-454 (LS6) Cu.In.	1.875-1.885
E - Angle of Face	45°
F - Guide Diameter	
V8-350 Cu.In.	.3427-.3437
V8-454 Cu.In.	.3732-.3742
G - Angle of Seat	46°
H - Valve Angle	
V8-350 Cu.In.	23°
V8-454 Cu.In.	4°
I - Valve Seat (Cutter) Diameter	
V8-350 Cu.In. (Base)	1.550-1.570
V8-350 (LT1) Cu.In.	1.600
V8-454 (LS5) Cu.In.	1.625
V8-454 (LS6)-Insert	1.942

PRINCIPAL COMPONENTS

PISTONS

Material	
V8-350 Cu.In. (Base)	Cast aluminum alloy
V8-350 (L46) Cu.In.	Alum. impact extruded
V8-454 (LS5) Cu.In.	Cast aluminum alloy
V8-454 (LS6) Cu.In.	Alum. impact extruded
Head Type	
V8-350 Cu.In. (Base)	Sump
V8-350 (LT1) Cu.In.	Flat, notched
V8-454 (LS5) Cu.In.	Flat head, valve cutout
V8-454 (LS6) Cu.In.	Domed head, notched
Skirt Type	
Slipper	
Top Land Clearance	
V8-350 Cu.In. (Base)	.0235-.0325
V8-350 (LT1) Cu.In.	.0305-.0395
V8-454 (LS5) Cu.In.	.0350-.0410
V8-454 (LS6) Cu.In.	.0320-.0380
Skirt Clearance	
V8-350 Cu.In. (Base)	.0007-.0013
V8-350 (LT1) Cu.In.	.0036-.0046
V8-454 (LS5) Cu.In.	.0024-.0034
V8-454 (LS6) Cu.In.	.0040-.0050
Compression Ring Groove Depth	
V8-350 Cu.In.	.2218-.2284
V8-454 (LS5) Cu.In.	.2348-.2412
V8-454 (LS6) Cu.In.	.2375-.2435
Oil Ring Groove Depth	
V8-350 Cu.In.	.2038-.2103
V8-454 (LS5) Cu.In.	.2183-.2247
V8-454 (LS6) Cu.In.	.2160-.2170
Pin Bore Offset	
V8-350 Cu.In. (Base)	.055-.065
V8-350 (LT1) Cu.In.	On center
V8-454 (LS6) Cu.In.	On center
Compression Height	
V8-350 Cu.In. (Base)	1.558-1.562
V8-350 (LT1) Cu.In.	1.553-1.567
V8-454 (LS5) Cu.In.	1.691-1.699
V8-454 (LS6) Cu.In.	1.643-1.657

PISTON PINS

Material	
Chromium steel	
Length	
V8-350 Cu.In.	2.990-3.010
V8-454 Cu.In.	2.930-2.950
Diameter	
V8-350 Cu.In.	.9270-.9273
V8-454 Cu.In.	.9895-.9898
Clearance in Piston	
V8-350 Cu.In. (Base)	.00015-.00025
V8-350 (LT1) Cu.In.	.00045-.00055
V8-454 Cu.In.	.00030-.00040
Pin Mounting	
Locked in rod by shrink fit	

VALVE TIMING (Crankshaft Degrees)

	Excluding Ramps	Including Ramps
V8-350 Cu.In. - Base		
Inlet Valve (Zero lash)		
Opens - BTC	28°	38°
Closes - ABC	72°	92°
Duration	280°	310°
Exhaust Valve (Zero lash)		
Opens - BBC	78°	88°
Closes - ATC	30°	52°
Duration	288°	320°

	Excluding Ramps
V8-350 Cu.In. (LT1)	
Inlet Valve (opens with .020 lash)	
Opens - BTC	42°40'
Closes - ABC	94°20'
Duration	317°
Exhaust Valve (opens with .025 lash)	
Opens - BBC	112°50'
Closes - ATC	53°23'
Duration	346°13'

	Excluding Ramps
V8-454 Cu.In. (LS5)	
Inlet Valve (Zero lash)	
Opens - BTC	56°
Closes - ABC	114°
Duration	350°
Exhaust Valve (Zero lash)	
Opens - BBC	110°
Closes - ATC	62°
Duration	352°

	Excluding Ramps
V8-454 Cu.In. (LS6)	
Inlet Valve (opens with .024 lash)	
Opens - BTC	44°
Closes - ABC	92°
Duration	316°
Exhaust Valve (opens with .028 lash)	
Opens - BBC	86°
Closes - ATC	36°
Duration	302°

COMPRESSION RING – UPPER

Material	Cast alloy iron
Type	Straight edge inside of ring
Face	Barrel
Coating	
V8-350 Cu.In. (Base)	Chrome plate
V8-350 (LT1) Cu.In.	Molybdenum inlay
V8-454 Cu.In.	Molybdenum inlay
Width	
V8-350 Cu.In. (Base)	.0775–.0780
V8-350 (LT1) Cu.In.	.0770–.0775
V8-454 Cu.In.	.0770–.0775
Wall Thickness	
V8-350 Cu.In.	.190–.200
V8-454 Cu.In.	.202–.212
Gap	.010–.020

COMPRESSION RINGS – LOWER

Material	Cast alloy iron
Type	Inside bevel (top of ring 30 degrees to piston vertical axis for V8-350; 28° – 52° for V8-454)
Face	Tapered
Coating	
V8-350 Cu.In. (Base)	Wear resistant
V8-350 (LT1) Cu.In.	Chrome plate
V8-454 Cu.In.	Chrome plate
Width	
V8-350 Cu.In. (Base)	.0770–.0775
V8-350 (LT1) Cu.In.	.0775–.0780
V8-454 Cu.In.	.0770–.0775
Wall Thickness	
V8-350 Cu.In.	.190–.200
V8-454 Cu.In.	.202–.212
Gap	
V8-350 Cu.In. (Base)	.013–.025
V8-350 (LT1) Cu.In.	.013–.028
V8-454 Cu.In.	.010–.020

OIL CONTROL RINGS

Type	Multi-piece (two rails and one spacer)
Material	
Rails	Steel
Spacer	Alloy steel
Width (assembled)	
V8-350 Cu.In.	.1870–.1890
V8-454 Cu.In.	.1870–.1890
Wall Thickness	
V8-350 Cu.In.	.150–.156
V8-454 Cu.In.	.137–.143
Gap	
V8-350 Cu.In.	.015–.055
V8-454 Cu.In.	.010–.030
Rail Coatings	Chrome plated

CONNECTING RODS

Material	Drop forged steel
Length (center to center)	
V8-350 Cu.In.	5.695–5.705
V8-454 Cu.In.	6.130–6.140

CONNECTING ROD BEARINGS

Material	Premium aluminum
Type	Precision removable
Clearance	
V8-350 Cu.In.	.0013–.0035
V8-454 Cu.In.	.0009–.0025
Theoretical I.D.	
V8-350 Cu.In.	2.1019
V8-454 Cu.In.	2.2012
Effective Length	
V8-350 Cu.In.	.797
V8-454 Cu.In.	.847
End Play	
V8-350 Cu.In.	.008–.014
V8-454 Cu.In.	.015–.023

FUEL SYSTEM

FUEL SYSTEM

FUEL TANK

Capacity (Gal)	18 (approximately)
Location	In body cavity at rear of deck area
Filler Location	Center of rear deck area

FUEL FILTERS, DUAL

In Fuel Tank	Mesh strainer
Carburetor Inlet	Paper
V8-454 Cu.In. (addition)	In-line paper element with vacuum return fuel line

FUEL PUMP

Type	
V8-350 (Base) & 454 (LS1)	Deep cover with vapor return lines.
V8-350 (LT1) & 454 (LS6)	Diaphragm
Drive	Camshaft eccentric
Location	Lower right front of engine
Pressure Range (shut off pressure at 1800 RPM)	
All Engines	7.50-9.00 PSI at pump outlet

AIR CLEANER

Type	
V8-350 (Base) & 454 (LS5)	Dual snorkel chrome plated.
V8-350 (LT1) & 454 (LS6)	Full circle intake, chrome plated.
Filter Element	Oil-wetted paper

CHOKE

Type	Automatic
------	-----------

CARBURETORS

Make & Type	
V8-350 Cu.In. (Base)	Rochester, Quadrajet
V8-350 (LT1) Cu.In.	Holley, 4-barrel
V8-454 (LS5) Cu.In.	Rochester, Quadrajet
V8-454 (LS6) Cu.In.	Holley, 4-barrel
SAE Flange Size	1.50
Throttle Bore	
V8-350 Cu.In. (Base)	
Primary	1.38
Secondary	2.25
V8-350 (LT1) Cu.In.	
Primary & Secondary	1.69
V8-454 (LS5) Cu.In.	
Primary	1.38
Secondary	2.25
V8-454 (LS6) Cu.In.	
Primary & Secondary	1.69
Venturi	
V8-350 Cu.In. (Base)	
Primary	1.04
Secondary	.625
V8-350 (LT1) Cu.In.	
Primary	1.38
Secondary	1.44
V8-454 (LS5) Cu.In.	
Primary	1.04
Secondary	.625
V8-454 (LS6) Cu.In.	
Primary	1.38
Secondary	2.25
Secondary Throttle Actuation	By linkage approximately when primary valves are opened half between closed and open

EXHAUST AND VENTILATION SYSTEM

MUFFLERS

Type	Dual, reverse flow
Construction	Heads and body joined by rolled lock seam construction
Shell	
Right Hand	.036 stainless steel
Left Hand	.036 sheet steel aluminum coating
Wrap	.030 indented asbestos sheet
Cover	.018 sheet steel aluminum coating
Heads	.060 sheet steel aluminum coating
Baffles	3; .036 sheet steel aluminum coating
Length, Body	17.00
Width (I.D.)	9.25
Height (I.D.)	5.00

EXHAUST PIPES

Type	Two piece; front and rear assemblies
Material	Seamless steel tubing

DIMENSIONS - O.D. & WALL THICKNESS

Front Pipes	
V8-350 Cu.In. (Base)	2.00 x .067-.081
V8-350 (LT1) & 454 Cu.In.	2.50 x .072-.092
Rear Pipes - Laminated	
V8-350 Cu.In. (Base)	2.00 x .072-.092
V8-350 (LT1) & 454 Cu.In.	2.50 x .084-.104

TAIL PIPES

Type	Two inch tube with rectangular chrome plated extensions.
------	--

EXHAUST EMISSION CONTROLS

Positive Crankcase Ventilation	Utilizes manifold vacuum to draw off engine crankcase vapors through a metered PCV valve and ultimately to the intake system for engine reburn
Controlled Combustion System	(except RPO LT1 & LS6) Increases combustion efficiency through leaner carburetor adjustments and revises distributor calibration
Combination Emission Control Valve	Controls vacuum supply to the distributor vacuum spark advance and positions the carburetor throttle blade during vehicle deceleration.
Air Injection Reactor	(RPO LT1 & LS6) Air pump injects air into exhaust manifold which burns unburned portion of exhaust fumes.

LUBRICATION SYSTEM

GENERAL

Type	Controlled full pressure
Main Bearings	Pressure
Connecting Rods	Pressure
Piston Pins	Splash
Cylinder Walls	Pressure, jet cross sprayed
Camshaft Bearings	Pressure
Valve Lifters	Pressure
Rocker Arms	Pressure
Timing Gears	Centrifugally oiled from front camshaft bearing
Oil Pressure Sending Unit	Electric
Oil Filler	
Cap	Positive seal
Location	
V8-350 Cu.In.	Top rear of left rocker cover
V8-454 Cu.In.	Top center of right rocker cover

OIL PUMP

Type	Gear
Normal Oil Pressure	
V8-350 Cu.In.	40 PSI @ 2000 RPM
V8-454 Cu.In.	40 PSI @ 2000 RPM
Intake Type	Fixed
Capacity (GPM @ Eng. RPM)	
V8-350 Cu.In.	4.3 @ 2000
V8-454 Cu.In.	6 @ 2000
Regulator Valve	Opens between 40-45 lbs

OIL DIP STICK - LOCATION

V8-350 Cu.In.	Left side, rear of engine block
V8-454 Cu.In.	Right side, center, direct to oil pan

OIL PAN CAPACITY (Quarts)

Refill	
V8-350 Cu.In.	4.0
V8-454 Cu.In.	5.0
Refill with Filter Change	
V8-350 Cu.In.	4.5
V8-454 Cu.In.	5.5

OIL FILTER

Type	Full flow, throwaway canister
Location	Left rear underside of engine
Capacity	One pint
By-pass Valve	Opens between 9 to 11 PSI drop in pressure

LUBRICANT GRADES AND TEMPERATURES

20°F and Above	20W, 10W-30, 10W-40, 20W-40
0°F to 60°F	10W, 5W-30, 10W-30, 10W-40
Below 20°F	5W, 5W-30, 5W-30

OIL PAN

Type of Drain Plug	Hex head
Location	Lower rear face of oil pan sump
Size Hex Head	.860-.875
Thread	1/2-20 UNF 2A
Length	0.81
Diameter	.410-.430

COOLING SYSTEM

GENERAL

Type	Liquid, pressurized
V8-350 Cu.In.	Internal by-pass
V8-454 Cu.In.	External by-pass
Capacity (with Heater)	
V8-350 Cu.In. (Base)	15 Qts.
V8-350 (LT1) Cu.In.	18 Qts.
V8-454 (LS5) Cu.In.	22 Qts.
V8-454 (LS6) Cu.In.	20 Qts.

RADIATOR

Type	
V8-350 Cu.In. (Base)	Aluminum, cross-flow
V8-350 (LT1) & 454	Copper-brass, cross-flow
Core Constant and Thickness	
Distance between Fins	
V8-350 Cu.In. (Base)	.18 Syn.; .16 auto.
V8-350 (LT1) Cu.In.	.16
V8-454 Cu.In.	.16
Distance between Tubes	.55
Thickness of Core	
V8-350 Cu.In. (Base)	2.88 Syn.; 2.70 auto.
V8-350 (LT1) Cu.In.	2.70
V8-454 Cu.In.	2.70
Frontal Area (Sq.In.)	
V8-350 Cu.In. (Base)	315 Syn.; 441 auto.
V8-350 (LT1) Cu.In.	441
V8-454 Cu.In.	467

SURGE TANK (350 Cu.In. Base engine only)

Location	Right side engine compartment connected by hosing to top of radiator
Capacity	2.3 Qts.
Fill Requirements	Half full when weather is cold

RADIATOR CAP RELIEF VALVE

Opens at	Approximately 15 PSI
----------	----------------------

FAN

● Number of Blades	5, staggered
● Diameter	17.50
Fan Pulley Pitch Diameter	7.00
Fan Cutout	Thermomodulated fluid coupling

THERMOSTAT

Type	Pellet
Begins to Open at	
V8-350 (Base) & 454 (LS5)	192°-198°
V8-350 (LT1) & 454 (LS6)	177°-183°
Fully opened at	
V8-350 (Base) & 454 (LS5)	227°
V8-350 (LT1) & 454 (LS6)	202°
Thermostat By-Pass Hose (V8-454)	.745 I.D.

RADIATOR HOSE

Outlet, Lower (Radiator to Water Pump)	
V8-350 Cu.In.	1.75 I.D.
V8-454 Cu.In.	1.88 I.D.
Inlet, Upper (Thermostat Housing to Radiator)	
V8-350 Cu.In.	1.50 I.D.
V8-454 Cu.In.	1.50 I.D.

BELTS; CRANKSHAFT, FAN AND GENERATOR

Number Used	Two
Angle of "V"	38°-42°
Pitch Line	
Fan, Generator and Water Pump Belt	
V8-350 Cu.In. (Base)	54.25
V8-350 (LT1) Cu.In.	52.75
V8-454 Cu.In.	53.75
Fan and Water Pump Belt	
V8-350 Cu.In. (Base)	35.14
V8-350 (LT1) Cu.In.	32.46
V8-454 Cu.In.	31.86
Width	.380

WATER PUMP

Type	Centrifugal
Capacity (GPM @ Engine RPM)	
V8-350 Cu.In.	23 @ 2000
V8-454 Cu.In.	25 @ 2000
Bearing	Permanently lubricated double row ball
Drive	Fan belt
Ratio (Pump to Engine RPM)	.949:1

DRAIN LOCATIONS AND TYPE

Radiator	Left hand, rear lower face
Engine Block	Plug; right and left center

ELECTRICAL SYSTEM

SUPPLY SYSTEM

BATTERY

Type	Sealed side terminal
Voltage	12
Cranking Power @ 0° F	
V8-350 Cu.In.	3250 watts
V8-454 Cu.In.	3750 watts
Total number of plates	
V8-350 Cu.In.	78
V8-454 Cu.In.	90
Capacity (SAE) @ 20 hr. rate	
V8-350 Cu.In.	62 amp. hr.
V8-454 Cu.In.	80 amp. hr.
Number of Cells	6
Terminal Grounded	Negative
Location	In passenger compartment behind driver

GENERATOR

Type	Diode rectified with integral regulator
Rating	
Amps	42
Volts	10-15
Drive	By fan belt
Pulley Pitch Diameter	2.70
● Ratio (Gen to Engine Speed)	
V8-350 (base) & V8-454 (LS5)	2.53:1
V8-350 (LT1 & V8-454 (LS6)	2.15:1

REGULATOR

Type	Micro-circuit unit, integral with generator
Voltage Regulator	
Voltage	13.8-14.8 @ 85° F

STARTING SYSTEM

STARTING MOTOR

Rotation (Drive End View)	Clockwise
Test Conditions	Engine at operating temperature
No Load Test	
Amps	65-100 (350); 70-99 (454)
Volts	10.6
RPM	3600-5100 (350); 7800-12000 (454)
Motor Drive	
Engagement	Solenoid
Pinion Meshes at	Rear
Pinion Tooth No.	9
Flywheel Tooth No.	153; V8-454 - 168
Mounting	Bolted to clutch housing

IGNITION SYSTEM

DISTRIBUTORS	Refer to chart below
--------------	----------------------

COIL

Type	12 Volt
Amperes Drawn	
Engine Stopped	4.0
Engine Idling	1.8

SPARK PLUGS

Make & Type	
V8-350 Cu.In. (Base)	ACR44TS
V8-350 Cu.In. (RPO LT1)	ACR43TS
V8-454 Cu.In. (RPO LS5)	ACR43TS
● V8-454 Cu.In. (RPO LS6)	ACR44XL
Thread Size (mm)	14
Gap	.033-.038
Torque	25 lb. ft.

CABLE	Linen core impregnated with electrical conducting material and insulation of rubber with neoprene jacket
-------	--

DISTRIBUTORS	V8-350 270 HP	V8-454 365 HP	V8-350 330 HP	V8-454 425 HP	
	Manual & Automatic Transmission		Manual Transmission	Manual Transmission	Automatic Transmission
Model	1112050	1112051	1112038	1112076	1112053
Type	Single breaker		Transistorized Magnetic Pulse		
Cam Angle	29-31	28-30			
Breaker Gap	.019 (new)				
Breaker Arm Tension	19-23 oz.	28-32 oz.			
Centrifugal Advance Begins (RPM)	1335	1145	1330	1300	1310
Max Degrees @ RPM	18 @ 4200	22 @ 3000	24 @ 5000	31 @ 6000	28 @ 6000
Vacuum Advance Begins (In. Hg.)	8.00	8.00	8.00	7.00	
Max Degrees @ In. Hg.	15 @ 15.5	20 @ 17	15 @ 15.5	12 @ 12	
Timing (Initial Design Setting)	8 BTC @	8 BTC @	8 BTC	8 BTC	12 BTC
Crankshaft Degrees @ RPM (with vacuum spark line disconnected)	600 Manual 550 Automatic	600 Manual & Automatic	@ 700	@ 700	@ 700
Timing Mark Location	Torsional Damper				

CLUTCHES AND TRANSMISSIONS

● CLUTCHES

Engine	Type	V8-350 Cu.In.		V8-454 Cu.In.		
	Availability	Standard	RPO LT1	RPO LS5	RPO LS6	
Clutch for		4-Speed				
Type		Single dry disc centrifugal			Dual dry disc centrifugal	
Clutch cover & pressure plate	Eff. plate load, lbs.	2450-2750			1600-1800	
	Press. plate matl.	Nodular iron				
	Clutch spring type	Circular plate diaphragm, bent finger design				
	Clutch spring matl.	Heat treated spring steel				
Driven plate	Type	Single disc with two friction surfaces			Dual disc, alum. back facing	
	Cushions	Flat spring steel between friction rings				
	Dampers	10 coil springs (5 sets of two) each plate				
	Friction rings	OD	11.00			10.00
		ID	6.50			6.00
		Total area sq. in.	123.70			201.06
		Material	Woven type asbestos			
Flywheel	Flywheel	Material				Nodular iron
	Ring gear	Material				Heat treated HR steel
		No. of teeth				168
		PD				14.00
		Attachment				Shrink fit
Bearings	Release	Type				Single row ball
		Lubrication				None, prepacked
	Pilot	Type				Bronze bushing
		Lubrication				None, sintered and oil impregnated
Controls	Clutch fork		Drop forged steel, pivot mounted on ball			
	Pedal mounting		Pendant, from brace on dash			
	Lubrication		Crossover shaft			
Clutch housing material		Aluminum alloy				

4-SPEED TRANSMISSIONS

Transmission Type		4-Speed RPO M20		4-Speed RPO M21 & M22	
Engine	Type	V8-350 Cu.In.	V8-454 Cu.In.	V8-350 Cu.In.	V8-454 Cu.In.
Application	Availability	Base & LT1	LS5	LT1	LS5 & LS6
Case material		Aluminum			
Gear Shift	Type	Remote			
	Control	Lever			
	Location	Floor, mounted between seats			
Gears	Type	Helical			
	Material	Forged steel, hardened			
	Synchronization	All forward gears			
	Constant mesh gear	All forward gears			
	Sliding gears	Reverse			
	Ratios	First	2.52	2.20	
		Second	1.88	1.64	
		Third	1.46	1.27	
		Fourth	1.00	1.00	
		Reverse	2.59	2.26	
Lubricant	Type	Meeting Military Specification MIL-L-2105-B			
	Capacity (pts)	3			
Extension	Material	Aluminum			
	Oil Seal	Steel encased double seal of spring loaded rubber or felt			

TURBO HYDRA-MATIC

General Data	Type	Automatic hydraulic torque converter with compound planetary gear system - three forward speeds and reverse.	
	Selector lever	Location	Floor mounted
		Operation	Actuates controls by a hydraulic system from pressurized gear type pump
		Quadrant pattern	P-R-N-3-2-1
	Parking Lock	Type	Locking pawl
		Operation	Applied by selector lever through manual linkage
	Method of cooling	Water	
	Flywheel assembly	Steel stamping with welded on ring gear	
Hydraulic System	Oil pressure pump	Supplies hydraulic pressure from an engine driven gear type pump	
	Type	Steel spool	
	Valves	Manual	Establishes range of transmission operation
		Pressure Reg.	Controls main line pressure
		Shift (1-2)	Controls oil pressure for transmission shift from 1-2 or 2-1
		Shift (2-3)	Controls oil pressure for transmission shift from 2-3 or 3-2
	Modulator	Regulates line pressure with modulator oil pressure that varies with torque to transmission	
	Accumulator	To obtain greater flexibility in attaining desired shift curve for various engine requirements	
	Pressure @ Idle (a)	3	70
		2	150
		1	150
		Reverse	107.5
Converter Assembly	Pump (Drive member)	Multivane type, sheet metal blade spot welded to steel pump housing that is an integral part of the converter housing	
	Turbine (Driven member)	Steel axial flow blades assembled between inner & outer steel shells	
	Stator assembly	Aluminum multivane type blades mounted on a one way (overrunning) roller clutch	
	Stall ratio	2.10	
	Stall speed (RPM)	2110	
	Diameter (nominal)	12.20	
Planetary Gear Set	Reaction carrier assembly	4 steep pinion gears	
	Output carrier assembly	4 steel pinion gears	
	Front band	Circular steel with organic lining	
	Rear band	Double wrap circular steel	
	Range	D (2.48 1st)	2.48:1 - 1.48:1 - 1.00:1
		L2 (1.48 2nd)	2.48:1 - 1.48:1
		L1 (1.00 3rd)	2.48:1
		R (2.08 Reverse)	2.08:1
Case	Servo Unit	Piston with release spring and inner cushion spring	
	Material	Aluminum	
Clutches	Type	Three, multiple disk	
	Material	Drive plates	Steel with bonded organic facings
		Driven plates	Flat steel
	Forward Clutch	5 each drive & driven plates	
	Direct clutch	5 each drive & driven plates	
	Intermediate clutch	3 each drive & driven plates	
	Release spring	Radial row steel coil	
Torque Multiplication	Drive (maximum)	5.21:1 to 1.00	
	Low 2	5.21:1 to 1.48	
	Low 1	5.21:1 to 2.48	
	Reverse	4.37:1 to 2.08	
Governor	Type	Cross-axis centrifugal	
	Operation	Regulates a pressure proportional to car speed which acts upon the (1-2) (2-3) shift and modulator valves	
Lubricant	Type	A suffix A	
	Capacity (pints)	Dry	22
	Refill	8	

(1) 450 RPM input @ 25 in. Hg. vacuum

engines:	RPO number
330-hp Turbo-Fire 350; available only when 4-Speed wide-range or 4-Speed close-ratio transmission is ordered. Includes full-transistor ignition system	L71
365-hp Turbo-Jet 454; available only when 4-Speed wide-range, 4-Speed close-ratio or Turbo Hydra-matic transmission is ordered. Includes HD battery	L55
425-hp Turbo-Jet 454; available only when 4-Speed close-ratio, special 4-Speed close-ratio or Turbo Hydra-matic transmission is ordered. Includes HD battery	L57
Transmissions:	
Replacing standard 4-Speed wide-range transmission: Turbo Hydra-matic; available only when 270-, 365-, or 425-hp engine is ordered	M40
4-Speed close-ratio; available only when 330-hp, 365-hp, or 425-hp engine is ordered	M21
Special 4-Speed close-ratio; available only when 425-hp engine is ordered	M22
Axle ratio, rear: replacing standard positraction rear axle ratio	
Economy ratio	ZQ8
Performance ratio	ZQ9
3.70 ratio	YE1
4.11 ratio	YE2
4.56 ratio	YE3

Power Assists

description	RPO number
Brakes, power	J50
Steering, power: (power brakes recommended)	N40
Windows, power	A31

description	RPO number
Air conditioning, Four-Season: available only when 4-Speed wide-range or Turbo Hydra-matic transmission with standard or 365-hp engine is ordered	C60
Alarm system, audio	UA6
Battery, heavy-duty: included when 365- or 425-hp engine is ordered	T60
Belts, shoulder Custom Deluxe: Convertible model only	A85
Driver and passenger	
Defroster, rear window	C50
Radio equipment—includes 30" fixed height rear antenna	
AM/FM Radio	U69
AM/FM/Stereo Radio	U69/U79
Roof cover, vinyl: black; convertible model with auxiliary top only	C08
Steering wheel, tilt-telescopic	N37
Top, auxiliary: hard top; convertible model only. In addition to folding top	C07
Top, folding: manually operated. Convertible model only. All tops available with all exterior colors	
Black	BB
White	AA
Trim, Custom: includes leather seat trim, special cut pile carpeting, door trim panels with wood-grained accents and lower carpeting plus console with wood-grained accents	...
Wheel covers, Custom	P02

Factory Installed Regular Production Tubeless Tires

description	RPO number
Replaces (5) F70 x 15 special nylon blackwall	
(5) F70 x 15 special nylon white lettered blackwall	PU9
(5) F70 x 15 special nylon white stripe	PT7

1971 Corvette options