BRAKE SYSTEM

CONTENTS

DESCRIPTION	BR-	2	Inspection	}R-	4
BRAKE PEDAL	BR-	2	Reassembly	3R−	5
Removal	BR-	2	Reinstallation B	3R-	5
Inspection	BR-	2	BRAKE LINE	3R-	5
Reinstallation	BR-	2	PROPORTIONING VALVE B	3R∙	5
ADJUSTMENT	BR-	2	Operation	3R-	5
Adjusting brake pedal	BR-	2	Inspection E	3R-	8
MASTER CYLINDER	BR-	3	Removal and reinstallation E	3R-	8
Removal	BR-	4	BRAKE LINE PRESSURE DIFFERENTIAL		
Disassembly	BR-	4	WARNING LIGHT SWITCH	3R-	8




Fig. BR-1 Brake system

DESCRIRTION

The S30 series vehicles is installing disc brake for front, drum brake for rear, and a six inch master-vac, to get great braking force.

The front disc brake is Girling-Sumitomo model S-16, and the pad is operated with two pistons.

The leading-trailing type rear drum brake is equipped with auto-adjuster, and in order to get enough cooling effect, aluminum fined brake drums are used.

Moreover, the brake system is equipped with a proportioning valve to prevent skid due to early rear wheel locking.

The hand brake is of a mechanical type, which brakes rear wheels, and is operated by the control lever through linkage and wire.

The control lever is located in the seat side center, and is operated easily. The hand brake force satisfies the MVSS sufficiently, and it may also be used as an emergency brake.

BRAKE PEDAL

The brake pedal is installed on the bracket which also supports the steering column, and the bracket is secured on the dash panel together with the master cylinder. The stop lamp switch is installed on the pedal bracket, and is operated by pedal arm.




Fig. BR-2 Brake pedal mounting

Removal

- Remove the return spring ①.
- 2. Remove the clevis pin ② from the push rod, and separate the pedal from the master vac.

3. Remove the fulcrum pin (3) and remove the pedal.




Fig. BR-3 Brake pedal components

Inspection

Check the brake pedal for the following items, and correct or replace if required.

- 1. Pedal bushing and sleeve for wear, deformation, and/or damage.
- 2. Pedal arm for twisting, bending, and/or cracking.

Reinstallation


Install the brake pedal in reverse sequence of removal, noting following matters.

- 1. Be sure to fill the pedal shaft sleeve unit and clevis pin unit with multipurpose grease (MIL G-2108 or G-10924)sufficiently.
- 2. Be sure to tighten the fulcrum pin under tightening torque of 3.5 to 4.0 kg-m (25.3 to 28.9 ft-lb).

ADJUSTMENT

Adjusting brake pedal

- 1. Loosen the lock nut, turn the push rod clevis, and adjust push rod length properly so that height of pedal pad upper surface is 206 mm (8.11 in) with the pedal stopper non-effected.
- 2. Next, turn back the stopper, and depress the pedal so that pedal pad height is reduced from 206 mm (8.11 in) to 203 mm (7.99 in).



Note: Install the stop lamp switch so that the installation screw end surface is flush against the bracket.

Fig. BR-4 Adjusting brake pedal

MASTER CYLINDER

The brake system adopts a tandem type master cylinder. Even the front or rear hydraulic circuit falls into

a trouble, sufficient braking force can be obtained by another. For the front wheels, the disc brake is used, and thus, a large capacity reservoir is used.




Fig. BR-5 Master cylinder




Fig. BR-6 Cross-sectional view of master cylinder

Removal

- Disconnect the brake tubes from the master cylinder.
- 2. Remove the master cylinder installation nuts, and remove the master cylinder from the master vac.

Disassembly (Parts number refer to Figure BR-5)

- 1. Drain brake fluid, and remove stopper bolts (18) and (19).
- 2. Remove the snap ring ① , and remove the primary piston assembly, secondary piston assembly, and other parts.
- 3. Remove the valve cap screw \bigcirc , and remove the check valve.

Note: Disassemble the master cylinder carefully so that the sliding surface of the piston and piston cup are not damaged. Do not remove the fluid reservoir unless really necessary. Moreover, do not remove the piston cup unless the piston is replaced.

Inspection

Thoroughly clean all disassembled parts, check for wear, damage, and other defective conditions, and replace if necessary.

Note: Do not clean rubber parts with mineral oil since they are deteriorated. Use brake fluid or alcohol. When alcohol is used, however, do not immerse rubber parts under alcohol longer than 30 seconds. After the parts are cleaned, dry them with compressed air.

- 1. Check the cylinder and piston for damage and uneven wear on the sliding surface and for other defective conditions. Replace as required.
- 2. Replace, if the cylinder and piston clearance is more than 0.15 mm (0.006 in).

- 3. In principle replace the piston cup, packing and valves with new ones whenever the master cylinder is disassembled. Be sure to replace, if damaged, worn, weakened, or expanded.
- 4. Check the return springs for wear, damage and other defective conditions, and replace as required.

Primary side return spring: Standard values: (Free length × Installing load - Length)

5. Replace others, if deformed, damaged, or defective.

Reassembly

Assemble the master cylinder in reverse sequence of disassembly, noting the following matters.

Apply brake fluid to the component parts such as cylinder bore, piston, etc., and install carefully so as not to damage them. Moreover, for rubber parts such as piston cup, etc., apply rubber grease slightly.

Tightening torque

- Stopper screw
 0.4 to 0.5 kg-m (2.7 to 3.6 ft-lb)
- Valve cap 8 to 9 kg-m (5.8 to 6.5 ft-lb)

Reinstallation

Reinstall the master cylinder in reverse sequence of removal. After air bleeding, make sure that no brake fluid leaks from the circuit. For the pedal height adjustment, refer to the paragraph pedal adjustment.

BRAKE LINE

The brake lines branched from the tandem type master cylinder are extended to the front and rear wheels, forming independent hydraulic circuits. An indicator switch is equipped for trouble alarming in brake line. In addition, the rear wheel side circuit is equipped with the proportioning valve in front of the 3-way connector so as to protect the rear wheels from locking during rapid braking. The brake line is a galvanized double-layer steel tube.




Fig. BR-7 Brake line

Check the brake lines (tubes and hoses) for crack and/or damage, and replace, if defective. When brake fluid leaks from the joint, retighten or replace.

Pay attention on the following matters when installing brake lines.

- 1. Provide a sufficient space between the brake lines and other parts so that the brake lines are not interfered with other parts due to vibration during driving.
- 2. Be careful not to warp or twist the brake hose, and particularly be careful not to interfence the brake hose to tires and suspension components.
- 3. Do not tighten the brake line installation flare nut forcedly or excessively.
- 4. Upon completion of the brake line installation, be sure to bleed the air.

PROPORTIONING VALVE




Fig. BR-8 Cross-sectional view of proportioning valve




Fig. BR-9 Performance curve

Operation

1. When pressure is applied (under split point)

P₁; Master cylinder oil pressure

P₂; Rear wheel cylinder oil pressure

A1; Cross-sectional area of diameter D1

A2; Cross-sectional area of diameter D2

F; Spring and friction forces




Fig. BR-10 Plunger and seal operation when pressure is applied (under split point)

The plunger is depressed downward by force of $P_1 \times A_1$, passage of seal is opened until it overcomes spring

force F, and hence, oil pressure in the master cylinder side is balanced with that in the rear wheel cylinder side.

Consequently, oil pressure at the split point is expressed as follows:

$$P_s = F/A_1 \dots (2)$$

2. When pressure is applied (over split point)

When oil pressure rises to split point, the plunger lowers, and the circuit is sealed at "C" periphery. When oil pressure further rises, the plunger rises, the seal is released, the plunger finely rises and lowers so that pressures are balanced under the following equation, and thus, seal opening and closing are repeated.

$$P_2 \times A_2 = P_1(A_2 - A_1) + F$$
(3)

As the result, rear wheel cylinder side oil pressure rises in a ratio lower than that in the master cylinder side (reducing ratio).

Reducing ratio =
$$\frac{A_2 - A_1}{A_2}$$




Fig. BR-11 Plunger and seal operation when pressure is applied (over split point)

3. When releasing

When master cylinder side oil pressure is reduced, the plunger drops to contact the stopper [refer to Figure BR-12(a)] depressing oil seal down.

And keeping balance of equation (3) the wheel cylinder side pressure is reduced also. But on this situation the wheel cylinder side pressure drops no more.




Fig. BR-12(a) Plunger and seal operation when releasing

Further being reduced master cylinder side pressure lower than the rear wheel cylinder side, the seal drops some more [refer to Figure BR-12(b)], and keeping balance of equation (1) the wheel cylinder side pressure is reduced also.




Fig. BR-12(b) Plunger and seal operation when releasing

When pressure further drops down to the split point, the plunger is pushed up by spring force, the condition recovers to the original condition, and with the balance of equation (1) being maintained, oil pressure drops. (refer to Figure BR-10)

Inspection

Inspect the proportioning valve every two years or 50,000 km (30,000 miles) in accordance with the following instruction, and replace the valve as an assembly.

With the vehicle loaded with one person (driver), drive the vehicle on dry concrete road, and rapidly brake at vehicle speed of 50 km/h (31 MPH).

- 1. The proportioning valve is serviceable (normal) when front and rear wheels are locked simultaneously or front wheels are locked first.
- 2. Proportioning valve is faulty if the rear wheels are locked before the front wheels.

Removal and reinstallation

The proportioning valve can be removed easily by removing the installation bolts. When reinstalling, however, note the following matters:

1. Appearance of proportioning valve for S30 series is the same as 510, C30 series vehicles. However, the performance differs. Be careful not to mix up.

Note: Proportioning valve for S30 indicates the part No. E4100 on it by means of stamping.

2. When installing the brake line, be sure to face the mark "M" to the master vac side and "R" to the rear brake side.




Fig. BR-13 Proportioning valve

BRAKE LINE PRESSURE DIFFERENTIAL WARNING LIGHT SWITCH

A warning light is located on the instrument panel to warn the driver when a pressure difference of 13 to 17 kg-cm² (185 to 242 lb/sq in) exists between the front and rear brake systems.

A hydraulically actuated warning light switch is positioned in the engine compartment. Both front and rear brake systems are connected to this switch assembly.

When a pressure difference of 13 to 17 kg/cm² (185 to 242 lb/sq in) occurs between the front and rear brake systems, the valves will shuttle toward the side with the low pressure. The valve contacts with the switch terminal and the ground circuit for the warning light is completed, thus the warning light lights.

The hydraulic brake problem must then be corrected and bleed the brakes.

Check the warning light switch assembly for a proper operation. Check the switch assembly for fluid leakage.

DO NOT ATTEMPT TO REPAIR SWITCH FOR ANY REASON: REPLACE COMPLETE SWITCH ASSEMBLY.




Fig. BR-14 Sectional view of warning light switch

FRONT DISC BRAKE

CONTENTS

REPLACING PAD BR-10	Inspection BR-11
Removal BR-10	Reassembly BR-11
Inspection BR-10	Reinstallation 8R-12
Reinstallation BR-10	DISASSEMBLING CALIPERS BR-12
REPLACING PISTON SEAL BR-10	INSPECTING ROTOR BR-12
Removal	ADJUSTING FRONT BRAKE BR-12
Disassembly pp 11	

Girling-Sumitomo Model S-16 disc brake is used. Rigidity of the caliper is high, brake pedal feeling is adequate, and the pad dragging is minimized. The pad is returned by elasticity of the piston seal. When the pad is worn, the piston operating stroke increases, slipping

occurs on the piston seal surface, and thus, clearance is adjusted automatically.

Moreover, in order to prevent brake squealing, a shim is inserted behind the pad.




Fig. BR-15 Front disc brake




Fig. BR-16 Piston seal automatic adjusting operation

REPLACING PAD

Removal

- 1. Jack up the front side of the vehicle, and remove the wheel.
- 2. Remove the clip ①, retaining pin ②, and anti-squeal spring ③, and remove the pad ④ together with the shim.




Fig. BR-17 Removing pad

Inspection

- 1. Clean the pad with carbon tetrachloride or gasoline.
- 2. When oil and/or grease is heavily sticked on the pad, or when deteriorated or deformed due to overheating, replace the pad with a new one.
- 3. When thickness of the friction material is less than 2 mm (0.0315 in), replace. (Replace, when total pad thickness is less than 7.5 mm (0.2953 in).

Note: Recommend pads be replaced as a set. Replacement at only one position may cause uneven brake effect. Recommend rotation of pads be made periodically.

Reinstallation

Clean the calipers and piston pad installing parts.

Note: Do not use mineral oil. Be careful not to apply oil on the rotor.

2. Depress the piston into the cylinder so that new pad can be installed.

Note: Note that brake fluid may overflow from the reservoir. Recommend operation be carried out by loosening the breather to release brake fluid.

3. Install pad and anti-squeal shim, assemble the anti-squeal spring and retaining pin, and secure them with clip.

Note: Install the shim so that the arrow mark is met the rotor forward rotating direction.

4. When the pad is installed, depress the brake pedal several times so as to settle down the pad in its position.

REPLACING PISTON SEAL

If brake fluid leaks from the piston unit or pad does not return properly, replace the piston seal with new one in accordance with the following instructions. It should be noted that the components should be maintained under clean state while disassembling.

Removal

- Remove the pad.
- Disconnect the brake line ① and caliper installation

bolt 2, and remove the caliper assembly from the knuckle spindle.




Fig. BR-18 Removing calipers

Disassembly

- 1. Remove mud and dust from the caliper assembly before disassembly.
- 2. Remove the retaining ring ① and dust seal ② in that order. (Refer to Figure BR-15.)
- 3. Hold piston in one side with finger, feed air from the brake line joint, and remove the other piston.
- 4. Remove the piston seal from the cylinder, and clean inside.

Note: Remove the piston seal carefully with finger so that the cylinder wall is not damaged.




Fig. BR-19 Removing piston

Inspection

Thoroughly clean all disassembled parts, and check them for the following items.

Note: When cleaning rubber parts, use alcohol or brake fluid. If rubber parts are cleaned with mineral oil, they will be deteriorated.

1. Calipers

If the cylinder wall is damaged or worn, replace. If the cylinder wall is rusted or foreign matters are accumulated on the cylinder wall, carefully polish with fine emery paper so that the cylinder wall is not damaged. If rusted or roughened excessively, replace.

2. Pad

See paragraph covering replacement of pad.

3. Piston

Replace, if unevenly worn, damaged, and/or rusted.

Note: The piston sliding surface is plated. Thus, although rusted or foreign matters are sticked on the sliding surface, do not use emery paper.

4. Seals

Primarily, replace both piston and dust seals whenever overhauling.

Note: The piston seal affects not only leaking but also piston return. For this reason, replace although damage is minor.

Reassembly

1. Install the piston seal carefully so that the seal is not damaged.

Note: Be sure to apply rubber grease to the piston seal before installing.

2. Install dust seal on the piston, and the piston into the cylinder. Clamp the dust seal with the retaining ring.

Note: When inserting the piston, apply brake fluid to the piston sliding unit.

3. After reassembly is completely accomplished on one cylinder, assemble the another side in the same manner.

Reinstallation

Reinstallation is reverse sequence of removal. After the pad is installed completely, bleed the hydraulic line.

Tightening torque

Caliper attaching bolt 7.3 to 9.9 kg-m (53 to 71 ft-lb)

DISASSEMBLING CALIPERS

Do not remove the bridge bolt.

If brake fluid leaks from the bridge seal, replace a new assembly: (Be sure to replace the calipers as an assembly.)

INSPECTING ROTOR

Remove the caliper assembly, check the rotor for deflection and damage, and correct or replace as required.

1. Deflection

With the wheel bearing adjusted correctly, measure deflection at the center of rotor pad contact surface using dial gauge.




Fig. BR-20 Measuring deflection

Deflection

Total deflection:

Less than 0.15 mm (0.0059 in)

Usage limit 0.

0.2 mm (0.0079 in)

2. Parallelism

Measure thickness toward the entire periphery on the same circumference using a micrometer.




Fig. BR-21 Measuring parallelism

Parallelism (when new):

Less than 0.03 mm (0.0012 in)

Usage limit 0.07 mm (0.0028 in)

3. Thickness

If the rotor thickness in out of limit, replace. When correcting thickness, be sure that the thickness after correction does not exceed the limit.

Standard thickness:

12.5 mm (0.492 in)

Wear limit

10.5 mm (0.413 in)

ADJUSTING FRONT BRAKE

Ordinarily, adjustment is not required because clearance between pad and rotor is adjusted automatically by elasticity of the piston seal.

REAR BRAKE

CONTENTS

REPLACING BRAKE SHOE BR-14	Removal	16
Removal BR-14	Inspection	
Reinstallation	Reassembly and reinstallation BR-	
DISASSEMBLY AND INSPECTION BR-16	ADJUSTING REAR BRAKE BR-	-18




Fig. BR-22 Rear brake

The leading-trailing system rear brake adopts sliding system cylinder. When the hand brake is operated, the wheel cylinder lever turns the adjust wheel, and thus,

clearance between the brake shoe and brake drum is adjusted automatically.




Fig. BR-23 Sectional view of rear brake

REPLACING BRAKE SHOE

Removal

- 1. Jack up the vehicle, support it with a stand, and remove the tire.
- 2. Remove the brake drum. When it is hard to remove the brake drum, the following instructions apply.
- (1) Remove the clevis pin (indicated by arrow mark) from the wheel cylinder lever, and disconnect the hand brake wire.
- (2) Remove the brake drum adjust hole plug, and remove the adjust lever from the adjust wheel with a screwdriver.




Fig. BR-24 Removing hand brake wire

- (3) Turn the adjust wheel downward with a screwdriver, loosen the brake shoe, and remove the brake drum.
- 3. Remove the anti-rattling spring, and remove the brake shoe together with.




Fig. BR-25 Adjust wheel

Reinstallation

Before installing the brake shoe, check the wheel cylinder for operating and sliding condition, and disassemble and adjust it operation is faulty. For the details, see the paragraph covering disassembly. When replacing the brake shoe lining, be sure to match the new brake shoe lining with the mark on the brake shoe.

I. Apply brake grease to the adjust wheel, and threaded portion and sliding portion (indicated by arrow mark) of the adjust screw sufficiently.




Fig. BR-26 Adjust wheel

2. Apply brake grease to the brake disc, anchor block, and wheel cylinder sliding portions (indicated by arrow marks).




Fig. BR-27 Applying brake grease

3. Install the brake shoe, return spring, and anti-rattling spirng.

Note: Be careful not to allow grease sticking on the brake shoe lining.

- 4. Install the brake drum, insert a screwdriver from the adjust hole, turn the adjust wheel upward, and lightly apply the brake shoe to the brake drum.
- 5. Reconnect the hand brake wire to the wheel cylinder lever, pull the hand lever several times, and with the automatic adjusting operation, adjust the brake shoe and brake drum clearance.

Note: Cotinue the adjustment until click is eliminated from the adjust wheel claw.

6. Install the adjust hole plug. Depress the plug head in the center powerfully and make sure that the lip has been fitted completely.




Fig. BR-28 Adjust hole plug

DISASSEMBLY AND INSPECTION

Removal

1. Jack up the vehicle, and remove the tire, brake drum and brake shoe.

Note: For the details, refer to the paragraph covering the brake shoe replacement.

2. Remove the brake tube ① and dust cover ②, drive out the lock plate ③ toward the front, withdraw the adjust plate rearward, and remove the wheel cylinder.




Fig. BR-29 Removing wheel cylinder

- 3. Remove the anchor block installation nuts from reverse side of the brake disc, and remove the anchor block.
- 4. When removing the brake disc, withdraw the axle shaft, and remove the attaching bolts.




Fig. BR-30 Rear brake component parts

Disassemble wheel cylinder

Remove the snap ring and dust cover. Withdraw the piston, and remove the adjust wheel and adjust screw.




Fig. BR-31 Wheel cylinder component parts

Inspection

- 1. Inspect the wheel cylinder and piston in the same manner as for the master cylinder.
- 2. When the adjust wheel and/or adjust lever is damaged, replace.
- 3. Check the return spring for wear, damage, breakdown, etc., and replace as required.

Return spring

	Free length	Coating color
Cylinder side	122 mm (4.73 in)	Black
Anchor block side	120.4 mm (4.67 in)	Green

4. Replace the brake shoe lining if cracked, floated or unevenly worn. When the brake shoe lining surface is contaminated with grease, oil, etc., clean with carbon tetrachloride or gasoline. When excessively contaminated, replace. When thickness of the brake shoe lining is less

than 1.5 mm (0.0591 in), replace.

5. Check the brake drum, and repair or replace if unevenly worn, worn in step or other faulty condition exists.

Brake drum

Standard inner diameter: 228.6 mm (8.98 in)
Usage limit: 229.6 mm (9.04 in)
Out-of-round drum inner

diameter: 0.05 mm (0.002 in)

6. Replace brake disc and/or other parts, if defective.

Reassembly and reinstallation

The rear brake is reasembled and reinstalled in reverse sequence of disassembly and removal. However, note the following matters.

1. When assembling the wheel cylinder, be sure to apply rubber grease to the piston cup and other rubber parts slightly.

- 2. When installing the wheel cylinder to the brake disc, apply brake grease to the cylinder, disc, and adjust plate sliding surfaces and to the wheel cylinder lever fulcrum portion sufficiently so that the wheel cylinder slides smoothly.
- 3. Measure the wheel cylinder sliding resistance without installing the brake tube as shown in Figure BR-32, and make sure that the sliding resistance is in range from 2 to 7 kg (4.409 to 15.432 lb).

Note: When sliding is improper, the brake shoe does not return smoothly or the automatic adjuster does not operate correctly.

4. Tighten the anchor block installation nut under 1.4 to 1.8 kg-m (10.1 to 13.0 ft-lb) tightening torque.



Ordinarily, adjustment is not required because brake shoe clearance is adjusted automatically by operating the hand brake, as well as the front brake.




Fig. BR-32 Measuring sliding resistance

HAND BRAKE

CONTENTS

 Removal
 BR-19
 Reinstallation

 Inspection
 BR-20

**

The hand brake linkage is in the floor tonnel. Hence, removal and other operations must be done after re-

moving the propeller shaft.




Fig. BR-33 Hand brake linkage

Removal

- 1. Remove the lock nut and adjust nut ① from the rear end of the front rod, the clevis pin ② from the front end, and remove the front rod.
- 2. Remove the hanger spring and clevis pin (3).




Fig. BR-34 Removal of hand brake

3. Remove the clevis pin ⑤ and separate the rear cable from the lever.

Remove wheel side retainers 6 from both sides, and remove the equalizer side retainer in the same manner. The rear cable can be removed.




Fig. BR-35 Remvoing rear cable

4. Remove four bolts 4 (shown in the Figure BR-34), and remove the center arm assembly from the floor.

Note: The nuts are secured on the floor panel by means of welding.

5. Remove the front rod end and attaching bolt ①, and remove the control lever toward the passenger's compartment.

Note: When removing the control lever, first, remove the right side seat. The boot is secured with four fasteners (2).




Fig. BR-36 Removing control lever

Inspection

Check all parts for excessive wear and damage, and replace, if necessary.

Reinstallation

Reinstall the hand brake in reverse sequence of removal, noting the following matters.

- 1. Be sure to apply multi-purpose grease (MIL G2108 or G-10924) to the pivot on the control lever head and other sliding portions sufficiently.
- 2. When adjusting the hand brake, first, make sure that distance between the wheel cylinder lever pin hole center and buffer plate is in range from 11.5 to 12.5 mm (0.453 to 0.492 in), and reduce the linkage play with the adjust nut on the front rod.

Note: Be sure to perform this adjustment with the control lever returned.




Fig. BR-37 Adjusting hand brake

MASTER-VAC

CONTENTS

Inspecting vacuum pressure	BR-22	Disassembly,.	BR-23
Inspecting check valve	1 1 2 2 2 2 1 2 2 2 2 2 2 2 2 2 2 2 2 2	Inspection	
Removal	BR-23	Assembly and adjustment	BR-25
•	•	Reinstallation	BR-26




Fig. BR-38 Cross-sectional view of Master-Vac

Overhaul the Master-Vac every two years, replacing those rubber parts accompanied with single asterisk (*) every two years and those with double asterisks (**) and check valve every four years. The parts required in replacing are available as Master-Vac repair kit.

Note: Repair Kit A: Parts to be replaced every two years

Repair Kit B: Parts to be replaced every four years

(including the Kit A)




Fig. BR-39 Repair kit A




Fig. BR-40 Repair kit B

Inspecting vacuum pressure

I. Install a vacuum gauge between the check valve and Master-Vac.

2. Increase engine speed, and stop the engine when the vacuum gauge indicates 500 mmHg (19.7 in Hg).




Fig. BR-41 Installing vacuum gauge

(1) When 15 seconds are elapsed after stopping the engine without braking and pressure drops more than 25 mmHg (0.984 in Hg);

	Possible cause	Corrective action
1.	Faulty check valve air-tight	Replace.
2.	Faulty push rod seal air-tight	Replace.
3.	Faulty air-tight between valve body and seal	Repair or replace
4.	Faulty valve plunger seat air-tight	
5.	Damaged piping or faulty joint air-tight	Repair or replace. Repair or replace.

(2) When 15 seconds are elapsed after stopping the engine by applying full braking force, and pressure drops more than 25 mmHg (0.984 in Hg);

Possible cause		Corrective action
1.	Faulty check valve air-tight	Replace.
2.	Damaged diaphragm	Replace.
3.	Dropped off reaction disc	Reinstall and check the push rod for returning.
4.	Faulty air-tight on poppet assembly seat surface and valve body surface.	Repair or replace.

Note: When a replacement is required, be sure to replace the Master-Vac as an assembly.

Inspecting check valve

1. Remove the clip (indicated by arrow mark) and disconnect the hoses from both ends. The check valve can be removed.




Fig. BR-42 Removing check valve

- 2. Using a Master-Vac tester, apply vacuum pressure of 500 mmHg (19.7 in Hg) to Master-Vac side of the check valve. When pressure drops more than 10 mmHg (0.394 in Hg) within 15 seconds, replace the check valve with a new one.
- 3. When pressure is applied to the Master-Vac side of the check valve and the valve does not open, replace the check valve with a new one.

Note: When no Master-Vac tester is available, apply soap water to the Master-Vac side (to form soap water film), blow air from the engine side. If soap water film swells (being a soap bubble), replace the check valve with a new one. Subsequently, blow air from the Master-Vac side, and if the check valve does not open, replace.




Fig. BR-43 Cross-sectional view of check valve

Removal

- 1. Remove the clevis pin from the push rod connected with the brake pedal, and disengage the Master-Vac from the brake pedal.
- 2. Disconnect the brake tube from the master cylinder.
- 3. Disconnect the vacuum hose from the Master-Vac.
- 4. Unscrew master cylinder fixing nuts and remove the master cylinder from the Master-Vac.
- 5. Unscrew four fixing nuts of Master-Vac from the dash board and remove the Master-Vac.

Disassembly

Remove dust and mud from the Master-Vac, and disassemble it at a clean place.

- 1. Before disassembling the Master-Vac, put marks on the front shell, rear shell and stud assembly so that make sure their relative positions.
- 2. Secure the flange and bolt assembly in a vise.
- 3. Remove the clevis ①, lock nut ② and valve body guard ③.




Fig. BR-44 Removing rear shell

4. When separating the front shell from the rear shell use the Master-Vac wrench set (special tool ST08050000).

Push the rear shell and stud assembly down and slide them off by rotating them approximately 17 degrees counterclockwise. Note: When the valve body and diaphragm plate are detached together with the rear shell and stud assembly from the front shell, be careful not to drop them while disassembling the Master-Vac.




Fig. BR-45 Removing rear shell

- 5. Remove the push rod from the diaphragm plate.
- 6. Detach the valve body and diaphragm from the rear shell and stud assembly. Then the Master-Vac is disassembled in three subassemblies as shown below:

Rear shell & seal assembly Diaphragm plate assembly Front shell & stud assembly




Fig. BR-46 Removing valve body

7. Disassembly of rear shell and seal assembly. Remove the retainer using a screwdriver and detach the bearing and seal.




Fig. BR-47 Removing retainer

- 8. Disassembly of the diaphragm plate assembly. Work on a clean bench.
- (1) Pull out the diaphragm from the groove of the diaphragm plate.




Fig. BR-48 Pulling out diaphragm

(2) Remove the air silencer retainer by tapping the periphery with a screwdriver and a hammer lightly and evenly.




Fig. BR-49 Removing air silencer retainer

Note: Do not tap rapidly, or otherwise the valve body may be cracked.

- (3) Depress the valve operating rod, face the key hole downward, and give a vibration. The valve plunger stop key will come out.
- (4) After removing the valve plunger stop key, detach the valve operating rod assembly, and the air silencer filter from the valve body and diaphragm plate.




Fig. BR-50 Removing valve operating rod assembly

- (5) Push out the reaction disc from the valve body side.
- 9. Disassembly of the front shell and stud assembly.




Fig. BR-51 Removing flange

(1) Remove the nut ① and flange ② .

(2) Remove the plate and seal assembly.

Inspection

1. Check the poppet assembly.

If wear or abnormal conditions are found, replace it as the valve operating rod assembly.

2. Check components.

If abnormal conditions are found, replace them with new ones.

Assembly and adjustment

Assemble in reverse sequence of disassembly.

- 1. Apply silicon grease thinly to the following:
 - Seal: lip and face contacting with the rear shell and seal assembly.
 - Poppet: lip
 - Reaction disc: both faces
 - Diaphragm: edge contacting with front and rear shells
 - Plate and seal assembly: face contacting with the front shell and the push rod
 - Push rod: face contacting with the diaphragm plate

Note: Grease is contained in the repair kit.

2. Insert the valve operating rod assembly correctly and perpendicularly so that it is not tilted against the valve body. When inserting the stop key, depress the valve operating rod assembly.




Fig. BR-52 Inserting stop key

3. When installing the retainer on the rear shell, use the press fit tool (special tool ST08060000) and fit it completely down to such an extent that the tool flange surface comes into contact with the bottom.




Fig. BR-53 Fitting retainer

4. Upon completion of the assembly, adjust push rod end height so that depth from the flange surface to the push rod end is 3.5 to 4.0 mm (0.1377 to 0.1575 in).

Note: When adjusting the depth, face the push rod end upward so that the reaction disc is not dropped off into the master vac.




Fig. BR-54 Adjusting push rod length

Reinstallation

Reinstallation is reverse sequence of removal.

SERVICE JOURNAL OR BULLETIN REFERENCE

JOURNAL or BULLETIN No.	PAGE No.	SUBJECT

SERVICE DATA AND SPECIFICATIONS

Brake pedal	
Pedal free height	203 mm (8.05 in)
Full stroke of pedal head	140 mm (5.51 in)
Master cylinder	
Inner dia. of master cylinder	22.22 mm (7/8 in)
Allowable max. clearance between cylinder wall and piston	0.15 mm (0.0059 in)
Wheel cylinder	
Inner dia. of wheel cylinder	
Front	53.98 mm (2 1/8 in) 22.22 mm (7/8 in)
Allowable max. clearance between	0.15 mm (0.0059 in)
cylinder wall and piston Rear wheel cylinder sliding resistance	•
Brake drum and rotor Rear brake drum inner dia.	228.6 mm (9 in)
	271 mm (10.67 in)
Front brake rotor outer dia.	less than 0.05 mm (0.0020 in)
Drum inside out-of-round	·
Limit of reconditioning drum in dia.	229.6 mm (9.04 in)
Run out of the rotor	less than 0.15 mm (0.0059 in)
Limit of reconditioning rotor in thickness	10.5 mm (0.413 in)
Lining dimension	•
Rear (width × thickness × length)	$40 \times 4.1 \times 219.5 \text{ mm} (1.575 \times 0.161 \times 8.64 \text{ in})$
Material	B701
Pad (width x thickness x length)	$51.6 \times 10 \times 78.4 \text{ mm} (2.032 \times 0.394 \times 3.087 \text{ in})$
Pad material	M33S
Total braking area	
Front	161.6 cm ² (25.0 sq in)
Rear	351 cm ² (54.4 sq in)
Tightening torque	
Fulcrum pin of brake pedal	3.5 to 4.0 kg-m (25.3 to 28.9 ft-lb)

Connection of brake tube	1.5 to 1.8 kg-m (10.9 to 13.0 ft-lb)
Rotor fixing bolts	
Caliper to knuckle flange	7.3 to 9.9 kg-m (52.8 to 71.6 ft-lb)
Disc to bearing housing	2.7 to 3.7 kg-m (19.5 to 26.8 ft-lb)
Anchor block installation nut	1.4 to 1.8 kg-m (10.1 to 13.0 ft-lb)
Master cylinder stopper screw	0.4 to 0.5 kg-m (2.9 to 3.6 ft-lb)
Valve cap	8 to 9 kg-m (57.9 to 65.1 ft-lb)
Spindle nut	2.5 to 3.0 kg-m (18.1 to 21.7 ft-lb)

TROUBLE DIAGNOSES AND CORRECTIONS

Troubles	Possible causes	Corrective action
Locked brake pedal	Swollen master cylinder selas due to poor fluid quality or contamination by kerosene, gasoline or mineral oil.	Flush the system, replace all rubber parts refill with new fluid and air bleed the lines
	Pistons or valve carrier locked by deposits of fluid, foreign matter, etc.	Clean and bleed the system.
	Seized master cylinder piston due to infil- trations of water through rear end due to defective boot or seals.	Service the master cylinder, replace the piston and the boot and/or seals, to prevent water infiltration.
	Seized pedal shaft.	Unbined, smooth bushings, or if sliding parts are damaged to a remarkable extent, replace them and lubricate.
	Clogged transfer port.	Disassemble and clean master cylinder.
	No compensation takes place. Weak return spring.	Replace defective spring.

Spongy pedal	Air in brake system because of imperfect bleeding.	Bleed thoroughly.
	Swollen hose due to deterioration.	Replace the hose and bleed the system.
	Hose swells under fluid pressure due to poor hose quality.	Fit new hoses and bleed the system.
	Use of a poor quality brake fluid (boiling point of which is too low).	Replace the fluid with the specified brake fluid and bleed the system.
	Clogged reservoir filler cap vent hole. This promotes a vacuum in master cylinder that sucks air through rear seal.	Clean reservoir filler cap and bleed the system.
Pedal yields under slight pressure	Deteriorated check valve.	Fit a new check valve, make sure that there are no burrs, roughness or blow holes in master cylinder, and bleed the system.
	Fluid leaks through connection.	Tighten connections, and if necessary replace faulty parts. Bleed the system.
	Fluid leaks at wheel cylinders.	Replace the seals and packings being damaged. Wipe and clean brake shoe linings
	Fluid leaks through hoses.	Replace the damaged hose, and bleed the system.
	Low thuid level in reservoir.	Add specified fluid up to correct level.
Paor pedal reserve	Master cylinder relief port clogged foreign matter.	Clean and bleed the system.
	System has not been bled.	Bleed the system.
	Excessive clearance between shoes and drum.	Adjust auto-adjuster operation.
Excessive pedal reserve	Fluid level in reservoir is too low.	Top up with specified brake fluid, bleed the system, if required.
	Deteriorated rubber seals in master cylinder or in wheel cylinders.	Replace seals and bleed the system.
	Excessively swollen hoses due to poor hose quality.	Replace by designated hoses and bleed th system.
	Thermal expansion of drums due to excessive overheating.	Allow drums to cool off. Check brake sho linings and drums. Replace damaged parts
Brake locked after pedal return	Worn or broken return spring.	Replace defective springs.

CHASSIS Improper brake shoe return. Grease brake shoe and wheel cylinder sliding surface. Clogged master cylinder relief port. Clean and bleed the system. Swollen or stuck rubber seals due to con-Flush the system, replace all rubber parts, tamination by kerosene, mineral oil, refill with new brake fluid and bleed the gasoline, etc. system. Fluid leakage at one wheel cylinder only. Wipe, clean or replace the brake shoe linings Unbalanced brakes or lining pads, service the wheel cylinder and bleed the system. Rusted or corroded edges of a wheel Eliminate rust and replace the boots. cylinder. Seized piston in wheel cylinder or caliper Service the wheel cylinder, replace the rear assembly. wheel cylinder piston or caliper assembly and bleed the system. Hose obstructed due to swollen or clogged Replace or clean the hose and bleed the inner lining. system. Obstructed flow in metal pipe due to crush-Replace or clean the pipe and bleed the ing or clogging (if the brakes on one axle are system. excluded, weak braking may result). Faulty seals at one half caliper. Take down and strip the half caliper, replace seals and dust covers. Brake linings drag-Insufficient shoe-to-drum clearance. Adjust clearance. ging all the time on Weak shoe return springs. Replace the springs. drums or brake discs Brake pedal has no free travel. Set the push rod length as prescribed. Seized master cylinder piston. Service the master cylinder, replace the piston and bleed the system. Master cylinder flooded due to clogged relief Service the master cylinder, replace the port. check valve if deteriorated, clean the relief port and bleed the system. Brake disc run-out. Check brake disc for run-out, and replace defective parts, if necessary. Weak brakes Fluid leakage from wheel cylinders. Wipe and clean the brake shoe linings, service the wheel cylinder replacing damaged parts, and bleed the system. Fluid leakage from caliper cylinders. Take down and strip the calipers; replace all rubber seals and clean lining pads.

	BRAKE	
	Master-Vac	1
	This trouble mainly resulting from improper function of Master-Vac. Please check as follows:	
	Improper master vac function due to poor vacuum.	Check the pipe or hose connections, and fasten if necessary. Or replace a defective vacuum hose.
	Required vacuum is not maintained.	Wipe, clean or replace the check valve and check the grommet for loose fit, re-fit or replace it. Replace seal or retighten plate and seal assembly-to-front shell bolts. Clean or replace poppet rubber, Replace diaphragm and diaphragm plate.
	Weak pressure on shoes due to use of too thick fluid.	Flush the system and refill with specified fluid. Bleed the system.
	Dust on drums or linings soiled with oil.	Remove and clean drums thoroughly.
	Weak shoe return springs.	Check springs and replace as required.
	Drum out of round.	Correct drums by means of a lathe.

SERVICE JOURNAL OR BULLETIN REFERENCE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT

SERVICE JOURNAL OR BULLETIN REFERENCE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
-			
-			
			
	-		

SECTION WT WHEEL AND TIRE

DATSUN 240Z SPORTS
MODEL S30 SERIES
CHASSIS & BODY



NISSAN MOTOR CO., LTD. TOKYO, JAPAN



WHEEL AND TIRE	WT- 1	
TROUBLE DIAGNOSES	WT.	3

WHEEL AND TIRE

WHEEL AND TIRE

CONTENTS

DESCRIPTION	₩/T.1	Tire materials	
PERIODICAL SERVICES			
PERIODICAL SERVICES		INSPECTION	WT.
Inflation of tires	WT-1		
Radial tire		Wheel balance	
	VV 1 - Z	Wheel	W/T.3

DESCRIPTION

The disc wheel dimensions are $14 \times 4 \cdot 1/2$ J with 15 mm (0.59 in) wheel offset. The hub bolt hole pitch

diameter is 114.3 mm (4.5 in).

Tire size

Model	Tire size	Disc wheel
HLS30-U	175 SR-14 (Tubeless) 175 HR-14 (Tubeless) 6.45 H14-4PR (Tubeless)	14-4½J
HLS30 HS30-U	6.45 H14-4PR (Tubeless) 165 HR-14 (Tubeless) 6.95 H14-4PR (Tubeless)	14-4½J

Tire pressure (To be measure when tire are cold.)

	175 SR-14 175 HR-14 165 HR-14	6.45 H14 6.95 H14
Under 160 km/h (100 MPH)	2.0 kg/cm ² (28 lb/sq in)	1.7 kg/cm ² (2.4 lb/sq in)
Over 160 km/h (100 MPH)	2.3 kg/cm ² (32 lb/sq in)	2.3 kg/cm ² (32 lb/sq in)

PERIODICAL SERVICES

Inflation of tires

Tires with proper pressure improve riding comfort and steering stability, reduce driving sound to the minimum, and extend the service life.

The tires should be checked for proper pressure on monthly basis or more frequently depending on driving conditions, while the tires are cold. Ordinarily, tire pressure rises 10 to 15% of that when the tire is cold during continuous driving under a constant speed due to the tire tempreature rise. When measuring tire pressure accurately, first, find out whether the tire is hot or cold.

When tire valve caps are removed, be sure to reinstall

them on the valves without fail. The valve caps assist in keeping air in the tire in case of a valve leak, and keep dust and water out of the valves.

When inflation pressure is too high, the following troubles will result:

- 1. Hard ride
- 2. Bruised tire or damaged carcass immediately inside the tread
- 3. Poor traction at rear wheel resulting in uneven wear
- 4. Rapid tread wear at center of tire

When inflation pressure is too low, the following troubles will result:

- Tire squeal on turns
- Hard steering
- Rapid and uneven wear on tire tread edges
- 4. Bruised tire rim and various types of rupture
- 5. Tire cord fatigue or breakage
- 6. Tramp and shimmy troubles
- 7. Unusual tire temperature rise
- 8. Car roll while turning a corner or making a sharp swerve in traffic

Tighten wheel nuts to a torque of 8.0 to 9.0 kg-m (58 to 65 ft-lb).

Be sure to retighten wheel nuts after running 100 to 200 km (60 to 120 miles).

Radial tire

When comparing to the ordinary tires, camber power of a radial tire is lower and cornering power is higher, and consequently, toe-in increases excessively, causing unevenly worn tire and/or rapid tire wear. Thus, the front wheel alignment should be carried out carefully and correctly. (See Chapter FA.)

Characteristics of a radial tire differ from that of an

ordinary tire. Do not mingle radial tires with an ordinary tire or viceversa. When replacing a radial tire with an ordinary tire due to unavoidable reason, use ordinary tires for front tires.

Tire rotation

Service life of a tire is indicated by miles driven. The tires are provided with "tread wear indicator" [marks in six positions on the tire circumference, which indicate limit of 1.6 mm (0.06 in) tread depth]. When the tire is worn to the service life, the tread wear indicator appears. (In other words, when the indicator appears, the tire has reached its service life.) Generally speaking, service life of a tire is 40,000 km (24,000 miles).

When it is intended to use five tires including the spare tire evenly, conduct tire rotation in accordance with the tire shifting order shown in Figure WT-1 whenever the vehicle is driven 10,000 km (6,000 miles).




Fig. WT-1 Tire rotation

INSPECTION

Wheel balance

The permissible unbalance of wheel and tire assembly is 10 gr (0.35 oz) or less [190 gr-cm (2.64 in-oz) or less] at the rim circumference. In no event should a 100 gr (3.63 oz) or heavier balance weight be attached to the wheel. Balance weights are available from 10 gr to 100 gr (0.35 oz to 3.52 oz) with every 10 gr (0.35 oz) interval.

WHEEL AND TIRE

Wheel

When the wheel deflections toward vertical and horizontal axes at the points indicated by the asterisk (*) in Figure WT-2 are 1.0 mm (0.04 in) or more, replace the wheel.




Fig. WT-2 Wheel rim run-out check points

TROUBLE DIAGNOSES AND CORRECTIONS

Troubles	Possible causes	Corrective action
Wheel wobbls.	Improper tire pressure	Measure and adjust correctly.
	Damaged tire or distorted wheel rim	Repair or replace.
	Unbalanced wheel	Balance correctly.
•	Loose wheel nuts	Retighten.
	Worn or damaged wheel bearing, or excessive play of wheel bearing	Correct play or replace.
	Improper front wheel alignment	Adjust.
	Worn or damaged ball joint and link bushing	Replace.
	Excessive steering linkage play or worn steering linkage	Adjust or replace.
	Loose steering linkage connection	Retighten the nuts with the rated tightening torque, or replace worn parts if any.
	Broken suspension spring	Replace.
	Defective shock absorber	Replace.

Unevenly or excessively worn	Improper tire rotation	Conduct tire rotation periodically. [Standard: Every 10,000 km (6,000 miles)]
tire	Improper tire pressure	Measure and adjust correctly.
	Unbalanced wheel	Balance or replace.
	Improperly adjusted brake	Readjust correctly.
	Improper wheel alignment	Realign.
	Excessively distorted or improperly installed suspension link	Repair correctly or replace if necessary, or reinstall correctly.
	High speed on curves	Reduce speed.
	Sudden start and improper speeding due to rapid acceleration or improper brake application	Follow correct and proper driving manner.
Tire squeals	Improper tire pressure	Measure and adjust correctly.
	Improper front wheel alignment	Realign correctly.
W A	Distorted knuckle or suspension link	Repair or replace if necessary.

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			<u> </u>
			-
_			

WHEEL AND TIRE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT

ENGINE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			·
<u> </u>			
		1	
· ·			

SECTION ST STEERING

DATSUN 240Z SPORTS
MODEL S30 SERIES
CHASSIS & BODY



NISSAN MOTOR CO., LTD. TOKYO, JAPAN



STEERING SYSTEM	····ST- 1
TROUBLE DIAGNOSES AND CORRECTIONS	ST-16
SERVICE DATA AND SPECIFICATIONS	ST-20

STEERING SYSTEM

CONTENTS

DESCRIPTION	ST-1	RACK-AND-PINION AND	
MAINTENANCE	ST-2	SIDE ROD ASSEMBLY	ST- 7
STEERING WHEEL AND COLUMN	ST-3	Removal	ST- 7
Removal	ST-4	Disassembly	\$T- 8
Disassembly	ST-5	Inspection	ST-10
Inspection	ST-6	Assembly and adjustment	ST-11
Assembly and lubrication	ST-6	Installation	ST-15
Installation	ST-6		

DESCRIPTION

The steering assembly is a direct-acting rack-and-pinion type with a gear ratio 17.8:1, providing sharp, light, and accurate control under all conditions.

It consists of a rack bar and toothed pinion, both

working in the plain bearing of the housing. Backlash is held to 0 mm (0 in) by the retainer and the retainer spring.




Fig. ST-1 Steering gear components

The steering wheel is a cone type which exhibits excellent safety characteristics. Between the steering wheel and gear assembly, a rubber coupling is used to prevent the vibration from the road surface, insuring excellent handling and safety, and two universal joints are used between the gear assembly and steering wheel to give the most suitable steering wheel position and angle.

These joints require no lubrication and have an excellent service life.

The collapsible steering column is designed to compress under impact. When an automobile is being driven, the forward movement of the automobile and the forward movement of the driver both constitute a form of energy or force. When an automobile is involved in a head-on collision, the primary force (forward movement of the car) is suddenly halted, while the secondary force (the driver) continues in the forward direction. A severe collision generally involves these two forces primary and secondary. The secondary impact occurs when the driver is thrust forward onto the steering wheel and column.

The collapsible column is designed to absorb primary and secondary force to the extent that the severity of the secondary impact is reduced, thereby reducing the tendency to move rearward into the driver's compartment. A split second later when the driver is thrown forward (the secondary impact), this energy is also partially absorbed by compression characteristics of the column.

When the collapsible column is installed in a car, it is no more susceptible to damage than is an ordinary column; however, when the column is removed, special care must be taken in handling this assembly. When the column is removed from the car, such actions as a sharp blow on the end of the steering shaft or switch levers, leaning on the column assembly, or dropping of the assembly could bend the steering column jacket, especially the bellows part which absorbs the energy.

The gear housing is located in front of the front suspension, and a ball joint with excellent sealing and long durability (at 510 series side rod) is used on the knuckle arm end of steering linkage.

As mentioned above, this steering assembly has simple construction. Shim adjustment or selective assembly of

parts, essential in the case of conventional assemblies, is not necessary. Thus, servicing is very convenient and structural strength is more than adequate.

MAINTENANCE

All working parts are immersed in grease. A grease is provided to replenish the grease, enabling simple lubrication.

Due to better sealing and durability, the lubrication interval is two years or 40,000 km (24,000 miles). The grease used is a lithium base type having excellent waterproof characteristics.

Lithium base multipurpose NLGI No. 2 grease which has excellent waterproof characteristics is used for meshing portions of the rack-and-pinion, friction portions of the housing, and joined portions of the rack and side rod. Lubrication on the housing side is made through a grease nipple installed in place of the plug.

The amount of grease to be added is 10 to 15 gr (0.35 to 0.53 oz); do not use more as the dust cover or other parts will be deformed, adversely affecting the service life. After completion of lubrication, return the plug to its original position. A grease reservoir is located on the tube side, and contains lithium base multipurpose NLGI No. 0 grease. Replace the grease reservoir with grease when the level drops to one-third of the original amount. Lubrication at other than the specified period is unnecessary.

When a high-pressure grease gun is used, proceed cautiously to avoid forcing out grease from areas other than the outlet hole.

Note: The lubrication of the gear housing should be made according to following steps.

- a. Remove the rack-and-pinion assembly with lower joint and disassemble the rack-and-pinion.
- b. Thoroughly clean all parts of the assembly.
- c. Assemble the rack-and-pinion.
- d. Lubricate through the grease nipple.
- e. Install the rack-and-pinion assembly with lower joint.

				RECOM	MENDEI) LUBRI	CANTS			
Lub-	Make	TEXACO INC.	CHEVRON OIL CO.	CALTEX	MOBIL	SHELL	ESSO	BP	CASTROL	Lubricating points
Multi- purpose grease		·	RPM Multi- Motive Grease	Marfak All Purpose Grease Marfak Multi- Purpose Grease	Mobil Grease MP	Retinax A	Esso Multi- Purpose Grease	BP Ener- grease L2	Castro- lease LM	. Journal portion of steering column shaft . Pinion bearing . Retainer portion of pinion housing . Meshing portion of the rack-and-pinion . Sliding portion of the housing . Joined portion of the rack and side rod

STEERING WHEEL AND COLUMN




Fig. ST-2 Steering column assembly

Removal

1. Remove the horn button by pulling rearward. Remove the steering wheel after removing the steering wheel nut.




Fig. ST-3 Removing steering wheel

2. Remove upper and lower steering column shell covers by loosening six screws. Then loosen two screws retaining the turn signal and lighting switch assembly to steering column and remove the switch assembly.




Fig. ST-4 Removing shell cover

3. Disconnect the steering column assembly from lower joint shaft at the rubber coupling by removing two bolts.



Fig. ST-5 Rubber coupling bolt

4. Remove the steering post clamp by removing four bolts.




Fig. ST-6 Removing steering post clamp

5. Remove the four bolts securing the steering column grommet to the dashboard. The steering column assembly can then be removed into the room, remaining the lower steering shaft in the engine compartment.




Fig. ST-7 Removing column bracket bolts

Disassembly

1. To disconnect upper and lower steering columns separately, three screws placed back side of the steering post clamp have to be removed.

The clamp can be moved by lightly hitting with a wooden hammer.

2. Remove a snap ring and spacer ring at the upper end of the upper column, and extract the upper column shaft from the steering upper column jacket.




Fig. ST-8 Removing snap ring

- 3. Disconnect the rubber coupling from the steering lower joint.
- 4. Remove the snap ring and disassemble the steering lower joint.

Note: Do not disassemble the joint unless otherwise defects found.




Fig. ST-9 Steering lower joint components




Fig. ST-10 Components of steering column assembly

Inspection

Thoroughly clean and examine all parts of the assembly; components showing signs of wear, chipping, or damage must be replaced with new parts.

Steering column shaft spring

Note: a. If there is extraordinary damage on the steering column shaft or jacket, also check the inside of the steering gear housing.

b. A damaged bearing must be replaced along with the steering column jacket assembly.

Wire diameter	2.9 mm (0.1142 in)
Free length	36.5 mm (1.4370 in)
Coil turns	3
Load x length	30 kg (66 lb) x 18 mm (0.7087 in)
	26 mm dia. (1.024 in dia.)

Assembly and lubrication

Assembly is the reverse of disassembly. Observe the following points.

Note: When the lower steering shaft spline is fit the upper steering shaft spline, the slit of the universal joint must coincide with the punch mark located on the upper end of the upper steering shaft (See figure ST-11).




Fig. ST-11 Aligning slit with punch mark

- 1. When assembling, apply multipurpose NLGI No. 2 grease to the steering column shaft journal and also fill up in the dust cover.
- 2. When assembling the universal joint, apply multipurpose NLGI No. 2 grease to the needle bearing.

3. When fitting the needle bearing, use the tightest snap ring among the variations.

Snap ring oversize

T	hickness	
0.95 mm	(0.0374 in)	
1.05 mm	(0.0413 in)	
1.15 mm	(0.0453 in)	

Thrust play of journal: 0 to 0.15 mm (0 to 0.0059 in)

Installation

Installation is the reverse of removal.

Tightening torque

Steering wheel nut: 4 to 5 kg-m

(28.9 to 36.2 ft-lb)

Rubber coupling bolt: 1.5 to 1.8 kg-m

(10.8 to 13.0 ft-lb)

RACK-AND-PINION AND SIDE ROD ASSEMBLY




Fig. ST-12 Cross-section of rack-and-pinion with side rod assembly

Removal

- 1. Jack up the vehicle and support on stands. Remove front wheels.
- 2. Disconnect the steering lower joint from the steering column at the rubber coupling by removing two bolts.

Loosen the bolt securing the steering lower joint to the pinion, and then remove the lower joint assembly from engine compartment.




Fig. ST-13 Rubber coupling bolts

3. Remove the splash-board.




Fig. ST-14 Disconnecting lower joint from pinion

4. Remove the side rod ball stud nut and disconnect the side rod from the knuckle arm.




Fig. ST-15 Disconnecting side rod socket

5. Hoist the engine slightly.

Note: Be careful not to damage the accelerator linkage or drop off the control linkage.

6. Remove bolts securing the steering gear housing to the suspension member.




Fig. ST-16 Bolts securing housing to the suspension member

7. Remove the rack-and-pinion assembly.

Disassembly

- 1. Disconnect the steering lower joint from the rack-and-pinion assembly.
- 2. Clamp the rack-and-pinion assembly in a vise by using patches on the steering gear housing to avoid scarring.
- 3. Remove the dust cover clamp and boot clamp from the steering gear boot. (Both left and right.)




Fig. ST-17 Removing dust cover clamp

4. Loosen the stopper nut, remove the side rod inner socket, and disconnect the side rod assembly from the rack.




Fig. ST-18 Removing side rod assembly

- Withdraw the spring seat and side rod spring.
- 6. Detach the steering gear boots. (Both left and right hand.)
- 7. Loosen the side rod lock nut and disconnect the side rod outer socket assembly from the side rod ball.




Fig. ST-19 Removing side rod outer socket

8. Loosen the lock nut and remove the retainer adjust screw. And then take out steering gear retainer.




Fig. ST-20 Removing lock nut

9. Pry off the oil seal.




Fig. ST-21 Removing oil seal

10. Remove the snap ring and draw out the steering pinion assembly.




Fig. ST-22 Removing snap ring

11. Remove the snap ring and draw out the bearing from the pinion.




Fig. ST-23 Removing snap ring

12. Remove the filler plug and draw out the rack from the steering gear housing. Remove the grease reservoir.




Fig. ST-24 Rack-and pinion and side rod components

Inspection

Thoroughly clean all parts of the assembly.

Rack

Thoroughly examine all parts of the assembly; components showing signs of wear must be replaced with new parts.

Fractures, hollows, or roughness in the surfaces of the rack indicate unserviceability.

Pinion

Thoroughly examine all parts of the assembly: components showing signs of damage, cracking, or wear must be replaced with new parts. A damaged bearing or oil seal must be replaced.

Side rod ball and spring seat

Components showing signs of damage or wear must be

replaced with new parts.

Side rod ball joint

Measure the swinging torque and axial play. When values are not within the specified ranges, make replacement.

Side rod inner ball joint

Swinging torque: 0.

0.8 to 1.5 kg-m

(5.8 to 10.8 ft-lb)

Axial play:

0.06 mm (0.0024 in)

Side rod outer ball joint

Swinging torque:

0.8 to 1.5 kg-m

(5.8 to 10.8 ft-lb)

Axial play:

0.1 to 0.5 mm

(0.0039 to 0.0197 in)




Fig. ST-25 Measuring swinging torque




Fig. ST-26 Cross-section of ball stud

Bearing

When the bearing is injured, cracked or worn, make replacement.

Bushing

When the bushing is scarred, cracked, or worn, make replacement with the steering gear housing assembly.


Oil seal

As a rule, replacement is made during overhaul.

Spring

Specified values are shown below.

Retainer spring



Side rod spring

Wire diameter	2.6 mm (0.102 in)
Free length	19.0 mm (0.748 in)
Coil turns	6.3
Load x length	40 kg (88 lb) × 17.0 mm (0.669 in)
	19 mm (0.748 in) —

Assembly and adjustment

1. Press the bearing onto the pinion gear.




Fig. ST-27 Pressing bearing

Fit the snap ring.

Note: Use the tightest snap ring among the variations.

Snap ring oversize

	Thickness
1.04 to 1.09 mm	(0.0409 to 0.0429 in)
1.09 to 1.14 mm	(0.0429 to 0.0449 in)
1.14 to 1.19 mm	(0.0449 to 0.0469 in)
1.19 to 1.24 mm	(0.0469 to 0.0488 in)
1.24 to 1.29 mm	(0.0488 to 0.0502 in)

- 3. Clamp the steering gear housing in a vise.
- 4. Evenly apply multiporpose NLGI No. 2 grease to teeth and friction surfaces of the rack, and lubricate the gear housing from the pinion housing side.
- 5. Make sure that the rack protrudes by the same amount from both ends of the housing [96 mm (3.800 in)] and that rack teeth are directed toward the pinion shaft.




Fig. ST-28 Measuring protruding portion of rack

- 6. Evenly apply multipurpose NLGI No. 2 grease to the pinion teeth, end bushing, and pinion bearing.
- 7. Mesh the teeth of the pinion to those of the rack, and insert the pinion without damaging the bushing.




Fig. ST-29 Inserting pinion

8. Make sure that the rack extends beyond the housing by equal amounts on the left and right, with the groove on the pinion serration part directed upward.




Fig. ST-30 Measuring protruding portion of rack

9. Fit the snap ring, holding the bearing outer race in place.




Fig. ST-31 Fitting snap ring

Note: Carefully fit the snap ring to the housing groove.

Use the tightest snap ring among the variations.

Snap ring oversize

	Thickness
1.55 to 1.60 mm	(0.0610 to 0.0630 in)
1.60 to 1.65 mm	(0.0630 to 0.0650 in)
1.65 to 1.70 mm	(0.0650 to 0.0669 in)
1.70 to 1.75 mm	(0.0669 to 0.0689 in)

10. Fit the oil seal.




Fig. ST-32 Fitting oil seal

11. Measure thrust play of the pinion.




Fig. ST-33 Measuring thrust play of the pinion

Thrust play of the pinion:

less than 0.09 mm (0.0035 in)

- 12. Apply an adequate amount of the multipurpose NLGI No. 2 grease to the retainer.
- 13. Insert the retainer and retainer spring into the retainer hole, and thread in the adjusting screw.




Fig. ST-34 Threading in adjust screw

14. Fully tighten the adjusting screw and back off 20 to 25 degrees. Lock this screw with the lock nut.




Fig. ST-35 Locking retainer lock nut

Retainer floating play: 0.09 mm (0.0035 in)

Lock nut tightening torque: 4 to 6 kg-m

(28.9 to 43.4 ft-lb)

15. After tightening the lock nut, cover liquid packing (Three Bond) around the lock nut at "A".




Fig. ST-36 Area to which liquid packing is covered

16. After assembly of the rack-and-pinion, measure the pinion torque, pinion angle, and preload of the ack. When these values are not correct, readjust.

Pinion rotation torque:

8 to 20 kg-cm

(7 to 17 in-lb)

Rack preload:

8 to 18 kg (17.6 to 39.7 lb)

Note: Rotate or slide smoothly over the entire range of the stroke.




Fig. ST-37 Measuring pinion rotation torque




Fig. ST-38 Measuring tack preload

- 17. Fit a dust cover clamp on each end of the housing.
- 18. Thread the stopper nut over the threaded portion of the rack.

- 19. Apply an adequate amount of grease to the ball joint friction portion of the side rod assembly.
- 20. Assemble the spring and ball seat, and fit the inner socket portion of the side rod assembly to the rack.

Note: Make sure that the boot is carefully positioned toward the ball stud end.

The side rod assembly for the left side has an L-mark. (No mark is used for the right side.)




Fig. ST-39 L-mark

21. Tighten the inner socket portion until the ball seat reaches the rack end, back off the inner socket 20 to 25 degrees, and lock with the stopper nut.




Fig. ST-40 Locking the stopper nut

Stopper nut tightening torque:

8 to 10 kg-m (57.8 to 72.3 ft-lb)

22. After assembly of the side rod, measure the swinging torque and axial play of the side rod assembly.




Fig. ST-41 Measuring swinging torque of side rod assembly

Side rod inner ball joint axial play

Side rod inner ball joint swinging torque: (at the side rod end)

3 to 6 kg

(6.6 to 13.2 lb)

23. Measure the rack stroke.




Fig. ST-42 Measuring rack stroke

Rack stroke:

60.7 mm (2.390 in)

24. Install a grease nipple at both ends of the rackand-pinion housing, and apply multipurpose NLGI No. 2 grease to each joint.




Fig. ST-43 Supplying the grease

Note: Lubrication of the rack ends is made so that a small quantity of new grease appears at the boot grease outlet hole, and lubrication of the pinion housing so that a small amount of grease appears between the rack and housing.

Do not apply excessive amounts of grease.

- 25. Remove the grease nipple and install the filler plug.
- 26. Fit the boot.
- 27. Fill the grease reservoir with multipurpose NLGI No. 0 grease, and attach the reservoir to the rack housing.
- 28. Adjust the side rod length. (Both left and right).




Fig. ST-44 Side rod

29. Fit the steering lower joint to the rack-and-pinion assembly and tighten the lower joint lower bolt.

Lower joint lower bolt: 4 to 5 kg-m (29 to 36 ft-lb)

Installation

Installation is the reverse of removal, taking care that the housing brakets are correctly positioned with the paint mark placed front.

TROUBLE DIAGNOSES AND CORRECTIONS

Troubles in the Front Axle and Front Suspension are discussed at this point, because they are generally asso-

ciated with steering troubles.

1. Vibration, shock, and shimmying of steering wheel

Vibration: Too much backlash of the steering gear, wear of linkage parts or the rubber coupling, and

vibration of front wheels are, in many cases, transmitted to the steering wheel. This is

very noticeable when traveling over rough roads.

Shock: When the front wheels are traveling over bumpy roads, shock is transmitted to the

steering wheel. This is also very much noticeable when traveling over rough roads.

Shimmying: This is abnormal vibration of the front suspension group and the entire steering linkage,

and occurs when a specific speed is attained.

Possible causes	Corrective action	
Improper tire pressure or insufficient tightening of wheel nuts.	Adjust or tighten.	
Difference in height of right and left tire treads.	Replace tires.	
Incorrect adjustment or wear of front wheel bearing.	Adjust or replace.	
Collapsing or twisting of front spring.	Replace.	
Incorrect wheel alignment.	Adjust.	
Incorrect adjustment of brakes (binding).	Adjust.	
Wear of rubber bushings for fitting transverse link and compression rod.	Replace.	
Deformation of steering linkage and suspension link.	Replace.	
Excessive clearance of side rod inner or outer ball joint.	Replace.	
Loose side rod lock nut.	Tighten more.	
Imbalance of vehicle level.	Correct the imbalance.	

2. Wandering of vehicle in one direction

When driving with hands off the steering wheel over a flat road, the car gently pulls to one side of the road.

Note: Defective rear suspension may also be the cause of this tendency. Refer to information concerning the rear suspension.

Possible causes	Corrective action
Improper tire pressure.	Adjust.
Imbalance and deformation of loadwheel.	Correct the imbalance or replace.
Uneven wear of tires and insufficient tightening.	Replace or tighten.
Faulty wheel alignment.	Adjust.
Wear of bushings for fitting transverse link and compression rod.	Replace.
Loose steering post clamp.	Retighten.
Wear of steering column bearing.	Replace steering column assembly.
Breakage or collapsing of steering column shaft spring.	Replace.
Loose rubber coupling bolts or wear of rubber coupling.	Retighten or replace.
Excessive serration play.	Replace.
Wear of lower joint journal.	Replace.
Insufficient tightening of steering gear housing.	Retighten.
Wear of suspension ball joint.	Replace.
Improper adjustment of retainer. (Too much backlash)	Adjust.
Malfunction of shock absorber (inside strut) or loose bolts.	Replace or tighten.
Imbalance of vehicle level.	Correct the imbalance.

3. Instability of vehicle

Possible causes	Corrective action		
Improper tire pressure.	Adjust.		
Wear of rubber bushings for fitting transverse link and compression rod.	Adjust.		
Incorrect wheel alignment.	Adjust.		
Wear and deformation of steering linkage and suspension link.	Replace.		

SERVICE DATA AND SPECIFICATIONS

SPECIFICATION

 Type
 Rack-and-pinion type

 Turns of steering wheel (lock to lock)
 2.7 m (8.9 ft)

 Steering gear ratio
 17.8 : 1

 Turning angle of front wheel - inside
 33° ± 30°

 - outside
 31° 42′ ± 30°

 Minimum turning radius
 4.8 m (16.0 ft)

 Rack stroke
 60.7 mm (2.390 in)

 Number of pinion teeth
 7

 Center distance between the rack-and-pinion
 15 mm (0.591 in)

 Lubrication period
 Two years or 40,000 km (24,000 miles)

SERVICE DATA

		
Steering column shaft spring	- Wire diameter	2.9 mm (0.1142 in)
	- Free length	36.5 mm (1.4370 in)
	- Coil turns	3
	- Load x length	25 kg (55 lb) x 18 mm (0.7087 in)
Retainer spring dimension	- Wire diameter	2.6 mm (0.102 in)
	- Free length	26.3 mm (1.035 in)
	- Coil turns	5.5
	- Load x length	20 kg (44 lb) × 16.3 mm (0.642 in)
Side rod spring dimension	- Wire diameter	2.6 mm (0.102 in)
	- Free length	19.0 mm (0.748 in)
	- Coil turns	6.3
	- Load x length	40 kg (88 lb) × 17.0 mm (0.669 in)
Side rod inner ball joint axial	play	0.06 mm (0.0024 in)
Side rod outer ball joint axial	play	0.1 to 0.5 mm (0.0039 to 0.0197 in)
Pinion thrust play		less than 0.3 mm (0.0118 in)
Retainer float play		
Rack stroke		
		, ,

STEERING				
Side rod inner ball joint swinging torque	0.8 to 1.5 kg-m (5.8 to 10.8 ft-lb)			
Side rod outer ball joint swinging torque	0.8 to 1.5 kg-m (5.8 to 10.8 ft-lb)			
Pinion rotation torque	8 to 20 kg-cm (7 to 17 in-lb)			
Rack preload	8 to 18 kg (17.6 to 39.7 lb)			
Steering wheel nut				
Rubber coupling bolt	1.5 to 1.8 kg m (10.8 to 13.0 ft.lh)			
Lower joint bolt				
Retainer lock nut	4 to 6 kg-m (28.9 to 43.4 ft-lb)			
Side rod inner socket stopper nut	8 to 10 kg-m (52.8 to 72.3 ft-lb)			
Side rod lock nut	9 kg-m (65.1 ft-lb)			
Side rod ball stud nut	5.5 to 7.6 kg-m (39.8 to 54.9 ft-lb)			

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			ı
<u> </u>			
,			
-			
<u></u>	<u> </u>		

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
	!		
	<u>-</u>		
			
			
			
	•		

SECTION FE

ENGINE CONTROL, FUEL & EXHAUST SYSTEM

DATSUN 240Z SPORTS MODEL S30 SERIES **CHASSIS & BODY**



NISSAN MOTOR CO., LTD. TOKYO, JAPAN

ENGINE CONTROL SYSTEMFE- 1 FUEL AND EXHAUST SYSTEM FE- 2

ENGINE CONTROL, FUEL & EXHAUST SYSTEM

ENGINE CONTROL SYSTEM

ACCELERATOR LINKAGE

Description

The accelerator linkage with the minimized weight has been constructed so that it is not affected by the engine vibration and operated smoothly.




Fig. FE-1 Accelerator pedal arm removal

Removal

- 1. Remove three screws from the accelerator pedal bracket.
- 2. Separate the accelerator rod from the pedal arm at the ball joint.
- 3. Remove two bolts from the torsion shaft support in the engine compartment and remove the accelerator linkage.

Reinstallation is carried out in reverse sequence of removal.

Adjustment




Fig. FE-2 Accelerator linkage setting

- 1. Properly adjust the screw on the ball joint No. 1 so that the dimension "L" is correctly aligned to 108 mm (4.25 in).
- 2. Adjust the screw on the ball joint No. 2 properly so that the length of the tension rod (length between both end ball joint centers) is correctly aligned to 182 mm (7.17 in).
- 3. Install the accelerator linkage on the vehicle, and readjust the tension rod length so that the throttle shaft of the carburetor is correctly positioned in "Fully Close"
- position. In this adjustment, the tension rod length adjusting range is 182 ± 6 mm $(7.17\pm0.2362 \text{ in})$ and the size "N" should be 148 mm (5.83 in). (The free height is adjusted automatically by the stopper shown in the Figure FE-2.)
- 4. Upon completion of the above adjustment, depress the accelerator pedal, and adjust the stopper bolt properly so that it comes into contact with the pedal when the throttle shaft is positioned in the "Fully Open" position. Now, turn the stopper bolt clockwise in one full turn and lock the stopper bolt with the lock nut.

FUEL AND EXHAUST SYSTEM

CONTENTS

EXHAUST SYSTEM FE-2	FUEL SYSTEM FE
Description FE-2	FUEL TANK FE
Removal	Description FE
Inspection FE-4	Removal FE
	FUEL LINE FE
	FUEL STRAINER FE

EXHAUST SYSTEM

Description




Fig. FE-3 Exhaust system

ENGINE CONTROL, FUEL & EXHAUST SYSTEM

The exhaust system consists of three units providing front tube, pre-muffler and center tube, and main muffler and tail pipe. As seen in the Figure FE-3, the exhaust system is mounted at the points "C", "D" and "E" and clamped at the points "B" and "D" with U-bolts.

Removal

1. Remove three front tube and exhaust manifold connecting bolts.



Fig. FE-4 Removing front tube

2. Remove the exhaust hanger strap (the point "E" shown in the Figure FE-3.).




Fig. FE-5 Removing exhaust hanger strap (point "E")

3. Remove the exhaust hanger strap (the point "D" shown in the Figure FE-3.).




Fig. FE-6 Removing exhaust hanger strap (point "D")

4. Remove the bolt (the point "C" shown in the Figure FE-3.) and dismount the exhaust system.




Fig. FE-7 Removing the bolt (point "C")

5. Remove the U-bolts (the points "B" and "D" shown in the Figure FE-3.), and separate the exhaust system into three sections.




Fig. FE-8 Removing U-bolt (point "B")

Inspection

- 1. Check the tube and muffler for deformation and damage, and replace as required.
- 2. Check the insulator rubber and mounting bracket for

crack and deformation, and replace as required.

3. Upon completion of the reinstallation, check the exhaust system for exhaust gas leaking and exhaust noise.

FUEL SYSTEM

FUEL TANK

Description




Fig. FE-9 Fuel tank (* for California, U.S.A.)

The fuel tank is installed beneath the rear floor with two bands, and approximately half of it is located beneath the spare tire housing. The fuel tank capacity is 60 liters (15.9 US gal).

The fuel inlet is in the filler lid located in the rear right side panel, and the filler cap is of a hermetic type. The bayonet type unit gauge is installed on the front surface of the tank. A reservoir as shown in the Figure FE-9 is provided so as to relief expansion and bubbles due to

heating. (for California, U.S.A.)

Removal

- 1. Remove the drain plug from the tank bottom, and drain fuel completely.
- 2. Disconnect the unit gauge cable, outlet tube and return tube hoses from the tank,

ENGINE CONTROL, FUEL & EXHAUST SYSTEM

3. Remove nuts from two tank securing bands, and slightly lower the tank.




Fig. FE-10 Fuel tank mounting

- 4. Disconnect three ventilation tubes (used to connect the reservoir to the tank) and filler hose from the tank, and dismount the tank.
- 5. Disconnect the breather tube and air supplier tube (used to connect the filler hose to the reservoir), remove three reservoir installation bolts, and remove the reservoir.

FUEL LINE

The fuel line between the fuel strainer and fuel tank is a molded single unit, and with this construction, fuel leaking is completely prevented. Moreover, the fuel line is provided with a fuel return pipe, and thus, vapor lock and similar phenomenon is prevented.

FUEL STRAINER

The fuel strainer is a Nylon cartridge type strainer which can be replaced easily. The replacement period is 40,000 km (24,000 miles).




Fig. FE-11 Fuel strainer

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			·
			,

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			
		,	
·			

SECTION BF

BODY

DATSUN 240Z SPORTS
MODEL S30 SERIES
CHASSIS & BODY



NISSAN MOTOR CO., LTD. TOKYO, JAPAN

BODY B	F٠	1	
FRONT END AND FRONT FENDER B	F-	4	
HOODB	F-	6	
WINDSHIELD GLASS BI	F-	7	
DOOR	F-1	0	_
TAIL GATE BI	F-2	0	
REAR PANEL FINISHER BI	F-2	3	•
INSTRUMENT PANEL BI	⁻ -2	5	
FLOOR CONSOLE BI	2	6	
SEAT BI	- 2	7	
INTERIOR TRIMS	: .)	g	



.

BODY

Description

The body adopts a unit construction system. With construction, the weight has been reduced to the minimum and rigidity and safety have been highly improved. In order to utilize the rider's compartment effectively, the fuel tank is located beneath the floor and

a spare tire is contained in the spare tire housing sunk below the floor level. Thus, flat floor space behind the seats is largely provided for luggages. In addition, the rear of the body is provided with a large tail gate.




Fig. BF-1 Body structure




Fig. BF-2 Outline of body

0




Fig. BF-3 Standard body dimensitons

FRONT END AND FRONT FENDER

CONTENTS

FRONT FENDER	BF-4	BUMPER	BF-8
		RADIATOR GRILL	
COWL TOP GRILL	BF-5		




Fig. BF-4 Removing front fender

FRONT FENDER

Removal

- 1. Remove the front bumper.
- 2. Disconnect the battery cable from the battery terminal, and remove the head lights and side flasher lamps.
- 3. Remove the inspection lid and cowl top grill.
- 4. Remove the front fender front assembly.
- 5. Remove the head light cases.

6. Remove the bolts and nuts used to clamp the fender.

COWL TOP GRILL

- 1. Remove the windshield wiper blades together with the arms.
- 2. Remove the set screws, and remove the cowl top grill toward the front.




Fig. BF-5 Removing cowl top grill

RADIATOR GRILL

1. Remove the front bumper, and remove the radiator grill installation screws.




Fig. BF-6 Removing radiator grill

2. Reinstall the radiator grill in reverse sequence of removal.

BUMPER




Fig. BF-7 Removing front bumper




Fig. BF-8 Removing rear bumper

HOOD

CONTENTS

Removal	BF-6	Removal	BF-7
HOOD LOCK		Adjustment	

The hood adopts a large size single sheet construction. The hood can be opened widely, and thus, the engine compartment can be inspected easily.




Fig. BF-9 Removing hood

Removal

- 1. Open the hood and remove bolts from both sides.
- 2. Hold the hood from both sides with two persons, and remove it.




Fig. BF-10 Removing hood torsion bar

HOOD LOCK




Fig. BF-11 Sctructural view of hood lock



Removal

- 1. Open the hood, and remove the hood lock male.
- 2. Remove the clamp from the hood lock bracket, and remove the ball caulked on the hood lock control cable from the lever of the hood lock female.
- 3. Remove the hood lock female and guide from the hood lock bracket.
- 4. Remove the hood lock control from the dash side.

Note: When removing the hood lock control only, the caulked clamp must be opened because the grommet is used commonly with the speedometer cable.




Fig. BF-12 Adjusting hood lock

Adjustment

- 1. When the dovetail of the hood lock male is not coincided with the guide hole, loosen and properly adjust the hood lock male installation bolt.
- 2. When the lock engagement is too shallow or too deep, adjust the dovetail height properly.

WINDSHIELD GLASS

CONTENTS

F	RONT WINDSHIELD GLASS	BF	8	SIDE WINDOW	BF	Ç
	Removal	BF-	8	TAIL GATE GLASS	BF 1	11
	Reinstallation	BE	Q			

FRONT WINDSHIELD GLASS




Fig. BF-13 Front windshield glass

Removal

- 1. Remove the rear view mirror.
- 2. Remove the instrument panel garnish.
- 3. Remove the windshield wiper blades together with the arms.
- 4. Remove the windshield moulding.

Note: Be careful not to deform the moulding.

- 5. Detach the adhesion in the windshield flange side by applying a spatula or ordinary [(-) headed] screw driver from the outside.
- 6. Depressing the weather strip toward outside, lightly tap and remove the windshield glass to the outside.



Fig. BF-14 Removing front windshield glass

Note: Recommend the windshield glass removing be started from the upper side portion.

Reinstallation

1. For the installation, use string and spatula shown in Figure BF-15.




Fig. BF-15 Tools for installation of windshield glass

- 2. Apply adhesive to the appropriate portions on the weather strip as shown in Figure BF-13, and apply the weather strip to the windshield glass.
- 3. Apply string into the groove of the weather strip.
- 4. Set the windshield glass to the windshield flange from the outside, put the string into the compartment side.

- Note: The operation should be carried out by two persons, one of them works at outside and the other works at inside.
- 5. Pull the string (a person working at inside) in such a manner that the weather strip correctly engages with the flange. At the same time, lightly tap the glass (a person working at outside) by hand and assist the person working at inside.

Note: When the weather strip is not fitted into the flange correctly but mounted on the flange, correctly fit the weather strip into the flange by the use of a spatula.

- 6. Tap the overall glass area lightly to settle the weather strip down on the flange evenly and tightly.
- 7. Apply adhesive to the entire periphery.
- 8. Install the windshield moulding.
- 9. Install the windshield wiper blades and arms.
- 10. Install the instrument panel garnish.
- 11. Install the rear view mirror.

SIDE WINDOW




Fig. BF-16 Structural view of side window

TAIL GATE GLASS

For the tail gate glass removal and installation, the instructions for windshield glass apply. However, sealing

agent is used in lieu of adhesive.




Fig. BF-17 Structural view of tail gate glass

DOOR

CONTENTS

DOOR	BF-11	Installation	BF-16
Removal	BF-11	DOOR OUTER MIRROR	BF-16
Reinstallation	BF-12	Removal	BF-16
Adjustment	BF-12	DOOR WINDOW REGULATOR AND	
DOOR LOCK STRIKER	BF-12	DOOR GLASS	BF-16
DOOR REGULATOR HANDLE	BF-13	Removal	BF-17
Removal	BF-13	Adjustment of door glass	BF-17
Reinstallation	BF-13	DOOR SASH	BF-18
DOOR LOCK INSIDE LEVER	BF-13	Removal ,	BF-18
DOOR ASSISTANT STRAP	BF-13	Reinstallation	BF-18
Removal	BF-13	DOOR LOCK	BF-19
DOOR TRIM	BF-14	Removal	BF-19
Removal	BF-15	Reinstallation	BF-20
DOOR SEALING SCREEN			

The door, eliminating front side glass ventilation window, adopts curved glass, obtaining wide rider compartment space. The door main unit is rigidly constructed, the outer panel is provided with two stiffeners, and thus, together with the highly rigid inside panel shape, the strength, rigidity, and safety of the rider compartment

0

are highly improved.

For both sides, one each block door lock is installed. The window glass regulator which supports the window glass is of an X-shape double arm type. The side handle is buried in the door, eliminating projection form the interior and improving the safety.

DOOR Front sash Rear glass run Sealing screen 7 Door glass 2 Door finish 3 Front glass run Assist strap (for 4 Sash assistant side only) Door panel 5 Arm rest (both sides)

Fig. BF-18 Structural view of door

Removal

The door may be removed with or without hinges installed on the door. Remove the door with the hinges installed on the door when adjustment is required later. The following instructions are for removal of door with the hinges installed on the door.

- 1. Disconnect the battery cable from the battery terminal.
- 2. Disconnect the horn relay from the dash sid (driver's seat side only).

- 3. Remove the hood lock control installation bracket (driver's seat side only).
- 4. Remove the dash side trim.
- 5. With the door opened fully, support the door by applying a stand beneath the door or by means of a jack so that the door is dropped down.

Note: Apply a piece of rag between the door and the stand or jack so as to protect the door panel from scarring.

6. Remove the door hinge installation bolts from the body side.



Fig. BF-19 Removing the door

Removing the door from the body

When removing the door without the hinges (the hinges are remained on the body), remove the door side installation bolts from the hinges and remove the door from the hinges.

Reinstallation

Reinstall the door in reverse sequence of removal.

Door hinge installation bolt tightening bolt 0.9 to 1.1 kg-m (6.5 to 8.0 ft-lb).

Note: a. Before installing the door, be sure to apply grease to the hinge link.

b. When the door squeaks during opening and

closing, oil to the hinge pin top.

Adjustment

1. When adjusting the door alignment, adjust the body side installation bolts on the hinge. The door side installation bolts on the hinges are not adjustable.

Adjusting stroke: 3 mm (0.1181 in) to upper, lower, forward and rearward




Fig. BF-20 Adjusting door hinge

DOOR LOCK STRIKER

- Adjust the door position when closed.
- 2. Adjust the door lock striker correctly so that the door can be closed lightly and securely.
- 3. Adjust the door lock striker position with three striker installation screws. A dovetail used to protect the door from lowering is tightened together with the striker. Adjust the dovetail also when adjusting the door lock striker.

Adjusting stroke: 3 mm (0.1181 in) to upper, lower, right and left directions




Fig. BF-21 Adjusting striker

DOOR REGULATOR HANDLE

Removal

1. Raising the door regulator handle forward, withdraw the pin.




Fig. BF-22 Removing door regulator handle

Note: Recommend the tool shown in the Figure BF-22 be made and used for this operation.

2. Remove the door handle from the door.

Reinstallation

Reinstall the door regulator handle in reverse sequence of removal.

Note: When installing the door regulator handle, make sure that the knob is faced forward with the side window glass completely closed.

DOOR LOCK INSIDE LEVER

1. Remove the cover, screw, and escutcheon in that sequence with an ordinary [(-) headed] screw driver.




Fig. BF-23 Removing cover

DOOR ASSISTANT STRAP

Removal

- 1. Raise the cover with an ordinary [(-) headed] screw driver.
- 2. Remove the installation screws with a cross-headed screw driver.
- 3. Remove the assistant strap.




Fig. BF-24 Removing assist strap cover

DOOR TRIM




Fig. BF-25 Removing door trim

Removal

- 1. Remove the inside handle, escutcheon, and regulator handle from the door.
- 2. Remove the arm test, assistant strap, and door lock knob from the door.
- 3. Insert an ordinary [(-) headed] screw driver between the door finish and door inner panel, and unhook the door finish clips from the door panel.
- 4. Raising the door finish, remove it.



Fig. BF-26 Removing door finish

DOOR SEALING SCREEN




Fig. BF-27 Installing door sealing screen

Installation

- 1. Apply adhesive to the panel, and stick the sealing screen on the panel.
- 2. Be careful not to choke the water drain hole on the inner panel.
- 3. Stick the sealing screen carefully and correctly so that the adhered surface is not wrinkled.

door finish and sealing screen.

- 2. Remove the door glass assembly. (For the details, refer to page BF-17.)
- 3. Loosen the nuts by applying tool from the opening on the door inner panel.
- 4. Remove the outer mirror.

DOOR OUTER MIRROR

Removal

1. Remove the door components up to extent of the

DOOR WINDOW REGULATOR AND DOOR GLASS




Fig. BF-28 Door window regulator and door glass

Removal

- 1. Remove the door components up to extent of the door sealing screen.
- 2. Remove the door outside moulding and glass bamper with an ordinary. [(-) headed] screw driver.
- 3. Raise the glass to the top, slide the front window sash downward, and remove it.




Fig. BF-29 Removing front door sash

- 4. Lower the window glass down to a half level, and remove the bottom channel from the regulator roller.
- 5. Raising the rear end of the glass slightly, remove it upward.
- 6. Remove the regulator assembly and glass guide channel.



Fig. BF-30 Removing door glass




Fig. BF-31 Removing door window regulator

Adjustment of door glass

1. Install the door outside moulding and glass bamper before adjusting the glass alignment.




Fig. BF-32 Adjusting door glass

2. Adjust the guide channel and front sash properly so that the window glass rises and lowers smoothly along the front sash.

3. Slide the window glass up and down, and make sure that the rear edge of glass is connected applied to the sash. If not, move the guide channel downward, secure it temporarily, and tighten completely after ensuring that

the window glass correctly engages with the sash. Adjust the front sash at the same time.

4. Be sure to install the front sash and in parallel.

DOOR SASH




Fig. BF-33 Removing door sash

Removal

- 1. Remove the door components up to extent of the door glass.
- 2. Remove both the front and rear sealing rubbers.
- 3. Remove the door sash.

Reinstallation

Install the door sash in reverse sequence of removal.

Note: The door sash can be adjusted slightly. Adjust as required.

()

DOOR LOCK

Removal





Fig. BF-34 Door lock mechanism

- 1. Remove the door components up to extent of the sealing screen.
- 2. Remove the door sash.
- 3. Remove the key cylinder rod from the key cylinder.
- 4. Remove the remote control rod from the lock main unit.
- 5. Remove the remote control side bell crank and inside lever installation screws, and remove the remote control mechanism from the opening on the inner panel.



1 Door sash 3 Inside lever 2 Door lock assembly

Fig. BF-35 Door without sealing screen




Fig. BF-36 Removing inside lever

6. Remove the door lock main unit installation screw, and removing the outside handle rod from the opening on

the door lock main unit, remove the lock main unit from the opening on the inside panel.

- 7. Remove the key cylinder installation plate clip, and remove the key cylinder.
- 8. Remove the nut from inside of the door, and remove the outside handle.

Reinstallation

Install the door lock in reverse sequence of removal.

Note: Be sure to screw the door knob lock into the rod after installing the door finish.

TAIL GATE

CONTENTS

Description	BF-20	Removing tail gate lock	BF-22
Removal	BF 22	Adjustment	BF-20

Description

The tail gate opened upward adopts a single-sheet construction, and thus, luggages can be loaded and unloaded conveniently.

The tail gate stay adopts a gas spring (filled with nitrogen gas) increasing the operating smoothness and improving the external appearance.

Note: The gas spring is filled with highly compressed nitrogen gas. Do not disassemble the tail gate stay.

In order to ease thy tail gate installation and removal, split type hinges are used. The hinges are secured with both side installation screws.

A push-button type tail gate lock has been adopted. Moreover, when the push-button is locked, the push-button can be depressed but not unlocked.






Fig. BF-37 Structural view of tail gate

Removal

1. Open the tail gate and remove the tail gate stay.

Note: Do not disassemble the tail gate stay because it adopts the high pressure gas spring.

- 2. Hold a piece of rag between the tail gate and roof, and securely support the tail gate.
- 3. Remove the hinge and tail gate installation screws.
- 4. Hold the tail gate from both sides (two persons are required), and remove it.




Fig. BF-38 Removing tail gate

Removing tail gate lock

- 1. Remove the lock from the tail gate.
- 2. Remove the trim, insert hand into the gate, remove the leaf clip, and remove the key cylinder.
- 3. Remove the license plate lamp, and remove the striker.
- 4. The down stopper and rubber bumper can be removed simply by loosening the installation screws.

Adjustment

Tail gate hinge

 Adjust the tail gate position at the section between the hinge and and body.




Fig. BF-39 Adjusting tail gate hinge

Tail gate lock

For the front and rear directions, adjust the tail gate lock at the lock proper, and for the upper and lower directions, at the striker. Moreover, the adjustable range toward the left and right sides is 5 mm (0.1969 in).




Fig. BF-40 Lock proper




Fig. BF-41 Striker

Down stopper

The down stopper is adjustable to the front and rear directions only. For the upper and lower directions, the adjustable range is 5 mm (0.1969 in).




Fig. BF-42 Down stopper

REAR PANEL FINISHER




Fig. BF-43 Rear panel finisher

The finisher is split into three pieces providing the center piece, left side piece, and right side piece. The bottom is secured with clip installed on the body side, and the top is secured with plastic rivets.

Removal

1. Remove the plastic rivet from the finisher.





Fig. BF-44 Removing plastic rivet



- 3. Pulling the finisher, remove it from the clip unit.
- 4. Tilt and withdraw the finisher, and remove it from the license plate unit.




Fig. BF-46 Removing rear panel finisher




Fig. BF-45 Fitting finisher clip




Fig. BF-47 Removing rear panel finisher

Note: Be careful not to scar the painted surface of the body with the finisher flange.

INSTRUMENT PANEL




Fig. BF-48 Removing instrument

Removal

1

- 1. Disconnect the battery cable from the battery terminal. [Either (+) or (-) terminal]
- 2. Remove the wiring harness
- (1) Disconnect the instrument harness from the engine compartment harness.
- (2) Disconnect the instrument harness from the turn signal switch.
- (3) Disconnect the instrument harness from the door switch, stop lamp switch, alarm buzzer, flasher unit, hazard flasher unit, horn relay, fuse block, and cigarette lighter.

3. Disconnect the speedometer cable from the speedometer.



Fig. BF-49 Removing instrument

- 4. Disconnect the heater control cable at the heater side.
- 5. Remove the steering wheel shell cover.
- 6. Remove the instrument garnish with a cross-headed screw driver.
- 7. Remove the floor console.
- 8. Remove the screws from the instrument panel top and bottom and both sides of the console unit, raise the instrument panel slightly, and remove it toward the rear.




Fig. BF-50 Removing instrument

FLOOR CONSOLE




Fig. BF-51 Removing floor console

- 1. The floor console is installed on the floor with screws.
- 2. Tighten the coin case with the floor console

installation screws together with the floor console.

3. Install the change lever dust cover by fitting it to the floor.

SEAT

CONTENTS

Removal	BF-30	SEAT BACK TILTING (Inclination)	BF-30
SEAT SLIDE	BF-30	SEAT ELEVATION	BF-30




Fig. BF-52 Structural view of seat

The bucket type separate seats completely hold driver and assistant even during a rapid cornering, and the seat back is a high seat back which combines the seat back and head rest.




Fig. BF-53 Removing and reinstalling seat

Removal

1. Loosen the seat installation nuts by inserting hand beneath the seat riser, and remove the seat.

Seat slide

Driver's Seat.....The total slide stroke is 180 mm (7.09 in) 100 mm (3.93 in) is forward, 80 mm (3.15 in) is rearward, and the adjusting pitch is 20 mm (0.787 in).

Assistant Driver's Seat....The total slide stroke is 120 mm (4.72 in), 60 mm (2.362 in) is forward and rearward and the adjusting pitch is 20 mm (0.787 in).

The slide adjust levers are arranged in the body center side.

Seat back tilting (Inclination)

The total adjustable angle is 10° (5° each forward and rearward), the adjusting pitch is stepless, and the inclination can be adjusted without leaving the seat.

Seat elevation

Both seats can be adjusted 20 mm (0.787 in) each upward and downward. The seat elevation is adjusted with the spacer indicated in dotted line in Figure BF-53. When it is desired to raise the seat, place the spacer on the seat riser. Contrarily, when desired to lower the seat, remove the spacer.

Note: When spacers are used, be sure to apply same number of spacers to each seat riser.

INTERIOR TRIMS

CONTENTS

DASH SIDE TRIM	BF-29	FRONT FLOOR MAT AND INSULATOR	BF-30
Removal	BF-29	LUGGAGE BELTS	BF-30
DASH INSULATOR	BF-29	REAR FLOOR TRIMS	BF-30
DASH SIDE DRAIN HOSE	BF-29	INSIDE REAR VIEW MIRROR	BF-30
BODY SIDE TRIM	BF-29	BODY SEALING	BE-31

DASH SIDE TRIM

Removal

- 1. Remove the flasher unit installation screws.
- 2. Remove the horn relay installation screws.
- 3. Raise the trim dash side holding clip.
- 4. Remove the rubber grommet.
- 5. Remove the dash side trim.

DASH INSULATOR

The dash insulator has been adhered and connected with clips toward the entire area so that sound is insulated effectively. For this reason, the insulator can be removed only by peeling it off. When the insulator is removed once, replace it with new one.

DASH SIDE DRAIN HOSE

- 1. Remove the hose clamp.
- 2. Remove the grommet from the dash side.




Fig. BF-54 Dash side trim and drain hose



BODY SIDE TRIM

Except for the body side front trim, all trims are installed with plastic rivets.

The body side front trim is installed with clips.






Fig. BF-55 body side trim

FRONT FLOOR MAT AND INSULATOR





Fig. BF-56 Floor mat and insulator

- Melt and put insulator on the floor panel. 1.
- Adhere the front floor tonnel jute on the tonnel unit.
- Do not adhere the front and rear floor jutes on the 3. floor.
- Both front and rear floor mats are secured with fasteners.

LUGGAGE BELTS

1. Luggage belts used to secure luggages are installed on the rear floor with screws.



- Rear suspension strut
 - Luggage belt
- Rear floor mat
- Luggage stopper Seat riser trim

Fig BF-57 Rear floor trim and luggage belt

REAR FLOOR TRIMS

- Install the luggage stopper with self-tapping screws.
- Install the rear floor mat on the floor with fasteners.
- Install the seat riser trim with adhesive.
- Install the rear suspension strut cap by means of fitting.
- Install the luggage belts with machine screws.

INSIDE REAR VIEW MIRROR

Install the rear view mirror on the body through a drop-off system mechanism.




Fig. BF-58 Removing inside rear view mirror

BODY SEALING

Sealer is applied to the individual panel joints, and

thus, the body sealing is secured.




Fig. BF-59 Sealing body panel joint




Fig. BF-60 Sealing rear panel joint




Fig. BF-61 Sealing rear wheel housing



SERVICE JOURNAL OR BULLETIN REFERENCE

	IOLIDMAL or		
DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
		-	
<u></u>			
	-		
		<u> </u>	
	<u></u>		
,			
	 	-	
<u> </u>	 		
		<u> </u>	



SERVICE JOURNAL OR BULLETIN REFERENCE

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
		·	
		-	

BODY ELECTRICAL

SECTION BE

DATSUN 240Z SPORTS MODEL S30 SERIES CHASSIS & BODY



NISSAN MOTOR CO., LTD. TOKYO, JAPAN

WIRING	BE.	1
LAMPS	BE-	5
METERS	BE-	9
WINDSHIELD WIPER	BE-1	5
WINDSHIELD WASHER	BE-1	8
SWITCH	BE-1	9
HORN AND HORN RELAY	BE-2	2
RADIO	BE-2	4
	DE O	-



. (•

BODY ELECTRICAL

WIRING

CONTENTS

ENGINE COMPARTMENT HARNESS	BE-1	Wiring instructions	BE-3
Wiring instructions	BE-1	BODY HARNESS	BE-3
INSTRUMENT HARNESS	BF-2		

ENGINE COMPARTMENT HARNESS




Fig. BE-1 Engine compartment harness

Wiring instructions

- 1. Connect the engine compartment harness to the instrument harness at the bottom of instrument.
- 2. Through the dash panel, extend the harness to the radiator support in the engine compartment along the right side of the hood ledge.
- 3. Extend the harness to the left side of the body

through the cross member top in lower front side of the radiator.

4. Through the radiator support, connect the wire to the ignition coil along the left hand hood ledge.

For details, see the above shown figure.



INSTRUMENT HARNESS




Fig. BE-2 Instrument harness

BODY ELECTRICAL



BODY HARNESS





Fig. BE-3 Body harness

Wiring instructions

- 1. Connect the body harness to the instrument harness at the bottom of the instrument panel.
- 2. Extend the harness to the wheel housing along the right side floor edge.
- 3. Extend the harness to the tail lamps by passing it between the inner panel and outer panel.
- 4. Branch the harness at rear side of the rear pillar, and extend the branched harness to the room lamp through the rear pillar.
- 5. Branch the harness at bottom of the tail lamp, and penetrating through the rear floor, extend to the fuel tank unit gauge along the inside of the right hand side member.
- 6. For details, see the above shown figure.





LAMPS

CONTENTS

BULB SPECIFICATIONS	BE-5	SIDE MARKER REFLEX REFLECTOR	
HEAD LAMP	BE-6	(For U.S.A., Canada)	BE-7
FRONT PARKING/TURN SIGNAL LAMP	BE-7	REAR COMBINATION LAMPS	BE-8
LICENSE PLATE LAMP	BE-7	<u> </u>	

BULB SPECIFICATIONS

	Specification	Quantity	Color	Remarks
Head lamp unit	12V-50/40W	2	White	
Side clearance and turn signal lamp	12V-23W/7W	2	Amber	
Side marker lamp	12V-7.5W	4	Amber	Front side: 2 bulbs Rear side: 2 bulbs
License plate lamp	12V-7.5W	2	White	
Rear combination lamps				
Tail lamp	12V-7W	2	Red	
Stop (brake) lamp	12V-23W	2	Red	
Turn signal lamp	12V-23W	2	Amber	
Back up lamp	12V-23W	2	White	
Meter illuminating lamp	12V-3W	6	White	
Brake warning lamp	12V-3W	1	Red	
Turn signal pilot lamp	12V-3W	2	Green	Used also for hazard pilot lamp
Head lamp main (high) beam pilot lamp	12V-3W	l	Blue	
Hazard lamp	12V-23W	4	Amber	Used also for front and rear side clearance and turn signal lamp
Room lamp	12V-10W	1	Milky white	
Engine compartment inspection lamp	12V-8W	1	Milky white	
Glove box illumination lamp	12V-3W	ì	White	
Clock illumination lamp	12V-3W	1	White	





HEAD LAMP

1. Removing the head lamp:

Remove four screws from the inside of the wheel opening.




Fig. BE-4 Removing head lamp

2. Head light aiming adjustment and adjusting values (unladen condition)




Fig. BE-5 Adjusting head light aiming

Adjusting values

Dimensions/Angle	Values to which adjusted
Н	622.0 mm (24.5 in)
θ	45'
θ '	I ₀ 35,
L	47.5 m (155.5 ft)
r,	22.5 m (73.8 ft)
H'	130.9 mm (5.15 in)

FRONT PARKING / TURN SIGNAL LAMP

	Bulb	capacity	
Territory	Turn signal lamp	Parking lamp	Lens color
Ordinary	23W	7W	White
U.S.A. Canada	23W	7W	Amber

Replacing bulb:

Turn the socket from the rear side, and remove it.

LICENSE PLATE LAMP

Replacing the bulb:

Remove the lamp cover after removing three set screws.

SIDE MARKER REFLEX REFLECTOR

(For U.S.A., CANADA)

Front and rear 7.5W




Fig. BE-8 Front side marker lamp




Fig. BE-6 Replacing front parking/turn signal lamp




Fig. BE-7 License plate lamp installation




Fig. BE-9 Rear side marker lamp

REAR COMBINATION LAMPS

Specification

Rear combination lamp	Bulb capacity
Tail lamp	7 W
Stop lamp	23W
Turn signal lamp	23W
Back up lamp	23W



Remove the rear panel trim (secured with plastic rivets in eight places), replace the bulb from the rear side of the socket.

Replacing the rear combination lamp assembly

Remove the finisher from the outside of the body, remove eight rear combination lamp installation




Fig. BE-10 Rear combination lamp




Fig. BE-11 Replacing rear combination lamp bulb

screws, and remove the rear combination lamp assembly.




Fig. BE-12 Installing rear combination lamp assembly

METERS

CONTENTS

Removal	BE- 9	Removal	BE-11
Removal	BE-10	Oil Pressure Gauge and Others)	
OIL PRESSURE GAUGE	BE-10	TROUBLE DIAGNOSES AND CORRECTION	BE-13

SPEEDOMETER




Fig. BE-13 Speedometer




Fig. BE-14 Removing speedometer

Removal

Loosen the wing nuts on the meter brackets [] and 2 in Figure BE-14] on the upper and lower sides of the reverse side of the speedometer, and withdraw the speedometer from the instrument panel.

Note: a. When loosening the wing nuts, use a pair of pliers.

- b. In order to facilitate the operation, remove the heater air duct.
- c. See Figure BE-15 for details of the speedometer support bracket and mounting bracket.




Fig. BE-15 Details of speedometer installation brackets

TACHOMETER




Fig. BE-16 Tachometer

Yellow zone:

6,500 to 7,000 rpm

Red zone:

7,000 to 8,000 rpm

(Engine rpm: Indicated in range 0 to 8000 rpm)

Removal

Remove the tachometer in the same manner as for the speedometer.




Fig. BE-17

Note: See Figure BE-17 for details of the tachometer support bracket and mounting bracket.




Fig. BE-18 Details of tachometer installation brackets

WATER TEMPERATURE GAUGE OIL PRESSURE GAUGE

The water temperature gauge and oil pressure gauge are combined. The water temperature gauge indicates water temperature in range from 120 to 250°F, and oil pressure gauge indicates oil pressure in range from 0 to 140 lb/sq in. A voltage regulator (meter regulator) is built in the meter unit to compensate thermal effect.




Fig. BE-19 Water temperature gauge and oil pressure gauge

Removal

1. Remove the center console finisher.

2. Inserting hand into the opening where the center console finisher has been removed, loosen hexagonal cross-headed screws [1] and 2 in Figure BE-21] use pair of pliers, and remove the unit from the reverse side of the instrument panel.




Fig. BE-20 Removing center console finisher




Fig. BE-21 Removing water temperature gauge and oil pressure gauge

AMMETER AND FUEL GAUGE

The ammeter and fuel gauge are combined to a single unit. The ammeter indicates in range from -45 to +45A. "E" and "F" marks on the fuel gauge represent respectively "Empty" [5 liters (18.9 US gal, 122.7 Imp gal)] and "Full" [60 liters (227 US gal, 273 Imp gal)].




Fig. BE-22 Ammeter and fuel gauge

Removal

Remove the ammeter and fuel gauge unit in the same manner as for the oil pressure gauge and water temperature gauge. To be more specifically, when removing the ammeter and fuel gauge unit, remove the meter bracket, and remove hexagonal cross-headed screws [1] and 2 in Figure BE-23 from reverse side of the meter.




Fig. BE-23 Removing ammeter and fuel gauge

INSTRUMENT UNIT CIRCUIT DIAGRAM

(Speedometer, Tachometer, Ammeter, Oil Pressure Gauge and Others)




Fig. BE-24 Circuit diagram of instrument unit

ILLUMINATION CONTROL

The illumination control is a variable resistor




Fig. BE-25 Circuit diagram of illumination control

(Rheostat) with which the meter illumination can be controlled (none step) to get proper brightness so that the meters can be seen clearly.




Fig. BE-26 Removing illumination control



TROUBLE DIAGNOSES AND CORRECTIONS

Speedometer

Troubles	Possible causes	Method of inspection	Corrective action
Both pointer and odometer do not	Faulty speedometer cable union nut tightening	Check the union nut for tightness.	Retighten the union nut.
operate.	Broken speedometer cable	Check the speedometer cable.	Replace the cable
	Damaged speedometer drive gear	Check the drive gear	Replace the drive gear and pinion assembly.
	Defective speedometer	Remove the speedometer unit, and check.	Replace the meter unit.
	Rusted cable	Make sure that the cable is rusted.	Replace the cable.
Pointer deflects excessively.	Improperly installed speed- ometer cable (bent excessively)	Check the cable for installing condition.	Correct bending radius to more than 100 mm (3.9 in).
	Broken speedometer cable	Check the cable for condition.	Replace the cable.
	Damaged speedometer drive gear	Check the drive gear.	Replace the drive gear, pinion assembly.
	Defective speedometer	Remove the speedometer unit, and check.	Check and replace if required.
Pointer unstable.	Improperly tightened speed- ometer union nut	Check the union nut for tightening condition.	Retighten or repair if required.
	Defective speedometer cable	Check the speedometer cable.	Replace cable.
	Damaged speedometer drive gear	Check the drive gear.	Replace speedometer unit.
	Defective speedometer	Remove and check the speed-ometer unit.	
Unusual noise	Excessively bent speedometer cable, lack of lubricant, or twisted speedometer cable.	Check the cable for excessive bending.	Replace the cable.
	Defective speedometer		Replace the meter.

Water temperature gauge

Even the switch is turned on, the pointer does not operate.	Blown off fuse	Check the fuse.	Replace if blown off.
	Defective thermal transmitter	Apply a test lamp (approximately 12V-3W) using DC12V in series to the lead wire yellow/white) which connected to the thermal transmitter, and ground another wire from the test lamp. Then pointer deflects.	Replace the thermal transmitter.
	Defective meter unit or faulty wiring	When above described inspection is conducted and the pointer still does not operate, remove the meter unit, connect the unit with a test lamp (12V-3W) in series, and apply DC12V. o If the pointer deflects; o If the pointer does not deflect;	Repair the wiring. Replace the meter unit.

Fuel gauge

When the source	Blown off fuse	Defective tank unit grounding	Replace if blown off.
switch is closed, the pointer does not operate.	Defective tank unit grounding	Apply a test lamp (12V-3W) using DC12V to the tank unit lead wire in series and ground the tank, then pointer deflects.	
	Defective meter unit or wiring	When above described inspection is conducted and the meter pointer does not deflect, remove the meter unit, apply a test lamp (12V-3W) to the unit in series, and apply DC12V.	-
		o The pointer deflects to "F". o The pointer does not deflect after repairing.	Correct the wiring. Replace the meter unit.
The pointer indicates a point constantly regardless of actual fuel level.	Defective tank unit	When the lead wire to the tank is disconnected at the tank unit terminal, the pointer returns to "E".	Replace tank unit.

 BODY E	LECTRICAL	
Defective meter unit or wiring	When the above described inspection is conducted and the pointer of the meter still does not deflect, remove the meter unit, apply a test lamp (12V-3W) to the unit in series, and apply DC12V. o The pointer deflects to "F". o The pointer does not deflect.	Correct the wiring. Replace the meter unit.

Ammeter

Main specifications

(45A) Voltage regulator/arternate	Improper indication	Lack of alternator capacity (45A)	Measure the alternator charging voltage	Repair the voltage regulator/alternator.
-----------------------------------	---------------------	-----------------------------------	---	--

WINDSHIELD WIPER

CONTENTS

Windshield wiper installing position BE-16

Moto	r perf	ormance .	BE-16 Windshield wiper motor connecting diagram BE-17
			1 Windshield wiper motor assembly 2 Auto-stop mechanism 3 Windshield wiper blade 4 Windshield wiper arm
			Power source) LW (Torelay) B (Ground)
co	LOR	CODE	L(Low)
L	:	Blue	
Υ	:	Yellow	LY (High)
В	:	Black	
R	:	Red	
W	:	White	
G	:	Green	

Fig. BE-27 Structure of windshield wiper

Main specifications

Wiping system		Parallel interlock sys	stem (tandem type)	Cross-sectional view of blade rubber:
Wiping angle		86° (Driver side)	96°(Assistant side)	₹ <u></u>
Rise-up angle		4º 30' (Driver side)	5°30' (Assistant side)	10.6 mm
Blade length		460 mm (18 in)		- (0 0200 in)
Arm installation m	ethod	Tapered serration		0.76 mm (0.0299 in)

Motor performance

Item .	Specification		
Rated voltage	12 V		
Test voltage	13.5	V	
Starting voltage	Less	than 8V	
Unloaded speed	LOW	HIGH	
Unloaded current	56 rpm	78 rpm	
Omonded current	Less than 2.5A	Less than 2.5A	
10 kg-cm (8.7 in-lb) loaded speed	52 rpm	68 rpm	
loaded current	Less than 3A	Less than 3.5A	
40 kg-cm (34.7 in-lb) loaded speed	40 rpm	50 rpm	
loaded current	Less than 6A	Less than 7.5A	
Locking torque	135 kg-cm (117.2 in-lb) or greater	125 kg-cm (108.5 in-lb) or greater	
Locking current	Less than 25A	Less than 25A	

Windshield wiper installing position

Install the windshield wiper blade in such a position that the blade comes into contact with the weather strip upper line lightly.

Tighten the windshield wiper blade arm lock nut under 80 to 100 kg-cm (70 to 87 in-lb) tightening torque.





Fig. BE-28

Windshield wiper motor connecting diagram






Fig. BE-29 Wiper blade operating range

WINDSHIELD WASHER

CONTENTS

REMOVAL	BE-18	TROUBLE DIAGNOSES AND	
Adjusting washer nozzle	BE-18	CORRECTIONS	BE-19

REMOVAL




Fig. BE-30 Structural view of windshield washer

Adjusting washer nozzle

When reassembling washer nozzle or washer fluid is not sprayed properly, adjust the nozzle direction using a pair of pliers so that fluid is sprayed in range indicated by asterisk mark (*) in Figure BE-31.

Washer tank capacity 1.5 liters (3.96 US gal, 3.30 Imp gal).

Precautions for usage of washer

Do not operate the windshield washer continuously for longer than 30 seconds or without fluid. (When the windshield washer is operated incorrectly, malfunction will result.)

Ordinarily, limit operating time within 10 seconds.




Fig. BE-31 Adjusting washer nozzle

TROUBLE DIAGNOSES AND CORRECTIONS

			<u> </u>	,
Trout	oles	Possible causes	Method of inspection	Corrective action
Fluid does not come out.	No motor operating sound	Blown off fuse Improper contact of each lead wire joint	Check the fuse box. Check the motor unit and switch unit for proper joint contact.	Replace fuse if required. Correct if required.
		Defective washer motor	Connect (+) and (-) terminals of the battery respectively to motor lead wires (blue) and (blue/red) with separate cables, and see if the motor operates. If not, the motor is defective.	Replace the motor with a new one.
Fluid does not come out.	Motor operating sound is audible	Incorrect piping	With the windshield washer switch turned on, measure voltage between two motor lead wires, and if the battery voltage is not detected, check the individual joints.	Correct.
		Lack of washer fluid	Check fluid level in tank.	Refill fluid.
The windshi		Defective switch.	With the windshield washer switch turned off, check the circuit between the wiper switch (yellow/blue) and (black) terminals for continuity. If there is continuity, the switch is defective.	Replace the switch with a new one.
		Short circuit.	Check wiring.	Repair wiring.

SWITCH

CONTENTS

COMBINATION SWITCH	BE-20	STEERING LOCK AND STARTER SWITCH	BE-2
HAZARD SWITCH	BE-21	WARNING BUZZER	BE-2

COMBINATION SWITCH




Fig. BE-32 Structural view of combination switch

The combination switch is split into two compartments; one consists of lighting switch, wiper switch,

and windshield washer switch, and the other consists of turn signal switch and dimmer switch.

Each switch operating force

 Turn signal switch
 0.2 to 0.6 kg (0.44 to 1.32 lb)

 Dimmer switch
 0.3 to 0.8 kg (0.66 to 1.76 lb)

 Windshield wiper switch
 1 to 3.3 kg (2.2 to 7.3 .b)

 Passing switch
 0.2 to 0.6 kg (0.44 to 1.32 lb)

 Lighting switch
 0.2 to 0.6 kg (0.44 to 1.32 lb)

 Windshield washer switch
 0.7 to 1.3 kg (1.54 to 2.87 lb)

Combination switch connection circuit

(1) Lighting/windshield wiper switch side

Conjunction table of Lighting Switch:

Terr Lever position	mi- nal Battery	parking lamp	Dimmer switch	Earth
OFF				
First step	0-6.	IA O		
Second step	○ <u>6.</u>	IA O	ე- <u>9.</u>	2A O

Conjunction of Wiper Switch:

Termi- nal Lever position	High	Low	Medium	Earth
OFF		O	○	
First step		0	5A 5/	0
Second step	O	5A	5	A

Fig. BE-33

(2) Turn signal lever side

Conjunction table of Dimmer Switch:

Termi- nal Lever position	Earth	Main switch	Dimmer switch
 Main switch 	O 9.	2A O	
Dimmer switch	0	9.2A	—-с

Conjunction table of Turn Signal Switch:

Lever nal position	Flasher	Stop switch	Front left	Front right	Rear left	Rear right
Left	Ç—		0-	5.8A 5.8A	<u> </u>	
Neutral		0—	5.8	A	5.8 5.8A	A _O
Right	O—	0	2.2A —	A.	——————————————————————————————————————	-

Fig. BE-34

HAZARD SWITCH

This switch is a tumbler switch. When removing, remove the installation screw from the switch boss portion.

When removing, use the tumbler switch replacer (special tool ST08900000).



Fig. BE-35

STEERING LOCK




Fig. BE-36 Steering lock

The steering lock is combined with the ignition switch to a single unit which contains warning buzzer microswitch for reminding the drive to lock the steering. The microswitch is connected to a warning buzzer.

WARNING BUZZER

(It operates if the door is unlocked with the key inserted in the steering lock)

The warning buzzer is installed on the steering support. When removing the warning buzzer, disconnect steering lock side microswitch cables, and remove two warning buzzer installation screws.




Fig. BE-37 Removing warning buzzer

HORN AND HORN RELAY

CONTENTS

TROUBLE DIAGNOSES AND	Adjusting horn volume BE-23
CORRECT N BE-23	

The horn is installed on the top of front crossmember. High tone horn is installed in the driver side and low tone horn is installed in the assistant side facing toward front. The horn relay is installed on the left side dash side panel.




Fig. BE-38 Horn and horn relay circuit diagram

Adjusting horn volume

- 1. Apply voltage meter and connect cables as shown in Figure BE-39.
- 2. Turn on the switch, make sure that the voltmeter indicates 12 to 12.5V, and adjust as described below so that the ammeter indicates approximately 3A.
- 3. Lock nut in reverse side of the body
 - (1) Turn the lock nut in counterclockwiseVolume and current increases.
 - (2) Turn the lock nut in clockwise Volume and current reduces.
- 4. When a proper volume is obtained through the above described method, raise the voltage to 14 or 15V, and further adjust the volume to better sound.
- 5. A proper sound obtained at range from 12 to 15V is the best adjusting point.

Lock the nut at that position.




Fig. BE-39 Circuit diagram of horn




Fig. BE-40 Adjusting horn volume

TROUBLE DIAGNOSES AND CORRECTIONS

Troubles	Possible causes	Method of inspection	Corrective action
The horn does not operate.	Excessively discharged battery	Measure specific gravity of electrolyte.	Charge if discharged.
	The battery is normal. Broken lead wire between horn relay (S) terminal and horn button.	The horn does not sound although the horn relay terminal (S) is grounded, but sounds when the terminals (B) and (H) are short- circuited.	

	 Improper horn button contact Defective horn relay Defective horn Blown off fuse 	The horn does not sound although the horn relay terminals (B) and (H) are short-circuited, and the horn still does not sound although the battery (+) terminal is connected to the horn terminal directly. When the horn sounds through the above inspection, check the fuse for wear, fusing, or improper contact.	Replace.
The horn sounds continuously.	. Defective horn relay . Short-circuited horn button and horn relay terminal (S).	The horn does not stop although the horn relay (S) terminal is disconnected. When the horn stops through the above disconnection, check the horn button unit particularly carefully.	Replace horn relay. Replace horn button (Switch).
Reduced volume and/or tone quality	Improper fuse wire contact Broken cable Improper horn button contact Worn horn point Broken resistance circuit cable		Correct. Repair. Repair. Adjust or replace. Replace the resistance with a new one.

RADIO

CONTENTS

Installation	BE-25	Installing antenna	BE-26
Radio specifications	BE-25	Antenna specifications	BE-27
Installing speaker	BE-26	Auto-antenna switch circuit	BE-27




Fig. BE-41 Structural view of radio

The radio receiver proper is a special unit designed for the Model S30 vehicles. The radio receiver unit is fitted into the instrument console box in flush.

The speaker is fitted into the left of the rear side inner. The antenna is a power-drive antenna, and the length is 1,020 mm (40.5 in) when fully extended.

For the detail of Radio refer to "All transistor car Radio MODEL TM-1081ZA service manual" which is published by Hitachi, Ltd.

Installation

When installing the radio receiver proper, first, install the radio on the instrument console finisher, and fit it into the instrument console. The radio manufacturer is Hitachi, Ltd.

Radio specifications

Model	TM-1081ZA
Manufacturer	Hitachi, Ltd.
Receiving system	ΛM
Circuit system	Superheterodyne
Receiving frequency	535 to 1,605 KC
Intermediate frequency	455 KC

Maximum sensitivity	Less than 20 db
Maximum output	6W
Speaker	130 mm (5.12 in) PM Type (Impedance: 4 Ω)
Rated current	90 mA
Rated voltage	12V (-) grounded
Used transistors	10 transistors, 5 diodes, and 2 thermistor




Fig. BE-42 Installing speaker and antenna

Installing antenna

First, install the speaker main unit and speaker hood on the speaker mounting bracket. With the speaker installed on the bracket, install the speaker mounting bracket on the body.

Installing speaker

- 1. Insert the antenna into the antenna installation hole on the left side rear fender from the passenger compartment side.
- 2. Install the antenna mounting bracket on the body side.
- 3. Install the antenna upper unit from the outside of the rear fender.




Fig. BE-43 Installing antenna

Antenna specifications

Rated voltage	12V (-) grounded
Rated current	Less than 6A
Operating voltage range	10.5 to 16.0V (Starting voltage: 9V)
Locking current	Less than 6A
Model	RO-74

Auto-anntena switch circuit




Fig. BE-44 Circuit diagram of auto-antenna

CLOCK

CONTENTS

Installation BE-28 Adjusting clock BE-28




Fig. BE-45 Installing clock

Installation

- Remove the center console finisher.
- 2. Remove the radio mask, and install the clock thereon.
- 3. Secure the radio bracket on the L-shape bracket in the instrument panel side with screws.




Fig. BE-46 Clock

Adjusting clock




Fig. BE-47 Adjusting clock

Remove the vinyl cover, and adjust the adjusting screw shown in the above figure. When the adjusting screw is turned to "F", the clock gain and retard when turned to "S".

Recommend the adjustment be not made unless the clock is out of order considerably.

Be sure to reinstall the vinyl cover after adjustment. (The vinyl cover protects the clock from dust and other foreign matters.)

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
	•		

			
DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
,			
		· 	
			-
			
			- A
	!		
-			
<u> </u>			
	· · · · · ·		

DATSUN 240Z SPORTS
MODEL S30 SERIES
CHASSIS & BODY



NISSAN MOTOR CO., LTD. TOKYO, JAPAN

SECTION SE SERVICE EQUIPMENT



SPECIAL SERVICE TOOL -----SE- 1

SERVICE EQUIPMENT

SPECIAL SERVICE TOOL

Tool number (Former tool number) Figure Tool name mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
---	-------------	------------------------------------	------------------------------------	------------------	--

Clutch and transmission

S30 special service tool set number 510 special service tool set number

ST09290000 ST09110000

ST20630000 (ST44450000) Clutch aligning bar	205 (8.1) 22.9 dia. (0.90 dia.) 15.8 dia. (0.62 dia.)	For centering the clutch disk		130 HA30 521	Fig. CL-14
ST20240000 Height gauge	44 (1.73)	For measuring the diaphragm spring height (Use with the distance piece)	•	New	Fig. CL-6
ST20051000 Clutch assembly base plate		For measuring the diaphragm spring height (Use with the distance piece)		130 \$30 510 521 4W73 60 41 C240 C80	Fig. CL-5
ST20058001 Clutch assembly distance piece	7.8 (0.307)	For measuring the diaphragm spring height (Use with the base plate)		510 521	Fig. CL-5

CHASSIS

Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST20052000 Clutch assembly center pole	3/4" dia. (0.0295 dia.)	For measuring the diaphragm spring height (Use with the height gauge)			130 C30 510 521 4W73 60 41 C240 C80	Fig. CL-6
ST20500000 (ST49400000) Diaphragm adjust wrench	3.2 (0.126)	For measuring the diaphragm spring height			HA30 C30 C10 510 SP(R)	Fig. CL-7
ST23810000 (ST44250000) Setting plate adaptor	8.3 dia. (0.3268 dia.) 90 (3.54) 37 (1.46)	Setting plate of the transmission gear	•		130 HA30 SP(R)	Fig. TM-11
ST23800000 (ST43920000) Transmission adaptor	480 (18.9) outer dia, 44 (1.73) inner dia, 31 (1.22)	For assembly of the main drive gear			130	Fig. TM-39
ST30600000 (ST43770000) Drift B	outer dia. 36 (1.42) inner dia. 31 (1.22)	For assembly of the counter drive gear	•			Fig. TM-40 Fig. TM-47

SERVICE EQUIPMENT

Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST22360000 (ST43910000) Drift C	outer dia. 30 (1.18) inner dia. 21 (0.83)	For assembly of the counter bearing	•		130 HA30 SP(R)	Fig. TM-60
ST23530000 Solid punch	1.8 dia. (0.0709 dia.) 130 (5.1)	For removal of the control arm retaining pin	•		SP(R)	Fig. TM-64
ST23500000 (ST44260000) Fork rod pin punch	3 dia. (0.118 dia.) 120 (4.7) 40 (1.57)	For removal of the fork rod retaining pin			130 HA30 SP(R)	Fig. TM-11

Differential carrier

ST06270000 (ST37400510)				
Gear carrier, strut, gear box attachment	541 (21.3)	Setting tool of gear carrier (Use with engine stand)	510 C10 C30	Fig. PD-3

CHASSIS

	· · · · · · · · · · · · · · · · · · ·					
Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST30030000 (ST49280000) Drive pinion rear bearing inner bearing replacer set	38 dia. (1.50 dia.)	For assembly and disassembly of the drive pinion bearing inner race		0	510 C10 C30 521	Fig. TM-21 Fig. TM-23 Fig. TM-24 Fig. PD-9
ST30610000 (ST49290000) Drive pinion outer race drift kit	48 dia. (1.89 dia.) 40 dia. (1.57 dia.)	For assembly of the drive pinion bearing outer race			510 C30	Fig. PD-10
ST31210000 (ST49300000) Gear carrier height gauge assembly		For height adjustment of the drive pinion		O	510	Fig. PD-19 Fig. PD-21
ST31500000 (ST49310000) Drive pinion collar		Dummy shaft for measure of the drive pinion pre-load (Use with gear carrier height gauge)			510 C30	Fig. PD-21

SERVICE EQUIPMENT

Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST31530000 (ST47340000)					130	
Drive pinion flange wrench	440 (17.3) 54 (2.13) pitch dia. 70 (2.76)	For removal of the drive pinion nut			HA30 C30 C10 510 521	Fig. PD-7
ST31850000 (ST49660000)	39 (1.54)				,,,	
Dummy spacer	(1.54)	Dummy shaft for height adjustment of the drive pinion	•	į	C30	Fig. PD-21
ST33012000 (ST46862000)	28.5 dia. (1.12 dia.)					
Adaptor	25 (0.98)	For disassembly of the side bearing		0	510 C30	Fig. PD-11
ST33230000 (ST49260000)	178 (7.0)					
Gear carrier side bearing drift	28 dia, (1.10 dia.)	For assembly of the side bearing			510 C30	Fig. PD-17
ST33270000 (ST49320000)						
Gear carrier oil seal drift		For assembly of the oil seal		0	510 C30	Fig. PD-14

CHASSIS

	· • · · · · · · · · · · · · · · · · · ·					
Tool number (Former tool number Tool name	Figure mm (inc	Description h)	S30 special service tool	510 special service tool	Applied model	(See
ST33290000 (ST49240000) Gear carrier oil seal puller	160 (6.3)	For disassembly of the oil seal		0	510 C30	Fig. No.)
ST33710000 (ST49230000) Gear carrier side retainer attachment	24 dia (0.94 dia.)	For disassembly of the side retainer		0	510 C30	Fig. PD-5
ST33730000 (ST49250000) Gear carrier side flange stand	12 dia. (0.47 dia.) 48.2 (1.90) pitch dia. 75 (2.95 in)	For removal of the side flange (Use with sliding hammer)		0	510 C30	Fig. PD-4
ST36230000 (ST46780000) Sliding hammer	830 (32.7)	Sliding hammer use with rear axle stand or side flange stand	-	-		Fig. PD-4 Fig. RA-22
ST23510000 (ST49270000) Differential locking in punch	4 dia. (0.1575 dia.) 95 (3.74) 55 (2.17)	For removal of pinion mate shaft lock pin) C	510 C10 H	Fig. PD-12

SERVICE EQUIPMENT

		<u></u>	т	,		
Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	\$10 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST30650000 Pilot bearing drift	430 (17.0) 32 dia. (1.26 dia.)	For disassembly of the pilot bearing	•		New	Fig. PD-8
ST33252000 (DT-49942000) Adaptor	79.5 dia. (3.13 dia.)	For assembly of the front oil seal	•		New	Fig. PD-1.2
ST33720000 (DT-4933) Side retainer guide	M8 × 1.25 (M0.3150 × 0.0492) 40 (1.57)	The guide pin for assembly of the side retainer		0	New	Fig. PD-22

Front axle and suspension

ST35650000 Coil spirng compressor set	For assembly and disassembly of the coil spring	New 510 C30 C10	Fig. FA-3
	coil spring max. dia. 165 (6.5) stroke 50 to 239 (1.97 to 9.4)		

CHASSIS

Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST35540000 Gland packing guide	25.3 dia. (1.00 dia.)	For assembly of the gland packing			New	Fig. FA-35
ST35500000 (ST4913A000) Gland packing wrench	100 (3.9) -12.7 (0.50) width across flats; 55 (12.7)	For tightening grand packing		0	510 C10 C30	Fig. FA-31 Fig. FA-37
ST36710000 Front transverse link bushing replacer	13.5 dia. (0.53 dia.) 34.5 dia. (1.36 dia.)	For assembly and disassembly	•		New	Fig. FA-46
ST35300000 Front wheel bearing drift	41.5 dia. (1.63 dia.) 59 dia. (2.32 dia.)	For assembly of the front wheel bearing	•		New	Fig. FA-19

SERVICE EQUIPMENT

Rear axle and suspension

					,	
ST07640000 (ST46790000)						
Rear axle stand	13 dia. (0.51 dia.) 80.8 (3.18)	For removal of the rear axle shaft (Use with sliding hammer)			510 C10 C30 B10	Fig. RA-21 Fig. RA-22
	pitch dia, 114.3 (4.5)					
ST33260000 (ST49150000) Differential mount- ing member insulator drift set	15.2 dia. (0.60 dia.) 15.2 dia. (0.60 dia.) 48 dia. (1.89 dia.) 62 dia. (2.44 dia.)	For assembly and disassembly of the differential mounting member insulator		0	510 C30	Fig. RA-6
ST38800000 Rear transverse link bushing replacer	29,5 dia. (1.16 dia.) 34 dia. (1.34 dia.) 15,5 dia. (0.61 dia.)	For assembly and disassembly of the rear transverse link bushing	•		New	Fig. RA-5
ST38300000 (ST49210000) Drive shaft snap ring plier	220 (8.7)	For removal of the drive shaft snap ring		0	510 C30	Page RA-11

CHASSIS

Tool number (Former tool number) Tool name	Figure mm (inch)	Description	S30 special service tool set	510 special service tool set	Applied model	S.M. reference page (See Fig. No.)
ST37780000 Rear axle shaft outer bearing drift	160 (6.3) 40 dia. (1.57 dia.) 33 dia. (1.30 dia.)	For assembly of the rear wheel bearing (outer side)	•		New	Page RA-10

Master - Vac.

ST08050000 Master-vac. wrench set	ST08051000 ST08052000	For disassembly of the master-vac.	•	C30	Fig. BR-45
ST08060000 Press fit tool		For assembly of the front oil seal retainer	•	C30	Fig. BR-53

Body electrical

Tumbler switch replacer	6 dia. (0.2362 dia.) 18 (0.709)	For assembly and disassembly of the tumbler switch	•		Fig. BE-35
	290 (11.4)	Tool box for special service tool set	•		

SERVICE EQUIPMENT

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
			
		<u>.</u> .	

-			

CHASSIS

	T	. ,	
DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
-		·	
	-		
			·
	·		

SERVICE EQUIPMENT

()

DATE	JOURNAL or BULLETIN No.	PAGE No.	SUBJECT
	·		
		·	
	·		
<u> </u>			
<u> </u>			
			. ,
		 -	